

**ZX6 & ZX8
TRUE VERTICAL LIFT
ELECTRIC WIRE ROPE HOIST**



**INSTALLATION, OPERATION
AND
MAINTENANCE INSTRUCTIONS**



INTRODUCTION

This manual has been carefully prepared to assist you in the installation, maintenance and safe operation of the Street Crane equipment as described in the manual. It is in the interest of all parties involved with the use of this equipment to ensure that procedures are followed efficiently and safely.

Before installing, using or starting any maintenance work on the hoist study this manual carefully. Obtain a complete understanding of the hoist and its controls in order to ensure the safe and efficient use of the hoist. Ensure that all persons involved in the operation are suitably qualified and trained in its safe operation.

Provided that the recommended operation, maintenance and lubrication procedures are followed, you will maximise the Hoists life expectancy and have trouble free service.

Anyone working with or on the equipment should also be aware of their relevant responsibilities under the Factories Act, the Health and Safety at Work Act 1974 and Lifting Operations and Lifting Equipment Regulations (LOLER) 1998. The user has the responsibility for ensuring that the equipment is properly inspected and maintained and is safe to use.

NOTE: Other national regulations may apply for other countries.

In Great Britain codes of practice exist for the "Safe Use of Cranes". This standard, BS 7121, also covers inspection, testing and examination. The user should be familiar with its contents and it is advisable to have a copy of this standard kept alongside this manual. BS 7121 covers the following subjects:-

- Safe systems of work
- Management of the lifting operation
- Planning of the lifting operation, risk assessments and method statements
- Selection and duties of personnel and their minimum attributes
- Maintenance of cranes
- Inspection, Testing and Examination

In addition, management and supervision have an initial role to play in any safety programme by ensuring that:-

- The equipment is suitable for the job intended
- The equipment has been thoroughly examined and is safe to use
- A safety procedure is adopted for emergency situations i.e. power failure
- A safe system of work is adopted for maintenance personnel

It should be emphasised that the safety advice and maintenance details included in this document should be made available where they can be most effective. It is your responsibility to ensure that this information is made available at THE PLACE OF WORK.

THIS PAGE IS INTENTIONALLY BLANK

CONTENTS

1. GENERAL SAFETY INSTRUCTIONS	10
1.1 SYMBOLS.....	10
1.2 PERSONNEL - Definitions and Attributes	10
1.3 MAINTENANCE SAFETY PROCEDURE	10
1.4 MAINTENANCE AND INSPECTION ACCESS.....	11
1.5 WARRANTY / REPLACEMENT PARTS.....	11
1.6 PERIODIC TESTS	11
1.7 STORAGE.....	11
1.8 TRAINING AND AFTER SALES SERVICE	11
2 DESCRIPTION OF EQUIPMENT.....	12
2.1 HOIST NAMEPLATE	14
2.2 LIMITING DEVICES.....	15
2.2.1 Hoisting and lowering limits.....	15
2.2.2 Rated capacity limiter (RCL)	15
2.2.3 Travel / Traverse limits (optional).....	15
3 INSTALLATION AND COMMISSIONING INSTRUCTIONS	16
3.1 TRAVERSE END STOPS.....	16
3.2 RUNNING & MOUNTING SURFACE TOLERANCES AND FINISHES.....	17
3.2.1 Tolerances on the Inclination of the Running Surface	17
3.2.2 Tolerances on Crab Rail Gauge & Rail Height.....	17
3.2.3 Tolerances on Single Girder Runway Flange Width	17
3.2.4 Tolerances on Mounting Surface for Foot Mounted Hoists.....	17
3.2.5 Tolerance on misalignment of rail joints, wheel running surfaces and guidance surfaces.....	18
3.3 HOIST WEIGHTS AND LIFTING POINTS.....	18
3.3.1 Low Headroom.....	18
3.3.2 Double Girder Crab	19
3.3.3 Foot Mounted	20
3.4 INSTALLATION OF LOW HEAD 4&8 FALL SINGLE GIRDER HOIST	21
3.4.1 Setting the Reaction Roller.....	23
3.5 INSTALLATION OF FOOT MOUNTED HOIST	24
3.6 SETTING THE UPPER AND LOWER LIMIT SWITCHES – ROPE GUIDED.....	25
3.6.1 Setting the lower limit.....	25
3.6.2 Setting the upper limit	25
3.7 SETTING THE UPPER AND LOWER LIMIT SWITCHES – OPEN BARREL.....	26
3.7.1 Setting the Hoist Upper limit.....	26
3.7.2 Setting the Hoist Lower limit.....	27
3.8 ULTIMATE UPPER LIMIT SWITCH - ROTARY (OPTIONAL).....	27
3.8.1 Setting the ultimate upper limit.....	27
3.9 ULTIMATE UPPER LIMIT SWITCH – HOOK BLOCK OPERATED (OPTIONAL).....	29
3.9.1 Setting the ultimate upper limit.....	29
3.10 LOW HEADROOM HIGHEST HOOK POSITION- 4 FALL & 8 FALL	30
3.11 FOOT MOUNT HIGHEST HOOK POSITION- ZX6 & ZX8.....	31
3.12 DOUBLE GIRDER PARALLEL CRAB HIGHEST HOOK POSITION- ZX6 & ZX8.....	31
3.13 DOUBLE GIRDER PERPENDICULAR CRAB HIGHEST HOOK POSITION- ZX8	32
3.14 CHECKING / ADJUSTING THE RATED CAPACITY LIMITER	33
3.14.1 Adjusting the Rated Capacity Limiter for Proof Loading	33

3.15	TRAVERSE LIMITS (OPTIONAL)	34
3.15.1	Setting traverse limits.....	34
3.16	CONNECTING THE POWER SUPPLY	36
3.16.1	Supply cables / fuses	36
3.16.2	Main isolator – supply switch (by others)	36
3.16.3	Connecting to the mains supply	36
3.16.4	Electromagnetic compatibility.....	38
3.16.5	Connecting the Pendant controller – Low Headroom.....	38
3.17	COMMISSIONING PROCEDURE	39
3.18	DISMANTLING / REMOVAL OF THE HOIST	39
4	OPERATING INSTRUCTIONS	40
4.1	INTENDED USE	40
4.2	DUTIES OF THE OPERATOR / SAFE HOISTING PRACTICES.....	40
4.3	REMOTE CONTROLLED CRANES / HOISTS.....	42
4.4	CONTROL STATION OPERATING INSTRUCTIONS	43
4.4.1	Legend Nomenclature	43
4.4.2	Switch ON.....	43
4.4.3	Push button operation	43
4.4.4	Joystick operation	44
4.4.5	Emergency Stop	44
4.5	LEAVING THE CRANE / HOIST UNATTENDED	46
4.6	POWER FAILURE	46
5	INSPECTION AND MAINTENANCE INSTRUCTIONS.....	47
5.1	REPORTING OF DEFECTS AND INCIDENTS	47
5.2	SPECIAL KNOWLEDGE	47
5.3	KEEPING OF RECORDS.....	47
5.4	DAILY PRE-USE INSPECTIONS (at the start of each day/shift).....	47
5.5	HOISTS THAT HAVE BEEN UNUSED FOR AN EXTENDED PERIOD	48
5.6	INSPECTION AND MAINTENANCE INTERVALS	49
5.7	LUBRICATION	52
5.7.1	Lubrication Schedule	54
5.8	INSPECTION AND MAINTENANCE – WIRE ROPE.....	56
5.8.1	Offloading and Storage	56
5.8.2	Replacing the Wire Rope.....	56
5.8.3	Fitting the Rope Guide	61
5.9	INSPECTION AND MAINTENANCE- HOIST / CRAB FRAME	63
5.9.1	Sheaves	63
5.9.2	Single Girder Wheels	64
5.9.3	Double Girder Crab Wheels (Double Flange)	64
5.10	INSPECTION AND MAINTENANCE – HOIST BRAKE	65
5.10.1	Hoist Brake Components.....	65
5.10.2	Hoist Brake Data.....	66
5.10.3	Brake Disc (Rotor) Spline	66
5.10.4	Checking / Adjusting the Air Gap.....	66
5.10.5	Changing the Brake Disc (brake rotor) / Inspecting the brake hub	67
5.10.6	Fitting the Hand Release	68
5.10.7	Fitting the brake seal kit (optional)	69

5.10.8	Brake rectifier	69
5.11	INSPECTION AND MAINTENANCE – TRAVERSE BRAKE	70
5.11.1	Traverse Brake Components	70
5.11.2	Checking / Adjusting the Air Gap.....	71
5.11.3	Changing the Brake Disc (brake rotor) / Inspecting the brake hub	71
5.11.4	Fitting the Traverse Drive Hand Release	72
5.11.5	Fitting the brake seal kit (optional)	73
5.12	INSPECTION AND MAINTENANCE – HOOK BLOCK	74
5.13	INSPECTION AND MAINTENANCE – HOIST DRIVE COUPLING.....	76
6	FAULT FINDING	77
6.1	GENERAL	77
6.2	BRAKES.....	78
6.3	MOTOR UNITS.....	79
6.4	GEARBOXES.....	80
7	TECHNICAL DATA.....	81
7.1	CONDITIONS OF USE.....	81
7.2	PROCEDURE FOR ESTIMATING REMAINING SERVICE LIFE.....	81
7.3	HOIST MODEL CODE	82
7.4	NOISE LEVELS.....	85
7.5	HOIST MOTOR DATA.....	86
7.5.1	ZX06 Hoist Motor Data – 3:1 SPEED RATIO - 400V, 3Ph, 50Hz.....	86
7.5.2	ZX08 Hoist Motor Data – 4:1 SPEED RATIO - 400V, 3Ph, 50Hz.....	86
7.5.3	ZX06 Hoist Motor Data – 3:1 SPEED RATIO – 460V, 3Ph, 60Hz.....	87
7.5.4	ZX08 Hoist Motor Data – 4:1 SPEED RATIO - 460V, 3Ph, 60Hz.....	87
7.5.5	ZX06 Hoist Motor Data – 3:1 SPEED RATIO - 575V, 3Ph, 60Hz.....	88
7.5.6	ZX08 Hoist Motor Data – 4:1 SPEED RATIO - 575V, 3Ph, 60Hz.....	88
7.5.7	ZX06 Hoist Motor Data – 3:1 SPEED RATIO - 380(±10%)V, 3Ph, 60Hz.....	89
7.5.8	ZX08 Hoist Motor Data – 4:1 SPEED RATIO - 380(±10%)V, 3Ph, 60Hz.....	89
7.5.9	ZX Dual Wound ‘WU’ Type Traverse Motor Data- 400V 50Hz	90
7.5.10	ZX Dual Wound ‘WU’ Type Traverse Motor Data- 460V 60Hz	91
7.5.11	ZX Dual Wound ‘WU’ Type Traverse Motor Data- 575V 60Hz	92
7.5.12	ZX Dual Wound ‘WU’ Type Traverse Motor Data- 380V 60Hz	93
7.5.13	ZX Traverse Motor Data for use with Frequency Inverter.....	94
7.6	CABLE CROSS SECTION AND LENGTH OF SUPPLY CABLE	95
7.7	RESULTS OF PERIODIC TESTS	96
7.8	RECORD OF REPLACEMENT PARTS (ropes, brakes, sheaves etc.).....	97

FIGURES

Figure 1	– Hoist Nameplate Location	14
Figure 2	– Single Girder 4 & 8 Fall Traverse End Stops.....	16
Figure 3	– Double Girder Traverse End Stops	16
Figure 4	– Single Girder Runway Tolerances.....	18
Figure 5	– Double Girder Runway Tolerances.....	18
Figure 6	– Low Headroom 4&8 Fall Lifting Points	18
Figure 7	– Double Girder Crab Lifting Points – 4 & 8 fall units.....	19
Figure 8	– Foot Mounted Lifting Points.....	20

Figure 9 – Installing the Low Headroom Trolley	21
Figure 10 – Withdrawing the Reaction Roller	21
Figure 11 – Low Headroom Runway Clearance	22
Figure 12 – Setting the Low Headroom Legs.....	22
Figure 13 – Low Headroom Hoist Transportation Feet.....	23
Figure 14 – Reaction Roller	23
Figure 15 – Installation of Foot Mounted Hoist	24
Figure 16 – Hoist Limit Switches – Standard Environment Rv-1 (see hoist nameplate for revision)	25
Figure 17 – Setting the Upper/Lower Limit Switch – Rotary Type	26
Figure 18 – Ultimate Upper Limit Switch – Rotary Type	27
Figure 19 – Ultimate Upper Limit Switch – Hook Block Type.....	29
Figure 20 – Rated Capacity Limiter	33
Figure 21 – Setting the Traverse Limit - Single Girder Arrangement	34
Figure 22 – Traverse Limit Double Girder arrangement	35
Figure 23 – Hoist Electrical Connections.....	36
Figure 24 – Delay Timers.....	37
Figure 25 – Phase Failure Relay.....	37
Figure 26 – Control Transformer Connections.....	38
Figure 27 – Strainer Wire Connections	38
Figure 28 – Clearances to consider when lifting	41
Figure 29 - Recommended Hand Signals.....	42
Figure 30 – Control Pendant Legends	43
Figure 31 – ZX6 Gearbox oil fill & level plug locations	52
Figure 32 – ZX8 Gearbox oil fill & level plug locations	53
Figure 33 – Correct Uncoiling of Wire Ropes	57
Figure 34 - Incorrect Uncoiling of Wire Ropes	57
Figure 35 – Winding of new wire ropes	57
Figure 36 - Fleet angle.....	58
Figure 37 – Reeving Diagrams for ZX6 & ZX8 4&8 Fall Low Head & Crab Hoists	59
Figure 38 – Reeving Diagrams for Foot Mount Hoists: ZX084-FTM / ZX088-FTM	59
Figure 39 – Reeving Diagrams for Foot Mount Hoists: ZX064-FTM	60
Figure 40 –Fitting Top and Bottom Halves of Rope Guide Inner Band	61
Figure 41 – Rope Guide Inner Band Spring and Sleeve Arrangement.....	61
Figure 42 – Rope Guide Inner Band Fitted	62
Figure 43 – Fitting Rope Guide Outer Band	62
Figure 44 – Fitting Rope Guide Retainer – Standard Environments Rv-1 (see hoist nameplate for revision)	63
Figure 45 - Sheave characteristics.....	63
Figure 46 - Sheave and barrel groove inspection.....	64
Figure 47 – Hoist Brake Components.....	65
Figure 48 – Checking Hoist Brake Air Gap	66
Figure 49 – Adjusting the Hoist Brake Air Gap	67
Figure 50 – Inspecting the Brake Disc	67
Figure 51 – Hoist Brake Hand Release	68
Figure 52 – Brake Seal.....	69
Figure 53 – Traverse Brake Components	70
Figure 54 – Checking Traverse Brake Air Gap	71
Figure 55 – Adjusting the Traverse Brake Air Gap	71
Figure 56 – Traverse Drive Brake Hand Release	72

Figure 57 – Traverse Drive Brake Seal.....	73
Figure 58 – Hook Throat Admittance	74
Figure 59 – 4 Fall Bottom Block, Hook Nut, Grubscrew, Grease nipple.....	75
Figure 60 – Sound Pressure Levels.....	85

1. GENERAL SAFETY INSTRUCTIONS

1.1 SYMBOLS



WARNING – This symbol draws attention to the possible injury or risk of life.



WARNING OF ELECTRICAL POTENTIAL – This symbol is found on electrical enclosures. These should only be opened by qualified persons or suitably instructed personnel.



WARNING OF SUSPENDED LOAD – This symbol warns of the risk to life and limb from standing under a suspended load.

1.2 PERSONNEL - Definitions and Attributes

The user should ensure that the person carrying out any task has such appropriate practical and theoretical knowledge and experience of the equipment in question as will enable them to perform the task safely and recognise any hazards associated with the work. They should be physically and mentally fit and trained in Safe Hoisting Practices and the use of safety and access equipment. No work of any kind should be authorised to persons who are under the influence of narcotics, alcohol or medication, which affects their ability to react. Hazards can only be minimised by care, common sense and being alert at all times.

Various personnel can be involved in the lifting operation, installation and inspection and maintenance of the equipment, supervisors, coordinators, operators, slingers, signallers, erectors and maintenance personnel. The duties of these personnel and their minimum attributes are defined in BS 7121-1:2006. Also, ISO 15513 gives competency requirements for crane drivers (operators), slingers, signallers and assessors. In the text of this manual the following definitions apply:-

User – person or organisation that has control of both the lifting operation and the crane operator and has the responsibility to ensure the equipment is properly maintained and thoroughly examined by a competent person.

Competent Person – person who has such practical and theoretical knowledge and mechanical and / or electrical experience of the crane / hoist and the equipment used in the lifting operation which enables them to detect defects or weaknesses and to assess their importance in relation to the safety and continued use of the lifting equipment.

Operator- trained person who is operating the crane / hoist for the purpose of positioning loads.

1.3 MAINTENANCE SAFETY PROCEDURE

When personnel are required to work on the crane / hoist for inspection, maintenance or other reasons, a system should be in operation to ensure that they are not endangered by movement of the equipment and that a secure working place is provided. Personnel should follow such a procedure. Where no formal procedure exists, Street Crane recommends the following:-

On commencing any maintenance work on the crane or hoist:-

1. Obtain the necessary authorisation / permit to work.
2. Park the crane or hoist in a designated maintenance position, clear of any personnel.
3. Follow the appropriate health and safety regulations and procedures.
4. Remove any loads or attachments from the hook and ensure that the bottom block is suitably supported to prevent accidental runaway.

5. Disconnect the mains switch and safeguard against unauthorised powering up, by placing locks and warning notices in the appropriate positions.



Some maintenance procedures are more effectively performed with power to the equipment. If work has to be carried out on live parts, an additional competent person must be available to actuate the power isolating switch in an emergency. Ensure that there is an effective manner of communication between personnel.

6. To avoid injuries, use only insulated tools and equipment.
7. On completion of any maintenance work, ensure all fixings, guards, covers, drip trays, etc. are replaced.

1.4 MAINTENANCE AND INSPECTION ACCESS

The equipment itself may have no provision for maintenance access or it may be fitted with full or partial maintenance access platforms. Where no or only partial access has been provided on the equipment, separate or additional access equipment will be required to service some of the components. These components should be accessed via a secure, mobile or temporary structure e.g. tower scaffold, self-standing stair platforms, scissor-lift or cherry picker. All access equipment should be assembled and operated by trained personnel in accordance with the manufacturer's instructions following the appropriate health and safety regulations and procedures.

The following should be considered when choosing the most appropriate type of maintenance access equipment.

- Floor space available for the access equipment.
- Working height above floor level.
- Number of personnel who require access at high level.
- Total weight of any parts to be removed / replaced.
- Provision of safety harness anchor points

1.5 WARRANTY / REPLACEMENT PARTS

The warranty will become invalid if the instructions for installation, operation and maintenance instructions contained in this manual are not followed.

Where replacement components are required use only genuine Street Crane parts. Modifications to the crane or any of its mechanisms should not be carried out without the approval of Street Crane Company Limited. Failure to adopt these recommendations will invalidate the warranty and could result in an unsafe condition. Please dispose of electrical and electronic equipment in an approved and environmentally friendly manner.

1.6 PERIODIC TESTS

The hoist must be inspected by a competent person at least once a year. The competent person may consider shorter periods to be more appropriate depending on the duty of the hoist. A record of the results of the test should be kept in the hoist log book, section 7.7. As part of the annual test the remaining service life of the hoist should be established, see section 7.2.

1.7 STORAGE

If the hoist is to be placed in storage for any period of time ensure that:-

- The hoist is covered and stored indoors in a heated building.
- Pack the hoist clear of the floor. Raise the bottom block to its top position and ensure that there are no 'kinks' in the wire rope.
- Ensure all electrical switches are turned to the OFF position.
- Always fully inspect the hoist before installing and putting into service.


1.8 TRAINING AND AFTER SALES SERVICE

If required, Street Crane Company are able to provide trained service technicians to assist in inspection and maintenance procedures and provide operator training.


2 DESCRIPTION OF EQUIPMENT

The ZX series hoist is of the electrically driven wire rope type. The hoist has a maximum load that it is permitted to lift. This is referred to as the Rated Capacity or Safe Working Load (SWL). The rated capacity is clearly marked on the hoist nameplate and the bottom block.


- | | | |
|------------------|------------------------------|------------------------------|
| 1. Hoist motor | 6. Control panel | 11. Upper level limit switch |
| 2. Hoist brake | 7. Travel drive | 12. Lower level limit switch |
| 3. Wire rope | 8. Reaction roller (LH only) | 13. Rope guide |
| 4. Bottom block | 9. Travel wheels | 14. Rope clamps |
| 5. Hoist gearbox | 10. Rated capacity limiter | 15. Sheave assembly |




ZX8-4 FALL LOW HEAD




ZX6-4 FALL LOW HEAD




ZX8-8 FALL LOW HEAD




ZX8-4 FALL CRAB




ZX6-4 FALL CRAB




ZX8-8 FALL CRAB



ZX8-4 FALL FOOT MOUNT



ZX6-4 FALL FOOT MOUNT



2.1 HOIST NAMEPLATE

The hoist nameplate is located on the hoist end frame and contains the following information:

- The hoist model code.
- The manufacturers name.
- The serial number.
- The year of manufacture.
- Hoist classification.
- Mechanism classifications.

The information on this nameplate will be required when ordering replacement parts and when assessing the remaining service life of the hoist. Further information on the hoist model code can be found in section 7.3.




Figure 1 – Hoist Nameplate Location

2.2 LIMITING DEVICES

Each hoist is fitted with upper and lower limits and a rated capacity limiter (RCL). These are essential items for the safe operation of the hoist. Additional limiting devices may be fitted if deemed necessary by the risk assessment.

2.2.1 Hoisting and lowering limits

Hoisting and lowering limit switches are fitted to all hoists to prevent the hook from going too high and damaging the hoist and from going too low so as to allow the ropes to go slack. These are safety devices and should **NOT** be used as a normal method of stopping the hoist. Movement in the opposite direction, at the speed selected by the operator (slow or fast) is still possible after the normal limit has been triggered.



Certain crane configurations allow the upper hook position to be set at a higher level than the underside of the bridge girders (double girder cranes). In such instances the operator must take extreme care when lifting to ensure that adequate clearance is maintained between the load or lifting attachment and the hoist or crane structure.

An optional second hoist upper limit or ultimate limit may also be fitted if deemed necessary by the user risk assessment.

The ultimate limit is an emergency limit employed only if the normal upper limit fails. Once tripped, the limit must be manually re-set by service or maintenance personnel and will require the hook block to be lowered manually and the limit re-set. If the second hoist upper limit operates, the hoist should be taken out of service until the reason for the normal upper limit switch failure has been investigated. The failure should be rectified before putting the hoist back into service.

The second hoist upper limit, when tripped, will prevent movement from all hoist and traverse motions. The travel motion (long travel) will remain fully operable.

A red warning light on the base of the control panel will illuminate to indicate when the second ultimate limit has been activated.

2.2.2 Rated capacity limiter (RCL)

All hoist units are fitted with a rated capacity limiter (RCL) to prevent the lifting of loads beyond the capacity of the hoist / crane. If the RCL is tripped the hoist motion will stop and it will then only be possible to move in the lower direction.

2.2.3 Travel / Traverse limits (optional)

Limit switches at the extremes of long and cross travel are optional based on the user's risk assessment. There are three types:-

1. On reaching the limit the crane or hoist travel motion will stop altogether.
2. On reaching the limit the crane or hoist will change from fast to slow speed and proceed at slow speed until the end stop is reached.
3. If a two stage limit is fitted, on reaching the first stage the motion will reduce to slow speed. On reaching the second stage the motion will stop.

Operation of the limit does not have any effect on other crane motions. Movement in the opposite direction, at the speed selected by the operator (slow or fast) is still possible after the limit has been triggered.

3 INSTALLATION AND COMMISSIONING INSTRUCTIONS

Installation and commissioning of the hoist must be carried out by a competent person(s). We recommend that installation and commissioning are carried out by Street Crane Company or their approved agents.

Immediately report any damage which may have occurred during transit. Consult with the manufacturer / supplier and repair the equipment before installation. Do not install damaged equipment. Use only original Street Crane spare parts for repairs. Do not carry out any alterations or modifications to the hoist either prior to or during installation.

If the hoist is located outdoors we recommend that a small cover (roof) is fitted to the runway beam to protect the hoist at its parking position.

3.1 TRAVERSE END STOPS

Single girder 4 & 8 fall low head hoists require end stops to be mounted on either end of the runway and include rubber buffers as shown. Weld on end stops can be provided by Street Crane. (Part No. 270-31).




Figure 2 – Single Girder 4 & 8 Fall Traverse End Stops

Double girder crab units are supplied fitted with rubber buffers. Suitable end stops should be positioned at either end of the crab rails. Weld on end stops can be provided by Street Crane. (Part No. 27-20061).





Figure 3 – Double Girder Traverse End Stops

3.2 RUNNING & MOUNTING SURFACE TOLERANCES AND FINISHES


3.2.1 Tolerances on the Inclination of the Running Surface

The angle of inclination of the running surface for the hoist should not exceed the values shown.




3.2.2 Tolerances on Crab Rail Gauge & Rail Height

The gauge shall not deviate from the nominal by more than 3mm. The difference in rail height shall not exceed 3mm for gauges up to and including 2000mm or 5mm for gauges greater than 2000mm. Rail height should be a minimum of 30mm.




3.2.3 Tolerances on Single Girder Runway Flange Width

The variation in the width of a single girder runway flange should be no greater than 3mm over its entire length.



3.2.4 Tolerances on Mounting Surface for Foot Mounted Hoists

The vertical misalignment between all mounting holes shall not exceed 1mm.



3.2.5 Tolerance on misalignment of rail joints, wheel running surfaces and guidance surfaces

The running surface for the hoist wheels and guide rollers (single girder hoist only) should be free from obstructions and left unpainted. These surfaces should also be free from damage, pitting, weld beads or other surface defects.

Surfaces should be aligned to provide a smooth transition path for the wheels between track sections.

- Gaps in any joints ('J') should be no greater than 2mm.
- There should be no step in the running or guidance surface ('h') greater than 0.5mm.
- Lateral misalignment in double girder rail joints ('L1') should not exceed 1mm.

NOTE: Runway joint splice plates on the bottom flange are not possible with ZX6 & ZX8 single girder low headroom hoists because of the hoist reaction roller.




Figure 4 – Single Girder Runway Tolerances




Figure 5 – Double Girder Runway Tolerances

3.3 HOIST WEIGHTS AND LIFTING POINTS

3.3.1 Low Headroom




Figure 6 – Low Headroom 4&8 Fall Lifting Points

3.3.1.1 Table of weights- Low Head Hoists

	Ø8 Rope						Ø13 Rope		
	4 Fall			8 Fall			4 Fall		
	NB	LB	ELB	NB	LB	ELB	NB	LB	ELB
ZX6	353	379	423	---	---	---	---	---	---
ZX8	844	895	1040	918	992	1140	886	936	1106

Weights shown for each model in kg do not include any optional extras



The lifting lugs fitted to the hoist unit are designed for lifting the mass of the hoist unit ONLY (including any transportation feet).

3.3.2 Double Girder Crab




Figure 7 – Double Girder Crab Lifting Points – 4 & 8 fall units

Double girder crab units having 4 or 8 falls should be lifted using the lifting points fitted to the hoist end frame see Figure 7.

After lifting is completed, refit the hoist cover top section and tighten setscrews to 15Nm.

3.3.2.1 Table of weights- Double Girder Crab

	Ø8 Rope						Ø13 Rope		
	4 Fall			8 Fall			4 Fall		
	NB	LB	ELB	NB	LB	ELB	NB	LB	ELB
ZX6	405	441	499	---	---	---	---	---	---
ZX8	PARALLEL ARRANGEMENT (...CRB...)								
1400 GAUGE	973	1045	1237	1064	1163	1373	1015	1121	1303
ZX8	PERPENDICULAR ARRANGEMENT (...CRE...)								
1400 GAUGE	965	---	---	1056	---	---	1008	---	---
2000 GAUGE	1003	1056	1209	1094	1174	1345	1045	1133	1276
2600 GAUGE	1040	1094	1246	1131	1211	1382	1082	1170	1312

Weights shown for each model in kg do not include any optional extras

3.3.3 Foot Mounted




Figure 8 – Foot Mounted Lifting Points

3.3.3.1 Table of weights- Foot Mounted

	Ø8 Rope						Ø13 Rope		
	4 Fall			8 Fall			4 Fall		
	NB	LB	ELB	NB	LB	ELB	NB	LB	ELB
ZX6	288	314	361	---	---	---	---	---	
ZX8	656	714	875	731	812	985	699	790	941

Weights shown for each model in kg do not include any optional extras



The lifting lugs fitted to the hoist unit are designed for lifting the mass of the hoist unit ONLY.

3.4 INSTALLATION OF LOW HEAD 4&8 FALL SINGLE GIRDER HOIST

- Measure the runway flange width.
- Whilst the hoist is on the floor and stood on the packing feet, slacken the 4-M12 locking grub screws that secure the panel side trolley frame to the legs (do not release any fixings on the hoist barrel side).
- Open the trolley frame until the gap between the ends of the wheel axles is at least 20mm wider than the width of the runway flange (see Figure 9). Do not remove the circlips on the ends of the legs.




Figure 9 – Installing the Low Headroom Trolley

- Disconnect the reaction roller assembly from the wheel support casting by removing the circlip and washer on the end of the pin.
- Withdraw the reaction roller assembly from the wheel support casting (see Figure 10).




Figure 10 – Withdrawing the Reaction Roller

- Raise the hoist to runway level, use the lifting lugs provided see Figure 6.
- Push the barrel side trolley onto the runway flange until the hoist side guide rollers touch the toe of the runway. Secure the barrel side frame against moving. Ensure that the reaction roller is held in the correct orientation with the spring pointing outwards, horizontally.
- Push the panel side trolley onto the runway (tap with rubber / nylon mallet as necessary) until the gap between guide roller and toe of flange is between 3 and 5mm (see Figure 11). Check that the gap is the same at both ends.




Figure 11 – Low Headroom Runway Clearance

- Lower the hoist unit so that the wheels are touching the beam flange ensuring that the 3-5mm clearance gap is maintained.



Do not remove the hoist lifting tackle until the hoist is fully secured on the runway.

- Remove each of the four M12 locking grub screws from the panel side trolley castings.
- Using the single cone point setscrew, screw into each hole in turn and tighten until a 'centre-pop' indent is made in the hoist legs.
- Using a 10mm diameter drill, drill a full cone of 10mm diameter into both legs at four positions (see Figure 12).
- Remove any swarf from the holes using a magnet.
- Replace cone point setscrew in its storage position, securing with the locknut.




Figure 12 – Setting the Low Headroom Legs

- Replace each of the four M12 locking grub screws and tighten to 40Nm. Secure each grub screw with locknut tightened to 40Nm.
- Replace the reaction roller assembly on the wheel support casting. Set the reaction roller as per section 3.4.1.
- Remove the four blue transportation feet from the hoist legs (Figure 13).




Figure 13 – Low Headroom Hoist Transportation Feet

3.4.1 Setting the Reaction Roller

Before setting the reaction roller ensure that the side guide rollers on the panel side trolley frame, i.e. the guide rollers on the same side as the reaction roller assembly, are in contact with the toe of the runway beam flange. For the setting operation the clearance between the side guide rollers and the runway flange must be on the barrel side (note this is on the **opposite** side to that shown in Figure 11).

The reaction roller fitted to low headroom hoist units runs on the underside of the runway beam directly below the traverse drive wheel.

If the roller assembly has not been replaced, rotate the assembly until the location pin aligns with the hole in the body casting (red adjusting spring facing horizontally outwards). Push the pin into the hole and attach the washer and circlip, the washer sits directly behind the circlip.




Figure 14 – Reaction Roller

- Ensure that the travel drive wheel is in contact with the runway flange. Turn the reaction roller adjusting nut until the roller just touches the underside of the runway.
- Turn the adjusting nut an additional five (5) full turns and then lock in position using the locknut. Hold the adjusting nut and tighten the locknut to 81Nm.



Five full turns of the adjusting nut is important to achieve correct compression on the reaction roller spring.

3.5 INSTALLATION OF FOOT MOUNTED HOIST



The ZX6 & ZX8 foot mounted hoist units are designed for mounting horizontally with the feet at the bottom of the unit. The hoists are not suitable for mounting suspended upside down or in any other orientation other than as shown.




Figure 15 – Installation of Foot Mounted Hoist

Foot mounted hoist units are supplied with four mounting feet.

On 4&8 fall units each foot has a single 22mm diameter hole. They should be secured to a suitable supporting structure using four M20 fixings with minimum grade of 8.8.



The supporting structure should be suitably designed to support both the mass of the hoist unit together with its rated capacity plus dynamic effects. Tolerances on the mounting surface should be in accordance with 3.2.4.

3.6 SETTING THE UPPER AND LOWER LIMIT SWITCHES – ROPE GUIDED

Each hoist is fitted with an upper and lower level hoist limit switch. The limit switches are activated by contact with the travelling rope guide retainer. These are safety switches and should not be used as the normal method for stopping the hoist. When activated, each switch will only allow travel in the opposite direction. Remove the hoist cover to gain access to the limit switches.

NOTE: The limit spacer tubes are designed to prevent the switches from being placed outside the normal range of operation. Do not remove or modify these tubes.



Incorrect setting of the limit switches may cause serious accidents and damage to the hoist unit.




Figure 16 – Hoist Limit Switches – Standard Environment Rv-1 (see hoist nameplate for revision)

3.6.1 Setting the lower limit

- Release the grub screws that secure the holding arm to the limit bars and slide the switch towards the end of the hoist.
- Lower the hook to the desired lowest operating position. Do not let the hook touch the floor such that it would cause the ropes to go slack.
- NOTE: The clearance between the rope guide and the rope clamps should not be less than 10mm when the hook is at its lowest position.
- Slide the limit switch up to the rope guide retainer until the switch is activated. Tighten the grub screws holding the arm to the limit bar.
- Test that the limit operates satisfactorily firstly at slow speed and then at fast speed. Re-adjust if necessary. When the adjustments are complete, replace the hoist cover.

3.6.2 Setting the upper limit

- Release the grub screws that secure the holding arm to the limit bars and slide the switch towards the centre of the hoist.
- Raise the hook to the correct operating position.



The upper hook level for low headroom hoists vary with the runway flange width. The hoist will be seriously damaged if the hook is set higher than the values indicated in section 3.10.

- Slide the limit switch up to the rope guide retainer until the switch is activated. Tighten the grub screws holding the arm to the limit bar.
- Test that the limit operates satisfactorily firstly at slow speed and then at fast speed, stopping at the correct distance from the underside of the beam. Re-adjust if necessary. When the adjustments are complete, replace the hoist cover.

3.7 SETTING THE UPPER AND LOWER LIMIT SWITCHES – OPEN BARREL

Open barrel hoists will not be fitted with standard upper and lower limit switches, they will however be fitted with a Rotary limit switch that will be mounted on the end of the drum in the same position as the Ultimate limit option. (Open barrel TVL hoists do not have a Rotary Ultimate Limit option).

3.7.1 Setting the Hoist Upper limit

- Raise the hook to the desired operating position at slow speed with no load attached allowing an additional 50mm for a fast speed approach.



The upper hook level for low headroom hoists vary with the runway flange width. The hoist will be seriously damaged if the hook is set higher than the values indicated in section 3.10.

- Remove the lid from the Rotary limit and loosen the central clamp screw (see Figure).
- Turn cam no.2 adjustment screw until cam no. 2 is positioned just before it operates the micro switch.
- Re-tighten the central clamp screw.
- Test the operating position in slow speed at first repeating the test in fast speed adjusting the trip position where necessary. Replace limit switch lid.




Figure 17 – Setting the Upper/Lower Limit Switch – Rotary Type

3.7.2 Setting the Hoist Lower limit

- Remove the lid from the Rotary limit and loosen the central clamp screw (see Figure 17).
- Turn cam no.1 adjustment screw until cam no. 1 is positioned just before it operates the micro switch.
- Re-tighten the central clamp screw.
- Test the operating position in slow speed at first repeating the test in fast speed adjusting the trip position where necessary. Replace limit switch lid.

3.8 ULTIMATE UPPER LIMIT SWITCH - ROTARY (OPTIONAL)

When specified, an ultimate upper limit may be fitted to the hoist unit to prevent the bottom block from damaging the hoist should the normal upper limit switch fail. It should be set to activate at the upper level given in section 3.10. The normal limit should then be set to activate approximately 75-100mm below the ultimate limit. A red warning light on the base of the control panel will illuminate to indicate when the second ultimate limit has been activated.




Figure 18 – Ultimate Upper Limit Switch – Rotary Type

3.8.1 Setting the ultimate upper limit



Extreme care must be exercised when testing the ultimate limit switch as it is necessary to bypass the normal upper limit.

- Reposition the normal upper limit such that the ultimate limit is the first to operate.
- Raise the hook to the desired operating position at slow speed with no load attached allowing an additional 50mm for a fast speed approach.



The upper hook level for low headroom hoists vary with the runway flange width. The hoist will be seriously damaged if the hook is set higher than the values indicated in section 3.10.

- Remove the lid from the second upper limit and loosen the central clamp screw (see Figure).
- Turn cam no.2 adjustment screw until cam no. 2 is positioned just before it operates the micro switch.
- Re-tighten the central clamp screw.
- Test the operating position in slow speed at first repeating the test in fast speed adjusting the trip position where necessary. Replace limit switch lid.
- Check that the red warning light in the base of the control panel illuminates.
- Set the normal upper limit so that it operates approximately 75-100mm below the ultimate upper limit (see 3.6.2).




Figure 19 – Setting the Ultimate Upper Limit Switch – Rotary Type

3.9 ULTIMATE UPPER LIMIT SWITCH – HOOK BLOCK OPERATED (OPTIONAL)

When specified, an ultimate upper limit may be fitted to the hoist unit to prevent the bottom block from damaging the hoist should the normal upper limit switch fail. It should be set to activate at the upper level given in section 3.10. The normal limit should then be set to activate approximately 75-100mm below the ultimate limit. A red warning light on the base of the control panel will illuminate to indicate when the second ultimate limit has been activated.




Figure 19 – Ultimate Upper Limit Switch – Hook Block Type

3.9.1 Setting the ultimate upper limit



Extreme care must be exercised when testing the ultimate limit switch as it necessary to bypass the normal upper limit.

- Reposition the normal upper limit such that the ultimate limit is the first to operate.
- Raise the hook to the desired operating position at slow speed with no load attached allowing an additional 50mm for a fast speed approach.



The upper hook level for low headroom hoists vary with the runway flange width. The hoist will be seriously damaged if the hook is set higher than the values indicated in section 3.10.



- Remove the bottom block trigger fixings such that the bottom block trigger can be split in two.
- Position the bottom block trigger around the hoist rope.




The bottom block trigger must be positioned around the static rope on the reeving arrangement i.e. the rope which passes over the Diverter sheave see Figure 19.

- Replace block trigger fixings.
- Adjust the length of the strainer wire and position of the bottom block trigger such that the limit switch operates
- Test the operating position in slow speed at first repeating the test in fast speed raising / lowering the bottom block trigger where necessary.
- Trim or secure any excess strainer wire.
- Check that the red warning light in the base of the control panel illuminates.
- Set the normal upper limit so that it operates approximately 75-100mm below the ultimate upper limit (see 3.6.2).


3.10 LOW HEADROOM HIGHEST HOOK POSITION- 4 FALL & 8 FALL




ZX6 - 4 FALL




ZX8 - 4 FALL – Ø8



ZX8 - 8 FALL




ZX8 – 4 FALL – Ø13



To prevent accidental damage to the hoist unit, all low headroom hoists are despatched from Street Crane with upper and lower limit switches set to suit a 500mm runway flange. As part of the commissioning procedure, the upper and lower limit switches should be adjusted to achieve the optimum C-DIMENSION for the runway flange width (see 3.6).


3.11 FOOT MOUNT HIGHEST HOOK POSITION- ZX6 & ZX8



ZX6 FOOT MOUNT					
HOIST	FALLS	ROPE Ø	BARREL	'C' DIMENSION (mm)	DATASHEET
ZX6	4	8Ø	NB, LB, ELB	479	DZX-1244

ZX8 FOOT MOUNT					
HOIST	FALLS	ROPE Ø	BARREL	'C' DIMENSION (mm)	DATASHEET
ZX8	4	Ø 8	NB, LB, ELB	461	DZX-1377
ZX8	4	Ø13	NB, LB, ELB	714	DZX-1385
ZX8	8	Ø 8	NB, LB, ELB	991	DZX-1393


3.12 DOUBLE GIRDER PARALLEL CRAB HIGHEST HOOK POSITION- ZX6 & ZX8



ZX6 DOUBLE GIRDER PARALLEL CRAB- 900mm GAUGE					
HOIST	FALLS	ROPE Ø	BARREL	'C' DIMENSION (mm)	DATASHEET
ZX6	4	Ø8	NB, LB, ELB	84.5	DZX-1224

ZX8 DOUBLE GIRDER PARALLEL CRAB- 1400mm GAUGE					
HOIST	FALLS	ROPE Ø	BARREL	'C' DIMENSION (mm)	DATASHEET
ZX8	4	Ø8	NB, LB, ELB	169	DZX-1329
ZX8	4	Ø13	NB, LB, ELB	217.5	DZX-1337
ZX8	8	Ø8	NB, LB, ELB	535	DZX-1361

3.13 DOUBLE GIRDER PERPENDICULAR CRAB HIGHEST HOOK POSITION- ZX8



ZX8 DOUBLE GIRDER PERPENDICULAR CRAB- 1400-2600mm GAUGE					
HOIST	FALLS	ROPE Ø	BARREL	'C' DIMENSION (mm)	DATASHEET
ZX8	4	Ø8	NB, LB, ELB	169	DZX-1345
ZX8	4	Ø13	NB, LB, ELB	217.5	DZX-1353
ZX8	8	Ø8	NB, LB, ELB	535	DZX-1369

3.14 CHECKING / ADJUSTING THE RATED CAPACITY LIMITER

The rated capacity limiter is used to prevent the hoist from lifting a load in excess of the rated capacity (safe working load). If the hoist is overloaded, the limit switch will trip and the UP direction will become inactive. The hoist will be allowed to lower only. Once the load has been removed then the limit switch will automatically reset and all motions will become active again.

The rated capacity limiter is pre-set at the factory prior despatch and is set to rated capacity +7.5%. Checking of the rated capacity limiter will require calibrated test weights equal to the rated capacity of the hoist and rated capacity plus 10%, (SWL and SWL+10%). Lift the load just clear of the floor with the test load attached. The limit does not require any adjustment if the hoist picks up its rated capacity (SWL) but does not lift the rated capacity + 10% (SWL+10%). If the limit trips either below or above these limits, adjust the limit by turning the grub screw.

3.14.1 Adjusting the Rated Capacity Limiter for Proof Loading

For proof load testing of a hoist or crane at a load greater than the rated capacity, proceed as follows:-

- Release the grub screw by approximately half a turn.
- Carry out the proof load tests on the hoist / crane as required.
- Attach a calibrated test load to the hook of (Rated Capacity + 10%). Lift the load just clear of the floor and tighten the grub screw until the limit switch just operates.
- Lower the load to the floor and repeat the lift several times at slow hoisting speed making sure that the limiter trips each time. Repeat the test at rated capacity, this time ensuring that the limiter does not activate.




Figure 20 – Rated Capacity Limiter

3.15 TRAVERSE LIMITS (OPTIONAL)

The traverse limit arrangement employs either a one or two stage cruciform switch depending on the type of stopping arrangement. Be sure of the type that is fitted to your hoist.

- A single stage limit switch (type PF33710100) is employed to stop the motion completely when the limit is reached or to allow the hoist to proceed at slow speed only until the end stop is reached. The single stage limit employs one actuating arm at each end of travel.
- The two stage switch (type PF26755100) is employed to firstly slow the speed from fast to slow and then to stop the motion completely on reaching the second stage. The two stage limit employs two actuating arms at each end of travel.

NOTE: On each of the above, when the limit is tripped, normal operation is available in the opposite direction. Reversing away from the stop is at the speed selected by the operator (slow or fast).

3.15.1 Setting traverse limits

To ensure reliable operation of the switch, the actuating arm should be positioned to strike the limit bar as shown in Figure 21. The arm should be positioned so that the switch rotates through 90° each time it passes an arm.

The short bar on the switch occupies the mid (0°) position when the switch is between the two actuating arms. The bar on the switch will then rotate through 90° clockwise or anti-clockwise each time it passes an actuating arm.



Failure to set the switch and actuating arms, as shown, will result in permanent damage to the switch.




Figure 21 – Setting the Traverse Limit - Single Girder Arrangement




Figure 22 – Traverse Limit Double Girder arrangement
(See Figure 21 for setting dimensions)

When setting the point of operation for the limit switch, account should be taken of the hoist speed and the stopping distance. The point of operation should be set to allow a fully loaded crane / hoist to stop from fast speed before reaching the required position.

3.16 CONNECTING THE POWER SUPPLY



Connection of the power supply must be carried out by a competent person. Ensure that the supply to the hoist matches the information in the hoist technical data and on the hoist nameplate. Also ensure that the supply has been correctly installed and protected, i.e. voltage, phase, frequency, fuse size, cable/conductor size. Check that the voltage at the point of supply is within the tolerance of $\pm 5\%$ and the nominal frequency is within the tolerance of $\pm 1\%$ of the rated values.

3.16.1 Supply cables / fuses

The size of the supply cables to the hoist must be selected in accordance with the table in section 7.6. Terminals must be of a size appropriate to the cable size and securely fixed. Selection of a suitable size of mains fuse is given in section 7.5. Fuses of class gL/gG should be used (or type 'J' for CSA installations).

3.16.2 Main isolator – supply switch (by others)

The main isolator (supply switch) must disconnect all phases of the supply to the hoist, must be clearly marked and located in an easily accessible position. The switch should be capable of being locked in the OFF position whilst any maintenance work is being carried out. The main isolator, if reasonably accessible, may also be used for emergency stop or emergency off purposes. NOTE a separate emergency stop is located on the hoist controller see 1.

3.16.3 Connecting to the mains supply

Connect the cables in accordance with the circuit diagrams via the plug and socket located on the side of the hoist control panel.





Figure 23 – Hoist Electrical Connections


- Check the setting of both the Traverse Fast to Slow and the Hoist Slow to Fast speed delay timers. These should correspond with the settings in Figure 24.
- Check the settings on the Phase Failure Relay correspond with Figure 25.
- Check that the connections to the control transformer match the supply voltage (see Figure 26).
- Before switching the power on carry out Earth continuity and insulation resistance tests on the completed installation.



Traverse Fast-Slow

Hoist Slow-Fast

Figure 24 – Delay Timers



380-575V

Figure 25 – Phase Failure Relay




Figure 26 – Control Transformer Connections

3.16.4 Electromagnetic compatibility

The hoist itself complies with the requirements of BS EN 61000-6-2/4 with regard to EMC. The user should take care to ensure that the remainder of the installation meets these requirements.

3.16.5 Connecting the Pendant controller – Low Headroom

Where a control pendant is to be attached directly to a low headroom hoist, it must be supported by the two strainer wires on either side of the pendant cable. The electrical cable or terminals must not support any load. Connect the two pendant strainer wires to the M6 screws on the suspension bracket as shown. Tighten the M6 fixings to 9Nm. Connect the plug on the end of the pendant cable to the socket on the side on the hoist control panel.




Figure 27 – Strainer Wire Connections

3.17 COMMISSIONING PROCEDURE



Checks to be carried out before switching on the power supply.

- Check that the hoist installation is complete and all fixing screws are secure.
- Check that the correct end stops are in place.
- Check that the electrical installation is complete and installed as section 3.16. Ensure that the Earth continuity and insulation resistance tests were satisfactorily carried out.



Once power supply is connected:-

- Check that the emergency stop functions correctly.
- Check each motion by first moving at SLOW speed and moving the minimum possible distance also ensuring that the direction of movements correspond to the legends on the controller.
- Double girder – Travel the crab unit the full length of the crane to ensure that there is sufficient clearance between the wheel flanges and the rail.
- Single girder - Travel hoist full length of runway to ensure that adequate clearance exists between guide rollers and runway. Check that the clearance does not become excessive. Check that the reaction roller operates satisfactorily.
- Check that the runway end stops function correctly.
- Set and check the upper and lower limits (section 3.6).
- Set the ultimate upper limit (rotary type see section 3.7, block operated type see 3.9) and the traverse limit (section 3.15) if fitted.
- Check and adjust, if necessary, the rated capacity limiter (see section 3.14). If the hoist is to be subject to a proof load test as part of a crane or runway installation, see the instructions for by-pass of the RCL in section 3.14.1.
- Run the hoist several times under light load (approx 10% of SWL) and at slow speed to allow the wire rope to bed down and improve its service life. After the running in period, check that the wedge and rope has seated correctly in the socket. Remove any twist imparted in the rope during installation, see section 5.8.2.6.

The hoist is now ready for proof load and performance testing as required.

Confirm that commissioning has been duly carried out and complete the test logbook in section 7.7.

3.18 DISMANTLING / REMOVAL OF THE HOIST

The following hoist dismantling and removal procedure assumes that the hoist is still in its original condition and working in the same environment.

If the hoist has been modified such that it no longer resembles the original installation, the competent person may decide on an alternative method of removal and dismantling.

- Raise the hook to its upper level. Alternatively the hook and rope may be removed if required. See 5.8.2.1
- Electrically isolate the crane, disconnect all electrical cables.
- Remove any attachments such as limit brackets, cable towing arms, pendant etc.
- Support the weight of the hoist at its appropriate lifting points. See 3.3
- Double Girder Crabs can be lowered to the ground.
- For Foot Mounted Hoists remove the foot bolts and check there is no adhesion of the foot plates before lowering to the ground.
- For 4&8 Fall Low Head TVL Hoists:-
 - Release the reaction roller. See 3.4.1
 - Remove the locking grub screws. See 3.4
 - Open the low head trolley frame until the wheels clear the runway flange.
 - Lower to the floor.
- If the hoist is not to be re-used, dispose of in an environmentally friendly manner.

4 OPERATING INSTRUCTIONS

4.1 INTENDED USE

The crane / hoist is designed for lifting, moving and lowering loads, up to the rated capacity of the equipment, by means of a hook or other similar load handling device. The equipment should not be modified or any additions made without the approval of Street Crane Co Ltd.

- The equipment is not intended for transporting any persons either suspended in a basket from the hoist or for persons travelling on the crane bridge.
- The crane / hoist is not intended for pulling loads at an angle and not for towing or dragging loads along the floor. The hoist is designed for lifting a load in a vertical path only.
- Ensure that the hoist is always operated within its rated capacity (SWL). The weight of any lifting gear should be taken into account when assessing the load on the hoist. It may also be necessary to allow for any adhesion between the load and its supports.



Overloading can lead to a possible failure of some of the load carrying parts. Overloading the crane / hoist may start a defect, which could lead to future failure even at less than the rated capacity.

- Do not use the crane / hoist for pulling loads loose, i.e. pulling components from moulds and always make necessary allowances for any adhesion between the load and its supports.
- The end of travel limits, (hoist or travel), are not intended to be a regular method of stopping the motion. They are safety devices and they should be approached with caution.
- The hoist is not intended to operate with a slack rope.

4.2 DUTIES OF THE OPERATOR / SAFE HOISTING PRACTICES

At the start of each working day or shift, carry out the daily pre-use checks see section 5.4. Do not work with any crane or hoist if any defects are found which may compromise safety.

The following information serves as a guide for safe hoisting practices and an operator adhering to these will quickly find that he / she is able to work both smoothly and quickly, without prejudicing safety and equipment.

1. Know where the safety, fire and first aid equipment is located and how to use it.
2. Ensure that no one is working on the crane track, crane platform (if fitted) or where they could be struck by the crane / hoist.
3. Before using the crane / hoist make a full visual inspection to ascertain that the equipment is in good working order, paying particular attention to the rope and hook. See 5.4 Daily pre-use inspections.
4. Do not use the crane for anything other than its intended purpose.
5. Ensure the crane is properly maintained and that all the necessary examination and maintenance records are up to date.
6. All relevant accident prevention, safe lifting and slinging procedures should be obeyed.
7. Constantly monitor all crane and hoist movements and be ready to activate the emergency stop should any abnormal circumstances arise. Be especially aware of instances where the crane / hoist may fail to stop when the push button/joystick is released or if the crane / hoist moves unexpectedly.
8. Always operate the crane with care and consideration. Care should be taken to avoid the swinging of loads.
9. Ensure that the SWL data plates are clearly visible to the operator at all times.
10. Centre the hoist over the load before lifting. Do not side pull as this can damage the hoist and endanger the operator.
11. Do not lower the hook / bottom block so far as to allow the hoist ropes to become slack.



If this does happen, the operator should satisfy himself that the rope is correctly reeved on the system of sheaves & hoist barrel before continuing to operate the crane.

12. Do not lift a load unless you can see it is securely slung with "suitable" lifting tackle.



Lifting tackle should only be deemed “suitable” if in accordance with LOLER 98. (Other national regulations may apply).

13. Always gently ‘inch’ the hoist into the load.



Running into the load at full hoist speed imposes excessive overloads on the hoist and could result in failure of parts and/or supporting structure.

14. Do not ‘inch’ the hoist unnecessarily. Excessive stopping and starting causes high temperatures in the motor and brake and may result in overheating or burnout of the component if continued to excess.
15. Do not try and move in the opposite direction until the crane/ hoist has come to a complete stop.



Do not stand below a suspended load or allow any other personnel to do so.

16. Prior to operating the travel or traverse motion, the operator should make personnel aware of approaching loads using audible warnings where necessary.



Do not move the loads over the heads of other personnel.

17. Do not run the hoist or crane into the travel stops at full speed. Ensure that the rubber buffer is in place and not damaged.
18. Ensure that adequate clearance is maintained between the load or lifting attachment and the hoist or crane structure. See Figure 28.




Figure 28 – Clearances to consider when lifting

19. Ensure that you can see the hook or load clearly at all times or are receiving signals from someone who can. Ensure that both parties know the full meaning of the hand signals for operating the crane / hoist. See Figure 29 for recommended hand signals.
20. Do not continue to travel or traverse once the crane or hoist has come to a stop against the endstops. This will cause localised damage to the rail or runway beam.
21. Never leave a load suspended in the air unsupervised.
22. Do not park the crane over fumes, steam or dangerous processes. For outdoor cranes/hoists, park in a sheltered area where possible.
23. Do not leave outdoor cranes/hoists unattended for long periods without applying the storm anchors.




Figure 29 - Recommended Hand Signals

4.3 REMOTE CONTROLLED CRANES / HOISTS

To prevent unauthorised use, the operator should either retain the transmitter in their possession or remove the key from its key lock switch and, for short periods, retain the key in their possession. For longer periods, or when the crane is not in use, the transmitter should be deposited in a designated safe storage place.

When the transmitter is fitted with a belt or harness, the operator should be wearing the harness before switching the transmitter on. This will prevent accidental operation of the crane / hoist whilst fitting. The transmitter should also be switched off before removing the harness.

Ensure that the identification tag on the radio security key matches the identification number on the radio transmitter and the identification number on the crane.

4.4 CONTROL STATION OPERATING INSTRUCTIONS

The control station may be fitted with either push buttons or joysticks. Pendants will be push button operated, remote control stations may be either push button or joystick. In all cases the push button or joystick is spring applied, which, when released, will return to the neutral position, the motion will stop and the relevant brake will automatically apply.

4.4.1 Legend Nomenclature

A legend corresponding to the direction of motion is located next to each of the control devices, (push button or joystick). The legend plates may be in either English (words) or International symbols.




Figure 30 – Control Pendant Legends

To improve safety in operation, there are directional identification legends on the crane that correspond to the legends on the controller.

4.4.2 Switch ON

- Establish power supply to the conductors via the main isolator (this may be located on a wall or supporting column).
- Release the emergency stop button on the controller.
- Momentarily depress the ON pushbutton. This will energise the crane / hoist main contactor and allow subsequent motions to take place.

4.4.3 Push button operation

1. The operating controls (push button) must **never** be mechanically blocked in an **ON** position.
2. All opposing functions are interlocked e.g. hoist function cannot be operated at the same time as the lower function.
3. All control pendants are fitted with dual pressure, two stage, pushbuttons to control hoist and crane motions. For push button operation depress the required pushbutton and the crane/hoist will move in the corresponding direction.
 - Select the direction of motion required.

Single Speed

- Press the button to either the first or second pressure.

Dual Speed motion (Switchgear Control)

- **Slow Speed:** Press the button in to the first stage.
- **Fast Speed:** Press the button fully in (i.e. to the second stage).
- **Change Speed - Slow to Fast:** To change from slow speed to fast speed push the pushbutton fully in to the second stage.
- **Change Speed - Fast to Slow (Long travel/traverse motion):** To change from fast speed to slow speed, reduce pressure on push button and allow it to come out to the first stage. The motion will first stop and then continue at slow speed.
- **Change Speed - Fast to Slow (Hoist motion):** To change from fast speed to slow speed, release pressure on push button completely and then engage slow speed. The motion will first stop and then continue at slow speed.


Dual Speed motion (Inverter Control – Standard Dual Speed)

- **Slow Speed:** Press the button in to the first stage.
- **Fast Speed:** Press the button fully in (i.e. to the second stage).
- **Change Speed - Slow to Fast:** To change from slow speed to fast speed push the pushbutton fully in to the second stage. The motion will accelerate until it reaches maximum speed.
- **Change Speed - Fast to Slow:** To change from fast speed to slow speed, reduce pressure on push button and allow it to come out to the first stage. The motion will decelerate to slow speed.

Variable Speed (Inverter Control – 2 Stage Ramp and Hold)

- **Slow Speed:** Whilst the motion is stopped, press the button in to the first stage.
- **Fast Speed:** Press the button fully in (i.e. to the second stage).
- **Maintain Speed:** When the motion is active, press the button in to the first stage.
- **Change Speed - Slow to Fast:** To change from slow speed to fast speed push the pushbutton fully in to the second stage. The motion will accelerate toward maximum speed.
- **Hold Speed:** To maintain desired speed, reduce pressure on the pushbutton and allow it to come out to the first stage.
- **Reduce Speed – From Fast speed:** To reduce speed, release pressure on the pushbutton completely and re-engage to first stage when the motion decelerates to the desired speed. The motion will maintain speed.
- **Change Speed - Fast to Slow:** To change from fast speed to slow speed, release pressure on the pushbutton completely and wait for motion to stop, then engage slow speed.

4. To maintain the selected motion the pushbutton must be held depressed. Releasing the pushbutton will stop the motion.
5. Press the **EMERGENCY STOP** pushbutton if no further actions are to be taken.



4.4.4 Joystick operation

1. The operating controls (joystick) must **never** be mechanically blocked in an **ON** position.
2. All opposing functions are mechanically interlocked e.g. hoist function cannot be operated at the same time as the lower function.
3. Control joysticks normally have two stages to control the hoist and crane motions, the first stage being slow speed and the second stage fast speed. However, three or four stage units may be supplied as an option. Move the required joystick forward and the crane/hoist will move in the corresponding direction. The speed of the motion will be proportional to the stage selected.
 - Select the direction of motion required.

Single Speed

- Move the lever or joystick fully.

Dual Speed motion (Switchgear Control)

- **Slow Speed:** Move the joystick to the first stage.
- **Fast Speed:** Move the joystick directly to the second stage.
- **Change Speed - Slow to Fast:** To change from slow speed to fast speed move the joystick fully to the second stage.
- **Change Speed - Fast to Slow (Long travel/traverse motion):** To change from fast speed to slow speed, reduce pressure on the joystick and allow it to come out to the first stage. The motion will first stop and then continue at slow speed.
- **Change Speed - Fast to Slow (Hoist motion):** To change from fast speed to slow speed, release pressure on the joystick completely and then engage slow speed. The motion will first stop and then continue at slow speed.

Dual Speed motion (Inverter Control – Standard Dual Speed)

- **Slow Speed:** Move the joystick to the first stage.
- **Fast Speed:** Move the joystick directly to the second stage.
- **Change Speed - Slow to Fast:** To change from slow speed to fast speed move the joystick fully to the second stage. The motion will accelerate until it reaches maximum speed.
- **Change Speed - Fast to Slow:** To change from fast speed to slow speed, reduce pressure on the joystick and allow it to come out to the first stage. The motion will decelerate to slow speed.

Variable Speed (Inverter Control – 2 Stage Ramp and Hold)

- **Slow Speed:** Whilst the motion is stopped, move the joystick to the first stage.
- **Fast Speed:** Move the joystick directly to the second stage.
- **Maintain Speed:** When the motion is active, push the joystick to the first stage.
- **Change Speed - Slow to Fast:** To change from slow speed to fast speed move the joystick fully to the second stage. The motion will accelerate toward maximum speed.
- **Hold Speed:** To maintain desired speed, reduce pressure on the joystick and allow it to come out to the first stage.
- **Reduce Speed – From Fast speed:** To reduce speed, release pressure on the joystick completely and re-engage to first stage when the motion decelerates to the desired speed. The motion will maintain speed.
- **Change Speed - Fast to Slow:** To change from fast speed to slow speed, release pressure on the joystick completely and wait for motion to stop, then engage slow speed.

4. To maintain the selected motion the joystick must be held in the selected position. Releasing the joystick will stop the motion.
5. Press the **EMERGENCY STOP** pushbutton if no further actions are to be taken.

4.4.5 Emergency Stop



Before starting work it is imperative to check the correct operation of the emergency stop button. It is important that the operator is constantly aware and monitoring all crane and hoist movements and ready to activate the emergency stop should any abnormal circumstances arise or situations occur that may endanger the safety of personnel working in the vicinity. Be especially aware of instances where the crane / hoist may fail to stop when the push button / joystick is released or the crane / hoist starts or moves unexpectedly.

1. Depressing the EMERGENCY STOP push button will cause all motions to stop and all brakes to engage.
2. The emergency stop will lock all controls in the off position.
3. If the button is used in an emergency stop situation, ensure that any faults are reported and rectified before re-establishing the power supply.
4. Twist to release the EMERGENCY STOP button. No functions will be operative until the emergency stop is unlatched and the ON pushbutton operated.

4.5 LEAVING THE CRANE / HOIST UNATTENDED



It is essential that a crane / hoist operator is present when a load is suspended from a hoist. When the crane / hoist are left unattended, even for a short period, it is essential that:-

1. The crane / hoist is parked away from any local sources of heat, fumes, condensation or damp conditions.
2. Any slings or lifting tackle have been removed from the hook and the hook is raised to a safe position.
3. The **Remote control** transmitter (where fitted)
 - Should always be kept in the authorised storage place when not required for immediate use.
 - The Emergency Stop and/or transmitter key must always be turned OFF when not in use and the key removed.
 - For short periods, the operator should either retain the transmitter in their possession or remove the key from its key lock switch and retain the key in their possession.
4. The **Pendant control** :-
 - Should be left in a safe location.
 - Must always be turned OFF by pressing the emergency stop button.
5. The **Joystick control ('ride-on' or cab)** :-
 - The cab must be parked at the authorised access / egress point.
 - Must always be turned OFF by pressing the emergency stop and removing the key. For short periods, the operator should either retain the key in their possession or for longer periods, the key should be placed at the authorised storage point.
6. For long periods and for out-of-service conditions, switch the mains isolator to the OFF position.
7. For outdoor cranes / hoists, attach the storm anchors.

4.6 POWER FAILURE

The appointed person should establish a safe operating procedure in the event of a power failure. If the appointed person does not have such a procedure the following is recommended: -

1. Switch off the power supply to the crane / hoist at the main isolator until the electrical supply is restored.
2. If a load is suspended from the hoist, fence off a safe area immediately below / around the load and clear all personnel from that area.
3. A load left suspended in mid-air is considered to be a hazard it should be lowered to the floor using the hand brake release lever.
 - Fence off and clear all personnel from the area under the load.
 - Follow the appropriate Health and Safety regulations and procedures.
 - Obtain the necessary authorisation / permit for access to the hoist brake.
 - Carefully lower load to the floor using the hand release on the hoist brake.



The load must be lowered under strict control only a few inches at a time before re-applying the brake. Serious damage and subsequent failure, of the gearbox may result if the load is allowed to 'run away'.

- When load is firmly supported at ground level, re-apply the brake mechanism.

When the electrical supply is restored, re-establish the crane power supply and carry out the daily pre-use inspections in section 5.4.

5 INSPECTION AND MAINTENANCE INSTRUCTIONS

To ensure that your hoist and / or overhead travelling crane continues to be safe in operation and operates as efficiently as possible, a regular planned inspection and preventative maintenance programme of the equipment is essential. Preventative maintenance, including lubrication, should be undertaken at pre-set intervals, depending on the crane / hoist duty, with the objective of keeping the equipment in a serviceable condition.

5.1 REPORTING OF DEFECTS AND INCIDENTS

The competent person should have a recognised procedure for reporting defects and incidents. The procedure should include the immediate notification of the following:-

1. Any defects found during the daily checks.
2. Defects found at any other time.
3. Incidents or accidents, however slight.
4. Shock loads however they occur.
5. Dangerous occurrences or reportable incidents.

5.2 SPECIAL KNOWLEDGE

Some equipment, such as a frequency inverter, may be fitted to the crane / hoist. This equipment requires special knowledge and should only be maintained by persons who are trained and competent in the use of such equipment.

5.3 KEEPING OF RECORDS

Accurate recording of the crane / hoist performance can provide useful information in regulating maintenance procedures and control of replacement stock. Record the date and reading on the hours-in-service meter each time a component is replaced and the reason for replacement. See section 7.8.

5.4 DAILY PRE-USE INSPECTIONS (at the start of each day/shift)

Part of the crane operator's training should be to make them aware of potential malfunctions requiring adjustments or repairs and the need to bring these to the attention of the competent person for corrective action.

The crane / hoist and associated equipment should undergo daily visual and functional checks to ensure that they operate correctly. These can be executed by the operator from floor level.



In the event of a malfunction of equipment or unusual occurrences, the operator should immediately REPORT the fault(s) to the competent person. The crane should be taken out of service until the fault(s) have been rectified by the appropriately qualified personnel.

1. Ensure that a "Men Working Overhead" or a "Permit to Work" is not in force.
2. Check all round visibility and carefully note both permanent and temporary hazards.
3. Check that the ropes are correctly seated in the rope groves of drum and sheaves and have not been displaced. The rope should be free of kinks, protrusions, broken wires and other obvious defects.
4. Check the safety latch on the hook for damage.
5. Check that no electrical equipment is exposed to contamination by oil, grease, water or dirt.
6. Check that any audible and visual warning devices operate correctly.
7. Be familiar with the way in which each controller functions. Ensure that each function button or joystick, including the emergency stop, on the controller performs its stated operation, (without a load attached) and that each button or joystick returns to the neutral position when released (except emergency stop). Exercise caution whilst making these checks in case of a malfunction.
8. Check that the hoisting and lowering limit switch device operates correctly. To do this, raise or lower the empty hook slowly into the limit position to test its operation.



Extreme care should be taken when performing this test. Should the upper limit fail then there is a possibility of damaging the hoist.

9. Check the operation of any travel and / or traverse limit switches and brakes.



Do not use ANY limit switch as a regular method of stopping the motion. They are intended as emergency devices and are for the safety of personnel.

10. Check the operation of the hoist brake. To do this lift a load clear of the ground and release the UP pushbutton. The hook should remain in position with no run-back.

5.5 HOISTS THAT HAVE BEEN UNUSED FOR AN EXTENDED PERIOD

In cases where the crane / hoist has been out of use for an extended period of time the user should ensure that the competent person specifies a special programme of pre-use checks. The extent of the checks depends on the length of time the crane has been out of service and the location of the crane during that period.

As a minimum the pre-use checks should include the daily pre-start inspections mentioned above plus the following:-

1. Check all ropes for signs of corrosion / degradation and damage and that there is still adequate rope lubricant. Check the entire length of the rope.
2. Check that the RCL (rated capacity limiter) is functioning correctly.
3. Check for corrosion on the structure and mechanisms.
4. Check for damage and missing components or legends.
5. Test every motion for several minutes without load ensuring all brakes work satisfactorily.

The extended period of time should be determined by the competent person and will depend on the conditions and location. As a minimum, we would recommend that operations 1 to 4 above are carried out at least once every 6 months, and operation 5 is carried out monthly.

5.6 INSPECTION AND MAINTENANCE INTERVALS


In addition to the pre-use inspections listed above, a regular thorough inspection and maintenance programme is important. The following recommended intervals may vary depending on any other statutory requirements, environmental conditions or results of previous examinations. The competent person may deem it necessary to reduce these recommended periods between examinations.

INSPECTION AND MAINTENANCE INSTRUCTION	Duty	INTERVAL				
		A	B	C	D	E
WIRE ROPE The rope is regarded as an expendable item requiring replacement when examination shows its strength to have diminished to the point where its further use would be unwise. The entire length of rope should be inspected with particular attention being paid to areas where deterioration will be at its highest, for example where the rope enters or leaves sheaves and at rope anchor points. Assessment of Wire Rope Condition The continued safe use of wire ropes depends on assessment of the condition. Instructions on wire rope examination and discard can be found in BS ISO 4309:2004 and BS 7121: Part 2:2003.	M3			*		
	M4			*		
	M5			*		
	M6		*			
	M7		*			
	M8		*			
WIRE ROPE ANCHOR Rope terminations are as important as the rope itself. Check for mechanical damage to clevis pins, elongation of holes and damage to rope thimbles. Inspect wedge and socket anchorages for rope damage as it emerges from the socket, condition of the socket and security and tightness of the wedge fitting. Check the security of the rope anchors on the barrel. Replace any damaged parts.	M3			*		
	M4			*		
	M5			*		
	M6		*			
	M7		*			
	M8		*			
ROPE GUIDE Examine for signs of wear or damage particularly around the rope exit/entry point. Check security of guide bar and other fixings. Ensure that the guide bush travels freely and operates the upper and lower hoist limit switches correctly.	M3				*	
	M4				*	
	M5				*	
	M6			*		
	M7			*		
	M8			*		
BOTTOM BLOCK Check for cracks, cold deformation, wear and freedom of rotation of the sheaves and hook. Ensure hook safety catch operates correctly. Check security of the hook nut, and the securing grub screw. Replace any covers that may be damaged. Ensure the information labels are still legible (See section 5.12).	M3				*	
	M4				*	
	M5				*	
	M6				*	
	M7			*		
	M8			*		
HOIST AND TRAVEL BRAKE Carry out a functional (load) check of each of the motion brakes to ascertain that they operate efficiently. Check the output from the brake rectifier. Clean the brake, check the air gap and adjust and renew worn parts where necessary. In particular check wear on the rotor (disc), and the condition of the spline on both rotor and hub. Also check the condition of the hub key and keyway.	M3				*	
	M4				*	
	M5				*	
	M6			*		
	M7			*		
	M8			*		
HOIST AND TRAVEL GEARBOX Inspect around gearbox casing, filler and drain plugs and around oil seals for signs of lubrication seepage. Clean ventilation plug. Check security of fixings and renew seals if necessary. Apply gasket glue to hoist gearbox seal. When gearbox oil is drained during oil replacement, remove the gearbox inspection cover and visually check the gear teeth for wear. Check keys and keyways for security.	M3				*	
	M4				*	
	M5				*	
	M6				*	
	M7				*	
	M8				*	

Inspection and Maintenance Intervals: - A = Weekly, B = Monthly, C = 6 Monthly, D = Annually, E = Every 5 Years

INSPECTION and MAINTENANCE INSTRUCTION	Duty	INTERVAL				
		A	B	C	D	E
HOIST MOTOR AND COUPLING Clean motor fins and fan cowling. Check security of motor and coupling fixings. Check coupling and coupling element (see section 5.13). There is an inspection aperture for the coupling located in the underside of the gearbox casing.	M3				*	
	M4				*	
	M5				*	
	M6				*	
	M7				*	
	M8				*	
BARREL AND ROPE SHEAVES Examine the rope groove for wear or damage due to rope indentations. Rope sheaves must be replaced if the groove profile is not within tolerance. See section 5.9.1 Check that all sheaves are free running and that the sheave saddle is free to tilt.	M3				*	
	M4				*	
	M5				*	
	M6				*	
	M7				*	
	M8				*	
TRAVEL / TRAVERSE DRIVE COMPONENTS Check the condition of the wheels for signs of wear on the tread and flanges. Inspect the condition of any geared pinions and wheels for damage and wear. Ensure correct engagement of gear teeth. Low Headroom Hoist - Check the condition of the guide rollers and that they are set correctly. Adjust the reaction roller if required (see 3.4.1). Double Girder Crab 4&8 fall - Check security of the wheel locking rings.	M3				*	
	M4				*	
	M5				*	
	M6				*	
	M7				*	
	M8				*	
END STOPS AND DRIVE TORQUE ARM BUFFERS (where fitted) Check the condition of the end stops and rubber buffers. Replace if damaged.	M3				*	
	M4				*	
	M5				*	
	M6				*	
	M7				*	
	M8				*	
HOIST STRUCTURE Visually inspect overall structure for damage and unusual rubbing marks. Check rail for wear or localised damage. Check security of a reasonable quantity of the bolts in particular those that are not pen marked or where the pen mark has been disturbed. Check security of the grub screws on the hoist low head frame trolley legs see Figure 12. Visually examine welds for signs of cracks. Clean off any corrosion and apply an approved protective treatment to the surface.	M3				*	
	M4				*	
	M5				*	
	M6				*	
	M7				*	
	M8				*	
PENDANT AND / OR REMOTE CONTROLLER Check that the controller casing, pushbuttons / joysticks and their rubber seals are undamaged. In particular check the operation of the Emergency Stop button. Check that the Pendant strainer wire fixings are secure and the cable entry seal is undamaged. Check that all legends on the controller and hoist are clear and legible. For radio controlled units, check for any corrosion caused by faulty batteries.	M3				*	
	M4				*	
	M5				*	
	M6				*	
	M7			*		
	M8			*		
ELECTRICAL CABLES Check for damage, loose connections and loose / damaged cable entry points. Check cable insulation for signs of brittleness (does not crack when flexed) or overheating (discolouration). Replace where necessary. Check the condition of the strainer wire on Pendant cable and the wire clamp points.	M3				*	
	M4				*	
	M5				*	
	M6				*	
	M7				*	
	M8				*	

Inspection and Maintenance Intervals: - A = Weekly, B = Monthly, C = 6 Monthly, D = Annually, E = Every 5 Years

INSPECTION and MAINTENANCE INSTRUCTION	Duty	INTERVAL				
		A	B	C	D	E
CURRENT COLLECTORS / BUSBAR Inspect collector arms and carbon shoes for signs of damage or wear. Replace where necessary. Check joints and insulation for signs of arcing. Rectify as necessary.	M3				*	
	M4				*	
	M5				*	
	M6				*	
	M7				*	
	M8				*	
DISCONNECT SWITCH AND MAIN ISOLATOR Check for damage and satisfactory operation.	M3				*	
	M4				*	
	M5				*	
	M6				*	
	M7				*	
	M8				*	
ELECTRICAL PANELS  Inspect relays, contactors and wiring for security and physical damage. Renew if signs of damage or overheating are apparent. Ensure panel door closes securely. Lightly lubricate panel hinges. Clean /replace enclosure filters where fitted. Check that isolating switch operates correctly. Remove any dirt or debris from the panel.	M3				*	
	M4				*	
	M5				*	
	M6				*	
	M7			*		
	M8			*		
EARTH CONTINUITY AND INSULATION RESISTANCE Carry out earth continuity and insulation resistance tests on the installation.	M3				*	
	M4				*	
	M5				*	
	M6				*	
	M7				*	
	M8				*	
HOIST AND LOWER LIMIT SWITCHES Inspect for wear or damage. Check for correct operating position. Check that the limit bush travels satisfactorily along the limit bush bar (see section 3.6) Check the operation of the second upper limit (where fitted) (see section 3.7)	M3				*	
	M4				*	
	M5				*	
	M6				*	
	M7			*		
	M8			*		
TRAVEL / TRAVERSE LIMIT SWITCHES Inspect for wear or damage and security of fixings. Check for correct operating position.	M3				*	
	M4				*	
	M5				*	
	M6				*	
	M7			*		
	M8			*		
RATED CAPACITY LIMITER Physically check the components in the RCL for wear or damage. Check security of cables, connections and mounting. Test the operation of RCL by applying the necessary calibrated load (see section 3.14).	M3				*	
	M4				*	
	M5				*	
	M6				*	
	M7				*	
	M8				*	
SERVICE LIFE Establish the remaining service life of the hoist (see section 7.2).	M3				*	
	M4				*	
	M5				*	
	M6				*	
	M7				*	
	M8				*	

Inspection and Maintenance Intervals: - A = Weekly, B = Monthly, C = 6 Monthly, D = Annually, E = Every 5 Years

5.7 LUBRICATION



Always follow the safety instructions provided by the lubricant manufacturer. Some general precautions are as follows:-

- Always be aware of the risk of fire. Keep the lubricant away from heat and open fires. Do not smoke. Have the relevant fire extinguish media to hand.
- Keep any containers closed and always store in the manner recommended by the manufacturer. Soak up any spillage immediately.
- Avoid prolonged and frequent contact with skin, wear gloves or use oil repellent barrier creams. Keep away from food and drink. Do not inhale any fumes. Do not swallow. Wear eye protection. Always wash hands thoroughly after use. Obtain first aid treatment for any injury, however slight.
- Dispose of the lubricant and its containers in the recommended manner. Do not allow the lubricant to contaminate water supplies.

General

- All gearboxes must be at standstill when oil filling.
- Use only fresh oils / greases
- Do not mix oils and greases of different types and manufacturers.
- Re-fit all plugs and covers etc. and check for leaks afterwards.
- Remove any excess lubricant.
- Note: too much grease can cause a bearing to over heat and reduce the life of the bearing.



= Oil Ventilation / filler plug




= Oil level plug




= Oil drain plug

THE ABOVE SYMBOLS APPLY TO Figure 31 & Figure 32




ZX6 Hoists with vertical position gearbox




ZX6 Hoists with horizontal position gearbox

Figure 31 – ZX6 Gearbox oil fill & level plug locations



ZX8 Hoists with angled position gearbox



ZX8 Hoists with horizontal position gearbox

Figure 32 – ZX8 Gearbox oil fill & level plug locations

5.7.1 Lubrication Schedule

Intervals of lubrication are given for general guidance. Special applications and/or experience may show alternative intervals to be more appropriate.

ITEM and LUBRICATION INSTRUCTION	Duty	INTERVAL					LUBRICANT										
		A	B	C	D	E											
ZX HOIST GEARBOX First oil change is due at 500 hours of operation. Thereafter replace the oil every 3000 operating hours or every 5 years. Fill to the level plug. See Figure 31 & Figure 32 <table border="1" style="margin-left: 20px;"> <thead> <tr> <th>Gearbox Size</th> <th>Quantity (litres)</th> </tr> </thead> <tbody> <tr> <td>ZX6 low head</td> <td>2.5</td> </tr> <tr> <td>ZX6 foot mount/crab</td> <td>2.5</td> </tr> <tr> <td>ZX8 low head</td> <td>9.20</td> </tr> <tr> <td>ZX8 foot mount/crab</td> <td>4.91</td> </tr> </tbody> </table>	Gearbox Size	Quantity (litres)	ZX6 low head	2.5	ZX6 foot mount/crab	2.5	ZX8 low head	9.20	ZX8 foot mount/crab	4.91	M3					*	ISO VG460 mineral oil for ambient operating temperatures of -10 to +60°C
	Gearbox Size	Quantity (litres)															
	ZX6 low head	2.5															
	ZX6 foot mount/crab	2.5															
	ZX8 low head	9.20															
	ZX8 foot mount/crab	4.91															
M4						*											
M5						*											
M6						*											
M7						*											
M8						*											
HOOK BLOCK THRUST BEARING Grease nipple for the thrust bearing. (Note: The ZX hook block sheave bearings are 'sealed for life' and do not require any further lubrication throughout the design lifetime of the hoist).	M3					*	NLGI grade 2 grease with EP additives and oxidation inhibitors. Viscosity : 1000 cSt at 40°C 58 cSt at 100°C Drop point : >180°C Operating temperature range : -10 to +120°C										
	M4					*											
	M5					*											
	M6			*													
	M7			*													
	M8			*													
HOIST ROPE Clean the rope surface before applying new lubricant. This is particularly important in environments containing abrasive particles. For maximum effect the lubricant is best applied to the rope where it 'opens up' as it travels over a sheave or winds on the barrel. Intervals of lubrication are given for general guidance. Special applications and/or experience may show alternative intervals to be more appropriate. As a general rule the dressing should be re-applied at regular intervals and before the rope shows signs of corrosion or dryness.	M3					*	<i>"Street-Drako Compound"</i> or similar oil based rope lubricant with additives for good penetration, adherence and corrosion protection. Effective temperature range -20 to +60°C										
	M4					*											
	M5			*													
	M6			*													
	M7		*														
	M8		*														
ROPE GUIDE Smear the inner groove of the rope guide with the rope lubricant each time a new hoist rope is fitted.	M3						<i>"Street - Drako Compound"</i> or similar oil based rope lubricant with additives for good penetration, adherence and corrosion protection. Effective temperature range -20 to +60°C.										
	M4																
	M5																
	M6																
	M7																
	M8																

Inspection and Maintenance Intervals: - A = Weekly, B = Monthly, C = 6 Monthly, D = Annually, E = Every 5 Years

ITEM and LUBRICATION INSTRUCTION	Duty	INTERVAL					LUBRICANT
		A	B	C	D	E	
SHEAVE SADDLE PIVOT POINTS AND HOIST LIMIT BUSH GUIDE BAR Spray into the end pivot points of the sheave saddle.	M3				*		Multi-purpose liquid aerosol lubricant/penetrant. (WD40).
	M4				*		
	M5				*		
	M6				*		
	M7				*		
	M8				*		
TRAVERSE DRIVE GEARBOX First oil change is due at 500 hours of operation. Thereafter replace the oil every 3000 operating hours or every 5 years. Fill to the level plug. See table below for lubricant quantity.	M3				*		ISO VG220 mineral oil for ambient operating temperatures of –10 to +40°C. ISO VG220 synthetic oil for ambient operating temperatures of –25 to +80°C.
	M4				*		
	M5				*		
	M6				*		
	M7				*		
	M8				*		

Traverse Drive Gearbox Ref. (see nameplate)	Lubricant Qty (litres)
SK01	0.25
SK172	0.35
SK250	1.4
SK373	0.55
SK2282	1.65

Inspection and Maintenance Intervals: - A = Weekly, B = Monthly, C = 6 Monthly, D = Annually, E = Every 5 Years

5.8 INSPECTION AND MAINTENANCE – WIRE ROPE



Failure of a wire rope may cause death or serious injury. A wire rope will fail if worn out, shock loaded, overloaded, miss-used, damaged, abused or improperly maintained. Information on care, maintenance, installation, examination and discard of wire ropes can be found in BS ISO 4309:2004 and / or BS 7121-1:2006. The competent person should hold a copy of these documents.



Do not replace a rope or any rope fittings with anything other than to the original specification. This applies equally to the rope length as well as its construction.

The Rope Data Plate is located in the vicinity of the Hoist Nameplate (see 2.1) and contains all the required rope replacement information.

5.8.1 Offloading and Storage

Care of a new rope begins immediately upon receipt. Use wide textile webbing slings or lift on the rope drum to avoid direct contact with the rope. Inspect the rope upon receipt and ensure that the details on the certificate and other documents are correct. Clearly label the rope and ensure that it is traceable to its certificate and / or other documents.

Steel wire ropes should be stored in a clean, cool, dry place, indoors and away from corrosive and damp atmospheres. Do not let the rope rest directly on the floor allow air to circulate around the reel. Cover with a breathable cover that prevents condensation. Inspect the rope periodically and if necessary, apply a suitable dressing that is compatible with the manufacturer's lubricant see section 5.7.1.

When removing from storage, check that no accidental damage has occurred and that there are no signs of corrosion. Ensure the rope certificate is available and retain this in a safe place, it will be required when periodic examinations are carried out.

5.8.2 Replacing the Wire Rope



Removal and replacing the wire rope is most effectively carried out with the power to the hoist unit switched ON so all work must be carried out with extreme care. Suitable safety precautions should be made to ensure that other motions are not accidentally activated, i.e. isolate any travel motions. It may be necessary to adjust the lower limit to allow the block to lower to ground level. NOTE: The upper and lower limit will require resetting after completion of new rope installation.

5.8.2.1 Removing the Rope and Rope Guide

- Lower the bottom block down to the lowest possible level and allow the block to rest on a solid support (floor or platform).
- Remove the rope guide Retainer from both of the rope guides and release the four screws in each one at the rope guide joint. Take care to ensure the lower half of the guide does not fall.
- Release the two screws joining the two halves of the inner bands and remove the inner bands. Retain all screws, washers, spacers and springs.
- Run the remaining rope off the barrel and through the sheaves keeping tension on the rope as it is being run off.
- Release the rope anchors on the barrel.

5.8.2.2 Fitting New Wire Rope



Fitting the wire rope is most effectively carried out with the power to the hoist unit switched ON so all work must be carried out with extreme care. Suitable safety precautions should be made to ensure that other motions are not accidentally activated, i.e. isolate any travel motions.

Fitting of a new rope must be carried out by a competent person. Before installation check that all sheaves are free running and rope grooves in sheaves and drums are in good condition. Groove profiles should be circular, smooth and free from ridges (see 5.9.1).

Check that the correct rope has been ordered / taken out of storage. Examine the rope visually to ensure that there is no damage or corrosion on the rope. Prepare a safe and clean working area to avoid contaminating the rope with any dirt or moisture.

To prevent the possibility of kinking or imparting any twist into the rope, it should be uncoiled without slack and in a straight line. Short lengths of rope can be uncoiled along the ground (see Figure 33). If the coil is too large to handle, place on a turntable and pull the outside end of the rope allowing the coil to rotate.




Figure 33 – Correct Uncoiling of Wire Ropes




Figure 34 - Incorrect Uncoiling of Wire Ropes

Do not pull the rope away from a stationary coil. This will induce twist and possibly kinks in the rope that will seriously impair its performance and result in premature failure (see Figure 34).

5.8.2.3 4 Fall hoist

- Pull the tail end of the rope off the spool and pass over the compensating sheave on the hoist.
- Drag the spool and the tail end away from the hoist together, until the spool is empty (note that the distance you need to travel with the spool will be half the total rope length). You should now have two equal length tail ends and the centre of the rope over the compensating sheave.
- With the bottom block positioned under the hoist in the correct orientation, bring both tail ends back to the hoist ensuring that the ropes don't cross or twist unnecessarily.
- Feed the tail ends through the bottom block and up to the drum. (See Figure 37 to Figure 39).

If it is not possible to uncoil the rope prior to fitting, the rope may be transferred directly from the reel to the hoist barrel. Place the reel on a suitable stand and ensure that the reel can rotate freely. When winding from reel to barrel the rope should be bent in the same direction. Wind from top of reel to top of barrel or from bottom of reel to bottom of barrel (see Figure 35).




Figure 35 – Winding of new wire ropes

- Clamp the tail ends to the drum.

- Transfer the new rope onto the hoist barrel. Ensure that sufficient tension is applied to the reel to prevent loops from forming. Tension can be applied with suitably gloved hands or with a brake on the reel (see Figure 35). During installation, also ensure that the fleet angle θ does not exceed $1\frac{1}{2}^\circ$, (see Figure 36).




Figure 36 - Fleet angle

- Wind approximately 15 scrolls of rope onto the barrel and then fit the rope guide as per section 5.8.3
- Wind the remainder of the rope onto the barrel.

5.8.2.4 8 Fall hoist

- Place rope spool onto an axle that will suspend it off the ground, at the side of the hoist. Ensuring that it will pay out in the same direction as it would from the drum.
- Place the bottom block on a pallet at a distance that represents the HOL of the hoist.
- Pull the tail end from the spool and pass through the first sheave of the bottom block.
- Then back to the hoist and over the outer most of the twin sheave assembly, closest to the spool side of the hoist.
- Back to the bottom block and through the inner sheave on the opposite side to that of which is already reeved.
- Back to the hoist and over the compensating sheave so the rope falls off on the spool side.
- Back to the bottom block and through the unused inner sheave.
- At the hoist pass tail end over the inner of the twin sheaves so that it falls off on the opposite side to the spool.
- Back at the bottom block pass through the last sheave and back to the hoist.
- At this point both tail ends should be at a similar length ready to be connected to the hoist drum.
- Clamp the tail ends to the drum.
- Wind approximately 15 scrolls of rope onto the barrel and then fit the rope guides as per section 5.8.3
- Wind the remainder of the rope onto the barrel.




Figure 37 – Reeving Diagrams for ZX6 & ZX8 4&8 Fall Low Head & Crab Hoists
 Low Head Hoists: ZX064-LHR / ZX084-LHR / ZX088-LHR
 Crab Hoists: ZX064-CRB / ZX084-CRB/ZX084-CRE / ZX088-CRB/ZX088-CRE





Figure 38 – Reeving Diagrams for Foot Mount Hoists: ZX084-FTM / ZX088-FTM



**4 FALL REEVING
ZX64 FOOT MOUNT**

Figure 39 – Reeving Diagrams for Foot Mount Hoists: ZX064-FTM

5.8.2.5 Running In

After installation of a new rope the hoist should be run several times under light load (approx 10% of SWL) and at slow speed to allow the wire and strands of the rope to align themselves and bed down. This can greatly increase the rope life.

5.8.2.6 Removing twist

If any twist is imparted in the rope during installation the bottom block will rotate, particularly with no load attached. If twisting does occur, remove the rope from the hoist and untwist by letting the rope hang freely or laying the rope out on the floor.



Remove any twist before the hoist is subject to any further load. The rope may otherwise be permanently damaged.

5.8.3 Fitting the Rope Guide

- Fit the top and bottom halves of the rope guide inner band over the rope ensuring correct orientation. NOTE: the reduced diameter of the Band faces **TOWARDS** the end of the drum.




Figure 40 –Fitting Top and Bottom Halves of Rope Guide Inner Band

- Fit the socket head capscrew and spring into the deep counterbore and place the sleeve and washer over the screw as shown in
- Figure 41 . Loosely tighten the socket head capscrew.




Figure 41 – Rope Guide Inner Band Spring and Sleeve Arrangement

- Fit the socket head capscrew to the non-spring side inserting the plastic washer between the two halves of the rope band. Tighten to 1.5Nm.
- Position the inner band assembly over the rope such that 2 free rope coils remain unclamped and tighten the capscrew on the spring side 1.5Nm (see Figure 42).



Ensure all slack rope is removed prior to tightening inner band fixings. It should not be possible to slide or rotate the inner band over the rope without using excessive force. If the inner band is moved easily, remove one or both plastic washers from the inner band joint.




Figure 42 – Rope Guide Inner Band Fitted

- Lightly lubricate the location groove on both halves of the outer band (see section 5.7.1).
- Fit the bottom half of the outer band (tapped joint holes) over the inner band and rotate until it is on the underside of the barrel ensuring that the slot collects the rope which leaves the barrel (see Figure 43).




Figure 43 – Fitting Rope Guide Outer Band

- Fit the top half of the rope guide over the inner band. Insert the four socket head capscrews and screw two halves together. Tighten to 1.5Nm.
- FOR STANDARD ENVIRONMENT ROPE GUIDES type Rv-1:- Fit the rope guide retainer to the face of the rope guide. Tighten the screws to 8Nm (see Figure 44).
- Set the upper and lower limit switches (see Section 3.6)




Figure 44 – Fitting Rope Guide Retainer – Standard Environments Rv-1 (see hoist nameplate for revision)

5.9 INSPECTION AND MAINTENANCE- HOIST / CRAB FRAME

Periodically inspect the frame in accordance with recommended intervals given in the inspection and maintenance programme (see 5.6). Check the security of a reasonable quantity of the bolts in the hoist frame in particular those that are not pen marked or where the pen mark has been disturbed.

5.9.1 Sheaves

Check all rope sheaves for wear and for free running. The sheaves should rotate freely when rotated without load.

The sheave must be replaced if the wear on the groove side wall or the groove base is significant. Measure the thickness of the side wall and groove depth as shown and replace the sheave if the wear exceeds the values given.




Figure 45 - Sheave characteristics

Hoist Type	Sheave Casting Identification	Diameter 'D' (mm)	't' (mm)		'g' (mm)	
			new sheave	minimum	new sheave	minimum
ZX6/ZX8	100-181	192	5	4.5	12	13.2
ZX8	100-271	289	10.6	9.5	19.5	21.5
ZX8	100-361	319	10.6	9.5	19.5	21.5

The sheave must also be replaced if the radius in the bottom of the groove has become too large. The rope may become flattened and distorted under load, thus resulting in premature failure. Minor impressions of the rope profile in the bottom of the groove are acceptable.




Figure 46 - Sheave and barrel groove inspection

Nominal Rope Diameter "d" (mm)	Minimum Groove Diameter (mm)	Maximum Groove Diameter (mm)
8.0 (ZX6 & ZX8)	8.4	9.0
13.0 (ZX8)	13.6	14.6

5.9.2 Single Girder Wheels

Visually inspect the wheels, the guide rollers and the reaction roller for wear. When the diameter has reduced to the value given in the table below, replace the wheels / roller.

Wheel		Low Head Hoist Reaction Roller		Guide Roller	
Original diameter (mm)	Replacement diameter (mm)	Original diameter (mm)	Replacement diameter (mm)	Original diameter (mm)	Replacement diameter (mm)
100	< 96	75	< 72	40	< 37
160	< 152				

If a trolley wheel or roller needs replacing, consult Street Crane.

5.9.3 Double Girder Crab Wheels (Double Flange)

Visually inspect the wheels for wear. When the diameter has reduced to the value given in the table below, replace the wheels.

Wheel		Flange Thickness	
Original diameter (mm)	Replacement diameter (mm)	Original thickness (mm)	Replacement thickness (mm)
125	< 119	10	< 5
160	< 152	10	< 5
200	< 190	18	< 9

If a trolley wheel needs replacing, consult Street Crane.

5.10 INSPECTION AND MAINTENANCE – HOIST BRAKE

The main hoist brake is a spring applied disc brake. The brake is electro-magnetically released by the application of DC to the brake coil in the stator. The size of the brake fitted to your hoist is indicated within the hoist model code see 7.3.

When inspecting the brake, particular attention should be made to checking the air gap and the condition of the rotor (brake disc) spline.

5.10.1 Hoist Brake Components




Figure 47 – Hoist Brake Components

Ref	Description
1	Armature plate
2	Brake hub
3	Brake disc (rotor)
4	Mounting Flange
5	Stator
6	Hub circlip
7	Assembly screws
8a	Outer brake seal (optional kit)

Ref	Description
8b	Stator brake seal (optional kit)
9	Hand release mechanism
10	Hand release spring
11	Washer
12	Hand release fixing
13	Barrel nuts
14	Adjustment tubes

5.10.2 Hoist Brake Data

Hoist Brake Size (see model code section 7.3)	1	2	3	4	5	6	7	8	9
Nominal air gap 'a' (mm) (+0.1, -0.05mm)	0.3	0.3	0.3	0.3	0.3	0.4	0.4	0.4	0.4
Maximum air gap 'a' (mm)	0.45	0.75	0.75	0.75	0.75	1.0	0.6	1.0	0.6
Maximum rotor thickness (mm)	10.0	10.0	10.0	10.0	11.5	13.0	16.0	16.0	16.0
Minimum rotor thickness (mm)	8.3	7.5	7.5	7.5	8.0	10.0	12.4	12.0	12.4
Rotor outside diameter (mm)	115	124	124	124	149	174	206	206	206
Maximum adjustment / admissible wear (mm)	1.7	2.5	2.5	2.5	3.5	3.0	3.6	4.0	3.6
Tightening torque of assembly fixings (Nm)	9.5	23	23	23	23	23	46	46	46
Tightening torque of hand release lever (Nm)	4.8	12	12	12	12	23	23	23	23
Hand release clearance 's' (mm)	1.5	1.5	1.5	1.5	1.5	2.0	2.0	2.0	2.0



Before adjusting the brake or changing the disc, lower the bottom block to a suitable level (floor or platform) and allow it to rest on a solid support. Disconnect the power supply to the hoist and to the brake.

5.10.3 Brake Disc (Rotor) Spline

Check the brake disc and hub for wear on the spline teeth. The end of the spline can be viewed from the end of the brake shaft. If the brake is fitted with the seal end cap (8b), this will have to be removed before inspection. For a more detailed inspection the brake disc will have to be removed. If the spline appears replace the brake disc and/or hub immediately.

5.10.4 Checking / Adjusting the Air Gap

To inspect the air gap it may be necessary to lift or remove the outer brake seal (8a), where fitted. Adjustment of the hoist brake will require total removal of the outer brake seal. The air gap 'a' (between the stator (5) and the armature plate (1)) should be checked in at least three positions around the circumference of the brake using non-magnetic feeler gauges (see Figure 48). The air gap should not exceed the maximum air gap figure given in the above table.




Figure 48 – Checking Hoist Brake Air Gap

Where adjustment is required, slacken the assembly screws (7). Adjust the air gap by turning the adjustment tubes (14) until the nominal air gap 'a' is reached (see Figure 49).

- If the air gap is too large, screw the three adjustment tubes (14) into the stator. If the air gap is too small, screw the adjustment tubes out of the stator.
- NOTE : 1/6 turn adjusts the air gap by approx. 0.15mm
- Re-tighten the assembly fixings to the recommended torque value (see table in 5.10.2).
- Re-check the air gap and repeat the adjustment procedure if necessary.
- Test the brake for correct operation before re-fitting the outer brake seal (where fitted) and returning into service.




Figure 49 – Adjusting the Hoist Brake Air Gap

5.10.5 Changing the Brake Disc (brake rotor) / Inspecting the brake hub

The thickness of the brake disc can be measured using a vernier calliper without the need to remove the brake. Disconnect the power supply and remove the brake seal (if fitted). Measure between the mounting flange and the armature plate (Figure 50). If the minimum thickness is below the figure given in the Hoist Brake Data table (5.10.2), the brake disc should be replaced.




Figure 50 – Inspecting the Brake Disc

- Remove the outer brake seal (where fitted) and clean any brake dust from around the brake.
- Loosen the assembly fixings evenly and remove them taking care to support the brake body.
- Remove the brake body, taking note of its orientation.
- The brake rotor (brake disc) will now be exposed. Withdraw the brake rotor from its hub.
- Before replacing the brake disc, visually inspect the end of the key between the brake hub and shaft. Check the condition of the spline on the brake hub and ensure there is no radial or rotational play between either the new brake disc and the hub or the hub and the shaft. If the hub is damaged, worn or play is apparent, the hub should be replaced. Before replacing, consult Street Crane.
- Ensure the face of the mounting flange is clean and free of any oil or grease. If the mounting flange is worn or excessively scored it should be replaced. Consult Street Crane before replacing.
- Using a vernier calliper, measure both the new brake disc thickness and length of protrusion of the adjustment tubes from the back of the brake.

- Calculate the distance between the stator and the armature plate as follows: -

$$\text{Distance} = \text{Brake disc thickness} + \text{Nominal Air Gap 'a'} - \text{adjustment tube height}$$

- The adjustment tubes should be unscrewed until the calculated distance between the stator and the armature plate is reached.
- Slide the new brake disc (rotor) onto the hub.
- Replace the brake body in the same orientation as originally installed.
- Replace the assembly fixings and tighten to the torque value stated in the table (5.10.2).
- Check and adjust, where necessary, the nominal air gap 'a' and the hand release clearance 's' (see 5.10.4 & 5.10.6).
- Replace the brake seal, where fitted (see 5.10.7).
- Re-connect the brake supply and test the brake for correct operation before returning into service.

5.10.6 Fitting the Hand Release

For safety reasons, the hand release is spring loaded and returns to its original position (brake applied) automatically.

- Insert the compression springs (10) into the holes of the armature plate (1).
- Fit the washers (11) onto the hand release fixings (12) and assemble through the compression springs (10) and the stator (5).
- Fit the barrel nuts (13) into the holes provided in the hand release (9).
- Position the hand release (9) over the stator and tighten the hexagon screws (12) into the barrel nuts (13) until the armature plate moves towards the stator.
- Adjust the gap between the armature plate and the stator using the hexagon hand release screws (12) to achieve a dimension ('s' + 'a') (see Figure 51). Example 1.8mm (1.5+0.3) for brake size 3. Check the dimension at three positions around the circumference.
- Fit the complete brake assembly onto the hoist and tighten the assembly screws (7) to the value shown in the table (5.10.2).
- Re-adjust the air gap 'a' in accordance with section 5.10.4.
- Re-check the Hand Release Clearance dimension 's' and nominal air gap 'a' before returning into service.



The hand release clearance gap, 's' is important. The brake may not apply correctly if the clearance is too small. If the nominal air gap 'a' is adjusted at a later date, do not alter the hand release clearance.




Figure 51 – Hoist Brake Hand Release

5.10.7 Fitting the brake seal kit (optional)

- Pull the electrical cable through the rubber sealing ring.
- Drop the outer brake seal (8a) over the hand release lever and push the sealing ring over the stator.
- Press the lips of the seal into the grooves into the stator (1) and the mounting flange (4) (see Figure 52).
- Tap the stator brake seal (8b) into the hole in the front of the stator.




Figure 52 – Brake Seal

5.10.8 Brake rectifier

The ZX series hoist uses three types of brake rectifier. These vary with the size of brake. The rectifier type is marked on the rectifier.

Brake Size (see hoist model code section 7.3)	1, 2 and 3	4 to 9
Brake rectifier type	Normal full wave 14.630.32.016 (BEG-161-270) OR B3-18464 (CSA approved)	Force voltage, full/half wave B3-69500(CSA approved)

Testing the normal rectifier types 14.630.32.016 and B3-18464

With the brake connected to the rectifier, check that the input voltage to the rectifier is correct at 220V. The output, measured at the brake coil terminals, should be approximately 198V DC.

Testing the force voltage rectifier, type B3-69500

With the brake connected to the rectifier, check that the input voltage to the rectifier is correct at 220V. The output, measured at the brake coil terminals, should be 198V DC for 1 second and then reduce to and hold at 98V DC (note these values are approximate only). Use an analogue meter for this test (a digital meter is not suitable).

If the output voltage from the test is below the figures provided, the rectifier should be replaced.

5.11 INSPECTION AND MAINTENANCE – TRAVERSE BRAKE

The traverse brake is a spring applied disc brake. The brake is electro-magnetically released by the application of DC to the brake coil in the stator. To access the traverse brake, the traverse drive fan cowl should be removed. First unscrew the hand release lever (if fitted). The brake rectifier is located in the motor terminal box.

5.11.1 Traverse Brake Components




Figure 53 – Traverse Brake Components

Ref	Description
1	Armature plate
2	Brake hub
3	Brake disc (rotor)
4	Mounting Flange
5	Stator
6	Hub circlip
7	Assembly screws
8a	Outer brake seal (optional kit)

Ref	Description
8b	Stator brake seal (optional kit)
9	Hand release mechanism
10	Hand release spring
11	Washer
12	Hand release fixing
13	Barrel nuts
14	Adjustment tubes
15	Torque adjuster nut (Factory set)



Before adjusting the brake or changing the disc, disconnect the power supply to the hoist and to the brake.

5.11.2 Checking / Adjusting the Air Gap

To inspect the air gap it may be necessary to lift or remove the outer brake seal (8a), where fitted. Adjustment of the brake will require total removal of the outer brake seal.

The air gap 'a' (between the stator (5) and the armature plate (1)) should be checked in at least three positions around the circumference of the brake using non-magnetic feeler gauges (see Figure 54). The air gap should not exceed the maximum air gap of **0.6mm**.




Figure 54 – Checking Traverse Brake Air Gap

Where adjustment is required, loosen the assembly screws (7) by half a turn. Adjust the air gap by turning the adjustment tubes (14) until the required air gap is reached (see Figure 55).

- If the air gap is too large, screw the three adjustment tubes (14) into the stator. If the air gap is too small, screw the adjustment tubes out of the stator.
- Adjust the air gap until a gap of 0.2-0.3mm is reached around the brake.
- Re-tighten the assembly fixings to 3Nm
- Re-check the air gap and repeat the adjustment procedure if necessary.
- Test the brake for correct operation before replacing the outer brake seal (where fitted), the fan cowl and returning the drive into service.




Figure 55 – Adjusting the Traverse Brake Air Gap

5.11.3 Changing the Brake Disc (brake rotor) / Inspecting the brake hub

The thickness of the brake disc can be checked by measuring the distance between the mounting flange and armature plate (5.10.5). If the distance is below **4.5mm**, the brake disc should be replaced.

- Remove the circlip and withdraw the fan from the motor shaft.
- Remove the outer brake seal (if fitted) and clean any brake dust from around the brake.
- Loosen the assembly fixings evenly and remove them taking care to support the brake body.
- Remove the brake body, taking note of its orientation.
- The brake rotor (brake disc) will now be exposed. Withdraw the brake rotor from its hub.

- Before replacing the brake disc, visually inspect the end of the key between the brake hub and shaft. Check the condition of the spline on the brake hub and ensure there is no radial or rotational play between either the new brake disc and the hub or the hub and the shaft. If the hub is damaged, worn or play is apparent, the hub should be replaced. Before replacing, consult Street Crane.
- Ensure the face of the motor end shield is clean and free of any oil or grease. If the end shield is worn or excessively scored it should be replaced. Consult Street Crane before replacing.
- Slide the new brake disc (rotor) onto the hub.
- Replace the brake body in the same orientation as originally installed.
- Replace the assembly fixings and tighten 3Nm.
- Check and adjust, where necessary, the nominal air gap 'a' and the hand release clearance 's' (see 5.11.2 & 5.11.4).
- Replace the brake seal, where fitted (see 5.11.5).
- Press the motor fan onto the motor shaft and replace the circlip, replace the motor fan cowl and the hand release lever.
- Re-connect the brake supply and test the brake for correct operation before returning into service.

5.11.4 Fitting the Traverse Drive Hand Release

For safety reasons, the hand release is spring loaded and returns to its original position (brake applied) automatically.

- Insert the compression springs (10) into the holes of the armature plate (1).
- Fit the washers (11) onto the hand release fixings (12) and assemble through the compression springs (10) and the stator (5).
- Fit the barrel nuts (13) into the holes provided in the hand release (9).
- Position the hand release (9) over the stator and tighten the hexagon screws (12) into the barrel nuts (13) until the armature plate moves towards the stator.
- Adjust the gap between the armature plate and the stator using the hexagon hand release screws (12) to achieve a dimension of 1.0mm. Check the dimension at three positions around the circumference.
- Fit the complete brake assembly onto the hoist and tighten the assembly screws (7) to 3Nm.
- Re-adjust the air gap 'a' in accordance with section 5.11.2.
- Re-check the Hand Release Clearance dimension 's' (0.7mm) and nominal air gap 'a' (0.2-0.3mm) before returning into service.



The hand release clearance gap, 's' (0.7mm) is important. The brake may not apply correctly if the clearance is too small. If the nominal air gap 'a' is adjusted at a later date, do not alter the hand release clearance.




Figure 56 – Traverse Drive Brake Hand Release

5.11.5 Fitting the brake seal kit (optional)

- Withdraw the fan from the motor shaft.
- Pull the electrical cable through the rubber sealing ring.
- Drop the outer brake seal (8a) over the hand release lever and push the sealing ring over the stator.
- Press the lips of the seal into the grooves into the stator (1) and the mounting flange (4) (see Figure 57).
- Tap the stator brake seal (8b) into the hole in the front of the stator.
- Press the motor fan onto the motor shaft and replace the motor fan cowl.




Figure 57 – Traverse Drive Brake Seal

5.12 INSPECTION AND MAINTENANCE – HOOK BLOCK



All inspections should be carried out by trained personnel.

- Each bottom block is clearly labelled with the maximum capacity (safe working load) of the hoist. Ensure that the SWL labels are legible on the sheave covers.
- Check that the hook rotates freely.
- Check the security of the hook nut and it's securing grub screw, for 4 and 8 Fall remove cap to inspect see Figure 59.
- Inspect the hook ensuring that it is in good condition and free from deformation.
- Check the hook throat admittance (see Figure 58). Replace the complete bottom block where "t" max. has been exceeded.




Figure 58 – Hook Throat Admittance

Example from hoist model code: ZX064 - 3EoNM5K031 - LHR0002 - 40050E14X

HOIST MODEL TYPE	NO. FALLS	Rope Ø	"t" New Hook (mm)	"t" max. (mm)	"w" ref only. (mm)
ZX06	4	Ø8	50	55	38
ZX08	4	Ø8	50	55	38
	4	Ø13	56	61.6	73
	8	Ø8	56	61.6	73

- Check that the safety catch operates and springs fully closed against the hook point.
- Check the condition of the sheave covers ensuring that they are not damaged. Replace any damaged covers.
- Check security of sheave cover fixings.
- Examine the condition of the sheave(s) and ensure that they are free from cracks or damage due to rope indentations. Check that they can be rotated freely.
- Grease the hook thrust bearing as required in the lubrication schedule (see section 5.7.1 & Figure 59).





Figure 59 – Bottom Block, Hook Nut, Grubscrew, Grease nipple

5.13 INSPECTION AND MAINTENANCE – HOIST DRIVE COUPLING

The coupling between the hoist motor and gearbox does not require any maintenance but periodically check for damage to the coupling element and that the correct gap between the two halves of the coupling as been maintained. Inspection can take place through an aperture on the underside of the gearbox case.



If the coupling element requires changing proceed as follows:-




Before removing the motor, lower the bottom block to a suitable level (floor or platform) and allow it to rest on a solid support. Ensure that the mains power is isolated before starting any work.

- Disconnect the power cables from the motor terminal box making notes of each cable and its relative terminal connection.
- Support the motor and remove the four retaining nuts and spring washers that fasten the motor to the gearbox.



NOTE: A hoist motor can weigh up to 120kg (see HOIST MOTOR DATA 7.5).

- Carefully withdraw the motor noting the orientation of the motor terminal box.
- Remove the motor complete and replace the coupling element with new.
- If the coupling body is damaged or loose on the shaft and has to be changed, consult the manufacturer before replacing.
- Carefully refit the assembly onto the side of the hoist gearbox ensuring that the orientation is correct and that the coupling spider element meshes correctly in the coupling hub claws. Do not force engagement of the coupling if any resistance is felt. Use the inspection hole on the underside of the gearcase to ensure correct engagement.
- Replace the motor retaining nuts and spring washers and tighten to 40Nm.
- Check, through the inspection hole, that the coupling halves have engaged correctly and that the gap between the two coupling halves is as shown.
- Re-connect the cables to the motor terminals and, when power is re-established, test for correct operation and direction of rotation.



6 FAULT FINDING



When fault finding on live electrical circuits or energised equipment wear the relevant PPE and use test equipment suitably rated for the tests being carried out. Obtain information from the people who use the equipment and who were present at the time the fault developed. Observe the system during start-up, operation and shut-down to trace the fault area. Isolate the area of the system that is suspicious but do not restrict your focus too narrowly. Test and take corrective action as required. Check the system / device is working properly and document your findings and corrective measures.

Should you require any assistance from the Street Crane Service Department please have available the following information:-

- The hoist serial number and details from both hoist nameplates.
- The reading on the hours-in-service meter.
- A description and the nature and extent of the fault.
- Explain under what circumstances the fault occurred.
- State your suspected cause.

6.1 GENERAL

Problem	Possible Cause	Remedy
Hoist will not operate but travel moves in wrong direction.	Wrong phase sequence to hoist or voltage supply to hoist is too low.	Correct phase sequence and supply.
Hoist unit does not operate or will not start.	No electrical power supply or not all phases are present.	Check that the power supply is correct and the equipment is switched ON.
	Phase monitoring relay not set correctly.	Check settings on relay as section 3.16.3.
	Emergency stop activated.	Release emergency stop. First ensure that the emergency stop button has not been depressed because of a fault.
	Pendant or switchgear fault.	Check condition of pushbuttons, pendant wiring and switchgear.
	After a long period out of service, the brake(s) may be stuck.	Dismantle and service the brake.
Movement of the equipment does not correspond to the symbols on the controller.	Power supply wrongly connected.	Check the phase connections to the equipment and to the relevant motor.
Hoist will not raise.	Hook is at upper limit switch position.	Lower to reset the limit. Check setting of limit.
	Attempt to lift load in excess of hoist rated capacity.	Lower load to floor. Do not apply any load greater than rated capacity of hoist.
	Motor over-temperature protection tripped.	Allow motor to cool. See fault finding guide for motors.
Hoist will not lower.	Hook is already at lower limit switch position.	Raise bottom block to reset limit. Check setting of limit
SWL cannot be lifted or loads in excess of SWL can be lifted.	Rated capacity limiter incorrectly set.	Check and adjust setting of rated capacity limiter.
Hoist does not travel when no load attached.	Wear on the wheel and/or reaction roller.	Check and adjust the setting of the reaction roller spring.
Bottom hook block and rope rotate.	Twist in the rope.	Remove the wire rope and let it hang or lay freely to remove the twist.

6.2 BRAKES

Problem	Possible Cause	Remedy
The brake will not release.	Wrong (low) voltage at the brake coil.	Check that the rectifier has the correct input and output voltage particularly at motor start up.
	Loss of supply to the brake.	Check output from rectifier and check supply from brake contactor. Check the cable for continuity.
	Max permissible air gap exceeded.	Check the air gap and adjust where necessary.
	Brake coil fault or short circuit.	Change the complete brake.
Brake overheating.	Excessive 'inching' of the drive.	Operator Training.
	High ambient temperature.	Check that the ambient temperature is within the design range. Consult Street Crane
	Voltage to the brake coil is too high.	Check function of the rectifier and supply to the rectifier.
Brake slow releasing.	Faulty rectifier or air gap too large.	Check the air gap and function of the rectifier.
Brake does not hold the load or excessive run through when stopping.	Air gap too large.	Check the working air gap.
	Brake lining worn.	Change the brake disc (rotor).
	Manual release device incorrectly set.	Adjust the hand release clearance gap.
Excessive brake lining wear.	Brake slow releasing allowing motor to run excessively before brake released.	Check operation of the brake. Check operation of the brake rectifier.
	Excessive 'inching' of the drive.	Operator Training.
Noise from the brake.	Wear of the carrier gearing caused by excessive stopping and starting.	Replace the carrier.

6.3 MOTOR UNITS

Problem	Possible Cause	Remedy
Motor will not start or motor 'hums',	Break in the connecting cable.	Check and restore the connections
	Loss of phase(s) to motor.	Check operation of switchgear.
	Fuse blown or circuit breaker tripped. Phase sequence to hoist incorrect.	Replace fuse or reset circuit breaker. Investigate reasons for the fault. Check phase sequence.
	Motor contactor does not operate, control system fault.	Check the motor contactor control circuit; rectify the fault if necessary
Motor will not start or starts with difficulty.	Voltage or frequency differs greatly from the design, especially when starting.	Ensure that the supply voltage conditions are improved. Check that the cross section of the cables matches the design
Motor hums and has high power consumption	Faulty winding or rotor catching on housing.	Motor must be repaired by service specialist.
Fuses blow or circuit breaker trips immediately.	Short circuit in the cable.	Repair the short circuit.
	Short circuit in the motor or short circuit to earth.	Motor must be repaired by service specialist.
Motor overheats and thermal protection device trips.	Overload.	Ensure the motion is free and clear of all obstructions.
	Inadequate cooling.	Ensure the cooling air passage is clear.
	Ambient temperature too high.	Check that the ambient temperature is within the design range.
	Motor connected in delta instead of star	Change connection
	Loose lead (intermittent two phase operation)	Repair the loose contact.
	Mains voltage is outside the range quoted in the technical data.	The mains voltage and the motor voltage must be within the stated limits.
	Brake slow to release or not releasing.	See brake fault finding.
	Motor being used beyond its design duty or excessive 'inching' by the operator.	Adjust the operating conditions to the design cycle otherwise consult Street Crane
Motor noisy	Bearings distorted, damaged or dirty, rotating parts vibrate.	Consult Street Crane
	Foreign matter in the cooling air passages.	Clean cooling air passages

6.4 GEARBOXES

Problem	Possible Cause	Remedy
Unusual grinding or knocking noise in gearbox when running.	Bearing damage or irregular gearing.	Check oil and condition of gears and bearings. Call customer service if noise persists.
	Polluted oil or not enough oil.	Check oil / oil level.
Oil is leaking from gearbox.	Defective seal.	Call customer service.
Oil is leaking at breather plug.	Excessive amount of oil in gearbox.	Correct the oil level
	Breather plug fitted incorrectly.	Fit breather plug correctly

7 TECHNICAL DATA

7.1 CONDITIONS OF USE

Standard ZX6 and ZX8 hoist units are designed to operate indoors, in an ambient temperature range of –10 to +40°C, at an altitude less than 1000m above sea level and in an atmosphere of normal humidity free of contamination and harmful deposits. Equipment class of protection against dust and moisture is IP55. For environments outside this range, i.e. outdoor, chemical pollution, offshore etc., consult Street Crane Co.

7.2 PROCEDURE FOR ESTIMATING REMAINING SERVICE LIFE

The following gives a procedure for estimating the remaining service life of the hoist. The hoist is classified into groups (M3 to M8) according to the desired service life and the conditions of loading (L1 to L4) to which it will be subjected.

1. Calculate or estimate the state of loading for the hoist (L?). If detailed information on the loading conditions is available, the competent person may be able to calculate the state of loading accurately by following the guidelines given in BS 466, FEM 1.001 or EN/ISO4301. If such information is not available then the competent person can estimate the state of loading using following descriptive guidelines.

L1 (light)	Mechanisms subjected very rarely to their maximum load and normally to very light loads.
L2 (moderate)	Mechanisms occasionally subjected to their maximum load and normally to rather light loads.
L3 (heavy)	Mechanisms frequently subjected to their maximum load and normally to loads of medium magnitude.
L4 (very heavy)	Mechanisms regularly subjected to their maximum load.

2. Ascertain the classification of the hoist (M?). The group classification of your equipment can be found on the equipment nameplate. See section 2.1 for nameplate and 7.3 hoist model code.
3. Knowing the state of loading and the hoist classification, determine the life expectancy of the hoist measured in hours from the following table.

State of Loading	Mechanism Classification					
	M3	M4	M5	M6	M7	M8
L1 (light)	3200	6300	12000	25000	50000	>50000
L2 (moderate)	1600	3200	6300	12000	25000	50000
L3 (heavy)	800	1600	3200	6300	12000	25000
L4 (very heavy)	400	800	1600	3200	6300	12000

The hoist is provided with a ‘hours-in-service’ meter. This meter records the actual hours run by the hoist. This reading should be compared with the expected service life as determined from the above procedure. When the meter reading approaches 95% of the expected service life, the user should consider replacing the hoist or including a major overhaul as part of the immediate maintenance procedure.

If meter reading exceeds the calculated service life, the life expectancy of the hoist has been exceeded and the hoist should be taken out of service.

Example. A hoist with a design classification of M5 and a calculated / estimated state of loading of L2 has an expected service life of 6300 hours.

7.3 HOIST MODEL CODE

The hoist model code is built up of different characters which identify individual components on the hoist. An example and break-down of each part of the code is given below.

The hoist model code complete with other information on the hoist nameplate (see 2.1) will be required when ordering replacement parts and when assessing the remaining service life of the hoist.

	HOIST CODE											CRAB CODE				SUPPLY CODE													
	ZX08	8	-	4	So	L	8	A	M5	K	6	3	-	S	R	-	LHR	00	0	2	5	-	400	50	E	1	4	*	
HOIST TYPE																													
NUMBER OF FALLS OF ROPE																													
HOIST MOTOR SPEED RATIO																													
GEARBOX																													
BARREL LENGTH																													
ROPE DIAMETER																													
BARREL PCD																													
HOIST DUTY																													
RATED CAPACITY																													
HOIST MOTOR DESIGNATION																													
HOIST BRAKE SIZE																													
No HOIST GEARBOXES																													
BARREL ARRANGEMENT																													
HOIST CONSTRUCTION																													
CRAB GAUGE																													
CRAB WHEEL TREAD WIDTH																													
TRAVERSE MOTOR SPEED																													
TRAVERSE DUTY																													
SUPPLY POTENTIAL																													
SUPPLY FREQUENCY																													
COMPLIANCE																													
CONTROL POTENTIAL																													
MAX AMBIENT TEMPERATURE																													
SPECIAL FEATURES																													

HOIST MODEL TYPE:

ZX06 or ZX08

NUMBER OF FALLS OF ROPE:

1, 2, 4, 6 or 8

HOIST MOTOR SPEED RATIO:

1 - Dual speed 10:1 (inverter)
2 - Dual speed, 20:1 ratio (inverter)
3 - Dual speed, 3:1 ratio
4 - Dual speed, 4:1 ratio
8 - Dual speed, 8:1 ratio

GEARBOX:

So (99:1 ratio – ZX6), (139:1 ratio – ZX8)
Fo (80:1 ratio – ZX6), (115:1 ratio – ZX8)
Xo (64:1 ratio – ZX6), (97:1 ratio – ZX8)
Xa (97:1 ratio – ZX8 only)
Eo (50:1 ratio – ZX6), (73:1 ratio – ZX8)
Ea (73:1 ratio – ZX8 only)

BARREL LENGTH:


N – Normal barrel
L – Long barrel
E - Extra long barrel
V – Very long barrel

ROPE DIAMETER:

8 – Ø8 Rope
3 – Ø13 Rope

BARREL PCD:	A – 251mm PCD N – 168mm PCD
CLASSIFICATION:	M1, M2, M3, M4, M5, M6, M7, M8
RATED CAPACITY:	A – 500 kg H – 2.5 t/T O – 10 t/T U – 14 T B – 630 kg I – 3.2 t P – 12.5 t/T V – 18 T C – 800 kg J – 4 t Q – 15 t/T W – 27.5 T D – 1 t/T K – 5 t/T R – 16 t Y – 6 T E – 1.25 t L – 6.3 t S – 20 t/T Z – 3 T F – 1.6 t M – 7.5 t/T T – 25 t/T G – 2 t/T N – 8 t
t = metric tonne T = short Ton (2000lbs)	
HOIST MOTOR DESIGNATION:	02 – ZX06-H2 03 – ZX06-H3 04 – ZX06-H4 05 – ZX06-H5 06 – ZX08-H6 07 – ZX08-H7 08 – ZX08-H8 09 – ZX08-H9 10 – ZX08-H10
HOIST BRAKE SIZE:	1 – Type 12/46/20/180 2 – Type 14/60/20/180 3 – Type 14/60/25/180 4 – Type 14/60/25/103 5 – Type 16/80/25/103 6 – Type 18/150/25/103 7 – Type 20/315/35/103 8 – Type 20/170/25/103 9 – Type 20/315/25/103
HOIST GEARBOXES	S – Single gearbox
BARREL ARRANGEMENT	T – Non-Rope guided (TVL) R – Rope Guided (TVL) S – Standard reeving
HOIST CONSTRUCTION:	FTM – Foot mounted LHR – Low head with reaction roller LHC – Low head with counterweight CRB – Crab with hoist parallel to beam CRE – Crab with hoist perpendicular to beam STH – Standard headroom
CRAB GAUGE:	00 – None 09 – 900mm gauge 14 – 1400mm 20 – 2000mm 26 – 2600mm 32 – 3200mm
CRAB WHEEL TREAD WIDTH:	0 – None A – 40mm B – 50mm C – 60mm D – 65mm

TRAVERSE MOTOR SPEED:	0 – No traverse drive fitted (Foot mounted) 1 – 20/2 m/min (inverter) 2 – 20/5 m/min 3 – 10/3 m/min 4 – 24.4/2.4 m/min (inverter)
TRAVERSE DUTY:	5 – M5 7 – M7
SUPPLY POTENTIAL:	230 - 230V (±6%) AC 380 - 380V (±10%) AC 400 - 380V ±6% - 415V±6% AC 460 - 460V (±6%) AC 480 - 480V (±6%) AC 575 - 575V (±6%) AC
SUPPLY FREQUENCY:	50 - 50Hz (±1%) 60 - 60Hz (±1%)
COMPLIANCE:	E – European directives (CE) U – North America N – Canada (CSA) Imperial D – Canada (CSA) Metric C – China (CCL) B - Brazil
CONTROL POTENTIAL:	4 - 48V AC 1 - 110V AC
MAX AMBIENT TEMPERATURE:	4 - 40°C 5 - 50°C
SPECIAL FEATURES:	X – Consult Street Crane. V – Galvanising environment A - Aggressive environment

NAMEPLATE MAJOR REVISION REFERENCE DETAILS	
	Revision (Rv-I shown)
Revision Rv-1 for details of changes refer to:- Section 3.6 SETTING THE UPPER AND LOWER LIMIT SWITCHES Section 5.8.3 Fitting the Rope Guide	

7.4 NOISE LEVELS

The mean sound pressure level was measured in accordance with BS EN ISO 3744:1994. For measurement purposes the hoist unit was operated under normal loading conditions for a full operating cycle.

Distance from Sound Source (metres)	Mean Sound Level dB(A)	
	ZX6	ZX8
1	80	80
2	77	77
4	74	74
8	61	61
16	68	68




Figure 60 – Sound Pressure Levels

The sound pressure level is reduced by approx. 3dB(A) each time the distance from the sound source is doubled.

7.5 HOIST MOTOR DATA

7.5.1 ZX06 Hoist Motor Data – 3:1 SPEED RATIO - 400V, 3Ph, 50Hz

Example from hoist model code: ZX064 - 3EoN8NM5K031-SR - LHR0002 - 40050E14X

Hoist Motor	Speed Ratio	Motor Mass (kg)	Motor Ratings at 400V(±10%) 50Hz							
			BS Class	CDF	S/h	Power	FLC	LRC	Main Fuse	Cos φ
				%		kW	A	A		
03	3	26 (57lb)	M3	17/8	50/100	3.7/1.2	8.24/4.24	24/10.5	16A	0.9/0.69
			M4	20/10	60/120	3.4/1.1	7.68/3.99			0.9/0.66
			M5	27/13	80/160	3.1/1.0	6.87/3.81			0.89/0.62
			M6	34/17	100/200	2.8/0.9	6.07/3.64			0.89/0.57
			M7	40/20	100/200	2.5/0.8	5.36/3.53			0.88/0.54
04	3	30 (66lb)	M3	17/8	50/100	4.7/1.6	12.0/5.0	39/13	20A	0.82/0.68
			M4	20/10	60/120	4.3/1.4	10.6/4.4			0.81/0.65
			M5	27/13	80/160	3.9/1.3	9.8/4.1			0.79/0.62
			M6	34/17	100/200	3.5/1.2	9.0/3.9			0.78/0.59
			M7	40/20	100/200	3.1/1.0	8.4/3.6			0.75/0.53
05	3	53 (117lb)	M3	17/8	50/100	7.8/2.6	17.5/7.5	61/23	25A	0.85/0.66
			M4	20/10	60/120	7.1/2.4	16.2/7.0			0.84/0.64
			M5	27/13	80/160	6.5/2.1	14.8/6.6			0.83/0.6
			M6	34/17	100/200	5.8/1.9	13.5/6.4			0.82/0.57
			M7	40/20	100/200	5.2/1.7	12.4/6.0			0.8/0.53

7.5.2 ZX08 Hoist Motor Data – 4:1 SPEED RATIO - 400V, 3Ph, 50Hz

Example from hoist model code: ZX084 - 4EoN3AM6K071-SR - LHR0002 - 40050E14X

Hoist Motor	Speed Ratio	Motor Mass (kg)	Motor Ratings at 400V(±10%) 50Hz							
			BS Class	CDF	S/h	Power	FLC	LRC	Main Fuse	Cos φ
				%		kW	A	A		
06	4	50 (110lb)	M3	17/8	50/100	9.1/2.3	21.0/8.8	61/17.5	32A	0.87/0.59
			M4	20/10	60/120	8.4/2.1	18.9/8.3			0.87/0.56
			M5	27/13	80/160	7.6/1.9	16.7/8.0			0.87/0.54
			M6	34/17	100/200	6.8/1.7	14.7/7.7			0.84/0.51
			M7	40/20	100/200	6.1/1.5	13.3/7.5			0.83/0.46
07	4	58 (128lb)	M3	17/8	50/100	11.2/2.8	26.0/11.5	72/24	40A	0.85/0.6
			M4	20/10	60/120	10.1/2.5	23.0/11.4			0.84/0.6
			M5	27/13	80/160	9.2/2.3	20.0/10.8			0.83/0.55
			M6	34/17	100/200	8.3/2.1	18.5/10.5			0.83/0.52
			M7	40/20	100/200	7.4/1.8	16.3/10.2			0.81/0.47
08	4	98 (216lb)	M3	17/8	50/100	13.0/3.2	27.0/11.0	129/29	40A	0.83/0.53
			M4	20/10	60/120	12.0/3.0	24.5/10.6			0.83/0.52
			M5	27/13	80/160	10.8/2.7	22.0/10.2			0.81/0.49
			M6	34/17	100/200	9.7/2.4	20.3/9.8			0.8/0.45
			M7	40/20	100/200	8.6/2.2	19.7/9.6			0.79/0.42
10	4	120 (265lb)	M3	17/8	50/100	19.2/4.8	46.0/17.5	240/40	TBA	0.75/0.89
			M4	20/10	60/120	17.6/4.4	46.0/15.5			0.7/0.56
			M5	27/13	80/160	16.0/4.0	45.0/14.7			0.67/0.53
			M6	34/17	100/200	14.4/3.6	44.0/14.0			0.64/0.5
			M7	40/20	100/200	12.8/3.2	42.0/13.7			0.6/0.46

7.5.3 ZX06 Hoist Motor Data – 3:1 SPEED RATIO – 460V, 3Ph, 60Hz

Example from hoist model code: ZX064 - 3EoN8N**M4**K041-SR - LHR0002 – 46060UE14X

Hoist Motor	Speed Ratio	Motor Mass (kg)	Motor Ratings at 460V(±6%) 60Hz							
			BS Class	CDF %	S/h	Power	FLC	LRC	Main Fuse	Cos φ
						kW	A	A		
03	3	26 (57lb)	M3	17/8	50/100	4.4/1.4	8.24/4.24	24/10.5	16A (15A)	0.9/0.69
			M4	20/10	60/120	4.1/1.3	7.68/3.99			0.9/0.66
			M5	27/13	80/160	3.7/1.2	6.87/3.81			0.89/0.62
			M6	34/17	100/200	3.4/1.1	6.07/3.64			0.89/0.57
			M7	40/20	100/200	3.0/1.0	5.36/3.53			0.88/0.54
04	3	30 (66lb)	M3	17/8	50/100	5.6/1.9	12.0/5.0	39/13	20A (20A)	0.82/0.68
			M4	20/10	60/120	5.2/1.7	10.6/4.4			0.81/0.65
			M5	27/13	80/160	4.7/1.6	9.8/4.1			0.79/0.62
			M6	34/17	100/200	4.2/1.4	9.0/3.9			0.78/0.59
			M7	40/20	100/200	3.7/1.2	8.4/3.6			0.75/0.53
05	3	53 (117lb)	M3	17/8	50/100	9.4/3.1	17.5/7.5	61/23	20A (25A)	0.85/0.66
			M4	20/10	60/120	8.5/2.9	16.2/7.0			0.84/0.64
			M5	27/13	80/160	7.8/2.5	14.8/6.6			0.83/0.6
			M6	34/17	100/200	7.0/2.3	13.5/6.4			0.82/0.57
			M7	40/20	100/200	6.2/2.0	12.4/6.0			0.8/0.53

7.5.4 ZX08 Hoist Motor Data – 4:1 SPEED RATIO - 460V, 3Ph, 60Hz

Example from hoist model code: ZX084 - 4EoN3A**M6**K071 -SR - LHR0002 – 46060U14X

Hoist Motor	Speed Ratio	Motor Mass (kg)	Motor Ratings at 460V(±6%) 60Hz							
			BS Class	CDF %	S/h	Power	FLC	LRC	Main Fuse	Cos φ
						kW	A	A		
06	4	50 (110lb)	M3	17/8	50/100	10.9/2.8	21.0/8.8	61/17.5	32A (30A)	0.87/0.59
			M4	20/10	60/120	10.1/2.5	18.9/8.3			0.87/0.56
			M5	27/13	80/160	9.1/2.3	16.7/8.0			0.87/0.54
			M6	34/17	100/200	8.2/2.0	14.7/7.7			0.84/0.51
			M7	40/20	100/200	7.3/1.8	13.3/7.5			0.83/0.46
07	4	58 (128lb)	M3	17/8	50/100	13.4/3.4	26.0/11.5	72/24	40A (35A)	0.85/0.6
			M4	20/10	60/120	12.1/3	23.0/11.4			0.84/0.6
			M5	27/13	80/160	11/2.8	20.0/10.8			0.83/0.55
			M6	34/17	100/200	10/2.5	18.5/10.5			0.83/0.52
			M7	40/20	100/200	8.9/2.2	16.3/10.2			0.81/0.47
08	4	98 (216lb)	M3	17/8	50/100	15.6/3.8	27.0/11.0	129/29	40A (35A)	0.83/0.53
			M4	20/10	60/120	14.4/3.6	24.5/10.6			0.83/0.52
			M5	27/13	80/160	13.0/3.2	22.0/10.2			0.81/0.49
			M6	34/17	100/200	11.6/2.9	20.3/9.8			0.8/0.45
			M7	40/20	100/200	10.3/2.6	19.7/9.6			0.79/0.42
10	4	120 (265lb)	M3	17/8	50/100	23.0/5.8	46.0/17.5	240/40	TBA	0.75/0.89
			M4	20/10	60/120	21.1/5.3	46.0/15.5			0.7/0.56
			M5	27/13	80/160	19.2/4.8	45.0/14.7			0.67/0.53
			M6	34/17	100/200	17.3/4.3	44.0/14.0			0.64/0.5
			M7	40/20	100/200	15.4/3.8	42.0/13.7			0.6/0.46

7.5.5 ZX06 Hoist Motor Data – 3:1 SPEED RATIO - 575V, 3Ph, 60Hz

Example from hoist model code: ZX064 - 3EoN8N**M5K04**1-SR- LHR0002 – 57560N14X

Hoist Motor	Speed Ratio	Motor Mass (kg)	Motor Ratings at 575V(±6%) 60Hz							
			BS Class	CDF %	S/h	Power	FLC	LRC	Main Fuse	Cos φ
						kW	A	A		
03	3	26 (57lb)	M3	17/8	50/100	4.4/1.4	6.8/3.69	23/10.3	15A	0.85/0.65
			M4	20/10	60/120	4.1/1.3	6.08/3.53			0.84/0.62
			M5	27/13	80/160	3.7/1.2	5.41/3.45			0.83/0.59
			M6	34/17	100/200	3.3/1.1	4.88/3.37			0.82/0.56
			M7	40/20	100/200	3.0/1.0	4.46/3.3			0.80/0.53
04	3	30 (66lb)	M3	17/8	50/100	5.6/1.9	10.2/3.6	22/10.4	15A	0.87/0.75
			M4	20/10	60/120	5.1/1.7	9.4/3.5			0.87/0.72
			M5	27/13	80/160	4.7/1.6	8.2/4.1			0.87/0.69
			M6	34/17	100/200	4.2/1.4	7.1/3.1			0.87/0.65
			M7	40/20	100/200	3.7/1.3	6.2/2.9			0.86/0.62
05	3	53 (117lb)	M3	17/8	50/100	9.3/3.1	13.0/5.3	71/24	20A	0.90/0.73
			M4	20/10	60/120	8.5/2.8	12.0/4.9			0.90/0.70
			M5	27/13	80/160	7.7/2.6	10.7/4.7			0.89/0.69
			M6	34/17	100/200	7.0/2.2	9.9/4.4			0.88/0.66
			M7	40/20	100/200	6.2/2.1	8.9/4.0			0.87/0.63

7.5.6 ZX08 Hoist Motor Data – 4:1 SPEED RATIO - 575V, 3Ph, 60Hz

Example from hoist model code: ZX084 - 4EoN3A**M6K07**1-SR - LHR0002 – 57560N14X

Hoist Motor	Speed Ratio	Motor Mass (kg)	Motor Ratings at 575V(±6%) 60Hz							
			BS Class	CDF %	S/h	Power	FLC	LRC	Main Fuse	Cos φ
						kW	A	A		
06	4	50 (110lb)	M3	17/8	50/100	10.9/2.7	18.3/8.0	62/17	25A	0.77/0.55
			M4	20/10	60/120	10.0/2.5	17.0/7.8			0.77/0.53
			M5	27/13	80/160	9.1/2.3	15.8/7.6			0.75/0.50
			M6	34/17	100/200	8.2/2.0	14.8/7.3			0.72/0.46
			M7	40/20	100/200	7.3/1.8	13.8/7.2			0.69/0.44
07	4	58 (128lb)	M3	17/8	50/100	13.4/3.4	20.2/9.5	77/20.2	25A	0.87/0.55
			M4	20/10	60/120	12.1/3.0	18.5/9.2			0.86/0.52
			M5	27/13	80/160	11.0/2.8	16.9/9.0			0.85/0.50
			M6	34/17	100/200	10.0/2.5	15.3/8.8			0.84/0.47
			M7	40/20	100/200	8.9/2.2	13.9/8.8			0.82/0.44
08	4	98 (216lb)	M3	17/8	50/100	15.6/3.8	24.7/10.0	115/25	30A	0.85/0.57
			M4	20/10	60/120	14.4/3.6	23.0/9.7			0.85/0.54
			M5	27/13	80/160	13.0/3.2	20.9/9.2			0.85/0.51
			M6	34/17	100/200	11.6/2.9	19.4/8.9			0.84/0.49
			M7	40/20	100/200	10.3/2.6	17.6/8.7			0.83/0.47
10	4	120 (265lb)	M3	17/8	50/100	23.0/5.8	33.3/14.9	181/39	40A	0.84/0.53
			M4	20/10	60/120	21.1/5.3	31.0/14.3			0.85/0.51
			M5	27/13	80/160	19.2/4.8	28.1/13.8			0.84/0.48
			M6	34/17	100/200	17.3/4.3	26.6/13.6			0.84/0.47
			M7	40/20	100/200	15.4/3.8	24.4/13.1			0.83/0.42

7.5.7 ZX06 Hoist Motor Data – 3:1 SPEED RATIO - 380(±10%)V, 3Ph, 60Hz

Example from hoist model code : ZX064 - 3EoN8NM5K031 - LHR0002 - 38060E14X

Hoist Motor	Speed Ratio	Motor Mass (kg)	Motor Ratings at 380V(±10%) 60Hz							
			BS Class	CDF %	S/h	Power kW	FLC A	LRC A	Main Fuse	Cos φ
03	3	26 (57lb)	M3	17/8	50/100	3.7/1.2	9.1/5.24	29/16.5	16A	0.87/0.55
			M4	20/10	60/120	3.4/1.1	8.1/5.14			0.86/0.52
			M5	27/13	80/160	3.1/1.0	7.4/5.07			0.85/0.49
			M6	34/17	100/200	2.8/0.9	6.7/5.0			0.83/0.46
			M7	40/20	100/200	2.5/0.8	6.1/4.95			0.82/0.43
04	3	30 (66lb)	M3	17/8	50/100	4.7/1.6	12.8/4.8	52/19.4	20A	0.76/0.68
			M4	20/10	60/120	4.3/1.4	11.7/4.6			0.75/0.66
			M5	27/13	80/160	3.9/1.3	10.8/4.4			0.71/0.63
			M6	34/17	100/200	3.5/1.2	10.5/4.3			0.70/0.61
			M7	40/20	100/200	3.1/1.0	9.8/4.05			0.67/0.55
05	3	53 (117lb)	M3	17/8	50/100	7.8/2.6	18.5/8.5	87/29	40A	0.83/0.6
			M4	20/10	60/120	7.1/2.4	17.2/8.1			0.81/0.58
			M5	27/13	80/160	6.5/2.1	15.9/7.8			0.80/0.54
			M6	34/17	100/200	5.8/1.9	14.7/7.6			0.77/0.51
			M7	40/20	100/200	5.2/1.7	13.8/7.3			0.75/0.47

7.5.8 ZX08 Hoist Motor Data – 4:1 SPEED RATIO - 380(±10%)V, 3Ph, 60Hz

Example from hoist model code : ZX084 - 4EoN3AM6K071 - LHR0002 - 38060E14X

Hoist Motor	Speed Ratio	Motor Mass (kg)	Motor Ratings at 380V(±10%) 60Hz								
			BS Class	CDF %	S/h	Power kW	FLC A	LRC A	Main Fuse	Cos φ	
06	4	50 (110lb)	M3	17/8	50/100	9.1/2.3	22.2/10.9	86/25.9	40A	0.86/0.49	
			M4	20/10	60/120	8.4/2.1	20.1/10.6			0.80/0.48	
			M5	27/13	80/160	7.6/1.9	18.9/10.2			0.78/0.42	
			M6	34/17	100/200	6.8/1.7	16.6/10.2			0.80/0.40	
			M7	40/20	100/200	6.1/1.5	15.4/10.2			0.76/0.37	
07	4	58 (128lb)	M3	17/8	50/100	11.2/2.8	25.7/12.1	100/28	40A	0.83/0.53	
			M4	20/10	60/120	10.1/2.5	23.6/11.7			0.82/0.50	
			M5	27/13	80/160	9.2/2.3	21.7/11.4			0.80/0.48	
			M6	34/17	100/200	8.3/2.1	20.3/11.2			0.79/0.45	
			M7	40/20	100/200	7.4/1.8	18.8/11.0			0.76/0.41	
08	4	98 (216lb)	M3	17/8	50/100	13.0/3.2	32.7/16.6	167/50	63A	0.84/0.44	
			M4	20/10	60/120	12.0/3.0	31.0/16.4			0.83/0.42	
			M5	27/13	80/160	10.8/2.7	27.9/16.2			0.83/0.40	
			M6	34/17	100/200	9.7/2.4	26.4/16.0			0.82/0.37	
			M7	40/20	100/200	8.6/2.2	24.8/15.8			0.80/0.35	
10	4	120 (265lb)	M3	17/8	50/100	19.2/4.8		TBA	TBA		
			M4	20/10	60/120	17.6/4.4					
			M5	27/13	80/160	16.0/4.0	TBA			TBA	TBA
			M6	34/17	100/200	14.4/3.6					
			M7	40/20	100/200	12.8/3.2					

CDF = Cyclic duration factor (%ED), S/h = Motor starts per hour, FLC = Motor full load current, LRC = Locked rotor current, Cos φ = Power factor.

The motors are designed for the voltage range shown. The hoist motor 2 pole starting current and the rated current of the travel motor are used in selecting the recommended main fuse size.

Main fuses are type gL/gG. Fuse size in (parentheses) are for class 'J' fuses for CSA (CSA-22.2) approved installations.

7.5.9 ZX Dual Wound 'WU' Type Traverse Motor Data- 400V 50Hz

Traverse Motor Frame	Motor Mass (kg)	Motor Ratings at 400V(±10%) 50Hz						
		Classification	CDF	S/h	Power	FLC	LRC	Cos φ
			%		kW	A	A	
80SWU/2-8	12 (26lb)	M3/M4/M5	20/10	80/160	0.55/0.13	1.61/0.79	4.25/1.17	0.77/0.57
		M6	27/13	100/200	0.45/0.1	1.37/0.73		
		M7	40/20	120/240	0.37/0.09	1.32/0.73		
ABOVE MOTOR IS USED ON THE FOLLOWING HOIST MODELS:-								
ZX064 - xxxxxxxxxxx - LHRxxx2 - 40050xxxx								
ZX064 - xxxxxxxxxxx - CRBxxx2 - 40050xxxx								
Traverse Motor Frame	Motor Mass (kg)	Motor Ratings at 400V(±10%) 50Hz						
		Classification	CDF	S/h	Power	FLC	LRC	Cos φ
			%		kW	A	A	
80LWU/2-8	13 (29lb)	M3/M4/M5	20/10	80/160	0.60/0.13	1.63/0.74	4.85/1.18	0.9/0.7
		M6	27/13	100/200	0.55/0.13	1.47/0.74		
		M7	40/20	120/240	0.55/0.13	1.47/0.74		
ABOVE MOTOR IS USED ON THE FOLLOWING HOIST MODELS:-								
ZX084 - xxxxxxxxxxx - LHRxxx2 - 40050xxxx								
ZX084 - xxxxxxxxxxx - CRBxxx2 - 40050xxxx								
ZX084 - xxxxxxxxxxx - CRExxx2 - 40050xxxx								
ZX088 - xxxxxxxxxxx - LHRxxx2 - 40050xxxx								
ZX088 - xxxxxxxxxxx - CRBxxx2 - 40050xxxx								
ZX088 - xxxxxxxxxxx - CRExxx2 - 40050xxxx								

7.5.10 ZX Dual Wound 'WU' Type Traverse Motor Data- 460V 60Hz

Traverse Motor Frame	Motor Mass (kg)	Motor Ratings at 460V(±10%) 60Hz						
		Classification	CDF	S/h	Power	FLC	LRC	Cos φ
			%		kW	A	A	
80SWU/2-8	12 (26lb)	M3/M4/M5	20/10	80/160	0.63/0.14	1.5/0.73	4.12/1.14	0.77/0.57
		M6	27/13	100/200	0.52/0.115	1.33/0.71		
		M7	40/20	120/240	0.42/0.10	1.22/0.69		
ABOVE MOTOR IS USED ON THE FOLLOWING HOIST MODELS:-								
ZX064 - xxxxxxxxxxx - LHRxxx2 - 46060xxxx								
ZX064 - xxxxxxxxxxx - CRBxxx2 - 46060xxxx								
Traverse Motor Frame	Motor Mass (kg)	Motor Ratings at 460V(±10%) 60Hz						
		Classification	CDF	S/h	Power	FLC	LRC	Cos φ
			%		kW	A	A	
80LWU/2-8	13 (29lb)	M3/M4/M5	20/10	80/160	0.65/0.15	1.39/0.68	4.52/1.09	0.9/0.7
		M6	27/13	100/200	0.63/0.15	1.37/0.68		
		M7	40/20	120/240	0.63/0.15	1.37/0.68		
ABOVE MOTOR IS USED ON THE FOLLOWING HOIST MODELS:-								
ZX084 - xxxxxxxxxxx - LHRxxx2 - 46060xxxx								
ZX084 - xxxxxxxxxxx - CRBxxx2 - 46060xxxx								
ZX084 - xxxxxxxxxxx - CRExxx2 - 46060xxxx								
ZX088 - xxxxxxxxxxx - LHRxxx2 - 46060xxxx								
ZX088 - xxxxxxxxxxx - CRBxxx2 - 46060xxxx								
ZX088 - xxxxxxxxxxx - CRExxx2 - 46060xxxx								

7.5.11 ZX Dual Wound 'WU' Type Traverse Motor Data- 575V 60Hz

Traverse Motor Frame	Motor Mass (kg)	Motor Ratings at 575V(±10%) 60Hz						
		Classification	CDF	S/h	Power	FLC	LRC	Cos φ
			%		kW	A	A	
80SWU/2-8	12 (26lb)	M3/M4/M5	20/10	80/160	0.63/0.14	1.31/0.64	3.09/0.92	0.77/0.57
		M6	27/13	100/200	0.52/0.115	1.21/0.62		
		M7	40/20	120/240	0.42/0.10	1.12/0.61		
ABOVE MOTOR IS USED ON THE FOLLOWING HOIST MODELS:-								
ZX064 - xxxxxxxxxxxx - LHRxxx2 - 57560xxxx								
ZX064 - xxxxxxxxxxxx - CRBxxx2 - 57560xxxx								
Traverse Motor Frame	Motor Mass (kg)	Motor Ratings at 575V(±10%) 60Hz						
		Classification	CDF	S/h	Power	FLC	LRC	Cos φ
			%		kW	A	A	
80LWU/2-8	13 (29lb)	M3/M4/M5	20/10	80/160	0.65/0.15	1.2/0.58	5.28/1.17	0.88/0.69
		M6	27/13	100/200	0.63/0.15	1.16/0.58		
		M7	40/20	120/240	0.63/0.15	1.16/0.58		
ABOVE MOTOR IS USED ON THE FOLLOWING HOIST MODELS:-								
ZX084 - xxxxxxxxxxxx - LHRxxx2 - 57560xxxx								
ZX084 - xxxxxxxxxxxx - CRBxxx2 - 57560xxxx								
ZX084 - xxxxxxxxxxxx - CRExxx2 - 57560xxxx								
ZX088 - xxxxxxxxxxxx - LHRxxx2 - 57560xxxx								
ZX088 - xxxxxxxxxxxx - CRBxxx2 - 57560xxxx								
ZX088 - xxxxxxxxxxxx - CRExxx2 - 57560xxxx								

7.5.12 ZX Dual Wound 'WU' Type Traverse Motor Data- 380V 60Hz

Traverse Motor Frame	Motor Mass (kg)	Motor Ratings at 380V(±10%) 60Hz						
		Classification	CDF	S/h	Power	FLC	LRC	Cos φ
			%		kW	A	A	
80SWU/2-8	12 (26lb)	M3/M4/M5	20/10	80/160	0.63/0.14	2.50/1.04	7.56/1.62	0.77/0.57
		M6	27/13	100/200	0.52/0.115	2.44/1.01		
		M7	40/20	120/240	0.42/0.10	2.37/1.0		
ABOVE MOTOR IS USED ON THE FOLLOWING HOIST MODELS:-								
ZX064 - xxxxxxxxxxx - LHRxxx2 - 38060xxxx								
ZX064 - xxxxxxxxxxx - CRBxxx2 - 38060xxxx								
Traverse Motor Frame	Motor Mass (kg)	Motor Ratings at 380V(±10%) 60Hz						
		Classification	CDF	S/h	Power	FLC	LRC	Cos φ
			%		kW	A	A	
80LWU/2-8	13 (29lb)	M3/M4/M5	20/10	80/160	0.65/0.15	1.69/0.82	5.45/1.31	0.9/0.7
		M6	27/13	100/200	0.63/0.15	1.65/0.82		
		M7	40/20	120/240	0.63/0.15	1.65/0.82		
ABOVE MOTOR IS USED ON THE FOLLOWING HOIST MODELS:-								
ZX084 - xxxxxxxxxxx - LHRxxx2 - 38060xxxx								
ZX084 - xxxxxxxxxxx - CRBxxx2 - 38060xxxx								
ZX084 - xxxxxxxxxxx - CRExxx2 - 38060xxxx								
ZX088 - xxxxxxxxxxx - LHRxxx2 - 38060xxxx								
ZX088 - xxxxxxxxxxx - CRBxxx2 - 38060xxxx								
ZX088 - xxxxxxxxxxx - CRExxx2 - 38060xxxx								

7.5.13 ZX Traverse Motor Data for use with Frequency Inverter

Traverse Motor Frame	Motor Mass (kg)	Motor Ratings at 400V(±10%) 50Hz						
		Classification	CDF	S/h	Power	FLC	LRC	Cos φ
			%		kW	A	A	
71 S/4	8.4 (19lb)	N/A	N/A	N/A	0.25	0.76	N/A	0.77
ABOVE MOTOR IS USED ON THE FOLLOWING HOIST MODELS:-								
ZX064 - XXXXXXXXXXXX - LHRxxx1 - XXXXXXXXXXXX								
ZX064 - XXXXXXXXXXXX - CRBxxx1 - XXXXXXXXXXXX								
Traverse Motor Frame	Motor Mass (kg)	Motor Ratings at 400V(±10%) 50Hz						
		Classification	CDF	S/h	Power	FLC	LRC	Cos φ
			%		kW	A	A	
71 L/4	9.3 (21lb)	N/A	N/A	N/A	0.37	1.09	N/A	0.71
ABOVE MOTOR IS USED ON THE FOLLOWING HOIST MODELS:-								
ZX064 - XXXXXXXXXXXX - LHRxxx4 - XXXXXXXXXXXX								
ZX064 - XXXXXXXXXXXX - CRBxxx4 - XXXXXXXXXXXX								
Traverse Motor Frame	Motor Mass (kg)	Motor Ratings at 400V(±10%) 50Hz						
		Classification	CDF	S/h	Power	FLC	LRC	Cos φ
			%		kW	A	A	
80 S/4	12 (26lb)	N/A	N/A	N/A	0.55	1.52	N/A	0.73
ABOVE MOTOR IS USED ON THE FOLLOWING HOIST MODELS:-								
ZX084 - XXXXXXXXXXXX - LHRxxx1 - XXXXXXXXXXXX								
ZX084 - XXXXXXXXXXXX - CRBxxx1 - XXXXXXXXXXXX								
ZX084 - XXXXXXXXXXXX - CRExxx1 - XXXXXXXXXXXX								
ZX088 - XXXXXXXXXXXX - CRBxxx1 - XXXXXXXXXXXX								
ZX088 - XXXXXXXXXXXX - CRExxx1 - XXXXXXXXXXXX								
ZX088 - XXXXXXXXXXXX - LHRxxx1 - XXXXXXXXXXXX								
ZX084 - XXXXXXXXXXXX - LHRxxx4 - XXXXXXXXXXXX								
ZX084 - XXXXXXXXXXXX - CRBxxx4 - XXXXXXXXXXXX								
ZX084 - XXXXXXXXXXXX - CRExxx4 - XXXXXXXXXXXX								
ZX088 - XXXXXXXXXXXX - CRBxxx4 - XXXXXXXXXXXX								
ZX088 - XXXXXXXXXXXX - CRExxx4 - XXXXXXXXXXXX								
ZX088 - XXXXXXXXXXXX - LHRxxx4 - XXXXXXXXXXXX								
Traverse Motor Frame	Motor Mass (kg)	Motor Ratings at 400V(±10%) 50Hz						
		Classification	CDF	S/h	Power	FLC	LRC	Cos φ
			%		kW	A	A	
80 L/4	13 (29lb)	N/A	N/A	N/A	0.75	2.10	N/A	0.74
ABOVE MOTOR IS USED ON THE FOLLOWING HOIST MODELS:-								
ZX084 - XXXXXXXXXXXX - LHRxxx4 - XXXXXXXXXXXX								
ZX088 - XXXXXXXXXXXX - LHRxxx4 - XXXXXXXXXXXX								
ZX088 - XXXXXXXXXXXX - CRBxxx4 - XXXXXXXXXXXX								
ZX084 - XXXXXXXXXXXX - CRBxxx4 - XXXXXXXXXXXX								

NOTE:

Street Crane policy is to where possible run motors at 87 Hz full speed from the inverter connected in Delta. The inverter will be common to all voltages as a transformer will be used, therefore CT inverter motors will be wound to 400V 50 Hz base and will be common for main supply voltages. IMPORTANT please contact Street Crane for inverter parameters if required.

7.6 CABLE CROSS SECTION AND LENGTH OF SUPPLY CABLE

Hoist Motor	Monorail Installation						Crane Installation					
	Flexible PVC sheathed festoon cable in free air from point of supply to hoist.						Flexible PVC sheathed festoon cable in free air along crane bridge to hoist.					
	400V(±10%) 50Hz		460V(±6%) 60Hz		575V (±6%) 60Hz		400V(±10%) 50Hz		460V(±6%) 60Hz		575V (±6%) 60Hz	
	CSA (mm ²)	Max Length (m)	CSA (mm ²)	Max Length (m)	CSA (mm ²)	Max Length (m)	CSA (mm ²)	Max Length (m)	CSA (mm ²)	Max Length (m)	CSA (mm ²)	Max Length (m)
03	2.5	60	2.5	69	2.5	87	2.5	22	2.5	26	2.5	33
	-	-	-	-	-	-	4.0	35	4.0	41	4.0	53
	-	-	-	-	-	-	6.0	53	6.0	62	6.0	79
04	2.5	36	2.5	41	2.5	53	2.5	13	2.5	15	2.5	19
	4.0	57	4.0	66	4.0	83	4.0	20	4.0	24	4.0	31
	-	-	-	-	-	-	6.0	30	6.0	35	6.0	46
	-	-	-	-	-	-	10.0	51	10.0	60	10.0	77
05	2.5	25	2.5	29	2.5	37	2.5	9	2.5	11	2.5	14
	4.0	40	4.0	46	4.0	59	4.0	14	4.0	17	4.0	22
	6.0	60	6.0	69	6.0	88	6.0	21	6.0	25	6.0	33
	-	-	-	-	-	-	10.0	36	10.0	43	10.0	56
06	4.0	38	4.0	44	4.0	56	4.0	13	4.0	16	4.0	21
	6.0	56	6.0	65	6.0	83	6.0	20	6.0	24	6.0	31
	-	-	-	-	-	-	10.0	34	10.0	40	10.0	52
	-	-	-	-	-	-	16.0	55	16.0	64	16.0	83
07	6.0	51	6.0	59	6.0	74	6.0	19	6.0	22	6.0	28
	10.0	86	10.0	99	10.0	125	10.0	32	10.0	37	10.0	47
	-	-	-	-	-	-	16.0	50	16.0	59	16.0	75
08	6.0	34	6.0	39	6.0	50	6.0	12	6.0	14	6.0	18
	10.0	57	10.0	66	10.0	84	10.0	20	10.0	24	10.0	31
	-	-	-	-	-	-	16.0	32	16.0	38	16.0	49
10					10.0	46					10.0	17
	TBA				16.0	74	TBA				16.0	28

CSA is the recommended conductor cross sectional area for the cable length stated.

Max supply cable length for monorail installation assumes 5% voltage loss from point of supply to hoist.


Max supply cable length for crane installation assumes 2% voltage loss along crane bridge to hoist (allowing 3% losses in supply to crane).

For 380V cable data consult Street Crane.

7.7 RESULTS OF PERIODIC TESTS

HOIST SERIAL No			Page No	
Date	Defects found	Remedial actions	Estimated remaining service life (see 7.2)	Signature

HOIST SERIAL No.			Page No.
Date	Hours In Service Reading	Part description / Reason for replacement	Signature



www.streetcrane.co.uk

Street

Street Crane Company Limited, Chapel-en-le-Frith, High Peak SK23 0PH, UK
email: admin@streetcrane.co.uk web: www.streetcrane.co.uk
Telephone: +44 (0) 1298 812456



Certificate No. FM13635

