

วงจรนี้เป็นวงจรวิทยุ แบบ DSP (Digital Signal Processing) ที่ใช้การปรับเลือก สถานีโดยการปรับเปลี่ยนแรงคัน ซึ่งจะต่างจากการปรับเลือกสถานีแบบเคิมๆ ที่ใช้ตัว เก็บประจุแบบปรับคาได้ เป็นตัวปรับเลือกสถานี ซึ่งจะมีปัญหาเมื่อใช้งาน ไปซักระยะ หนึ่ง วงจรนี้ใช้ใอซีควบคุมเพียงตัวเดียวก็สามารถทำหน้าที่เป็นวิทยุ AM และ FM ได้ จึงทำให้วงจรสามารถสร้างและประกอบได้งายสำหรับมือใหม่อีกด้วย

ข้อมูลทางด้านเทคนิค

- ใช้แหล่งจ่ายไฟบนาด 4.5-6 โวลท์ดีซี
- กินกระแสสูงสุดประมาณ 200 มิลลิแอมป์
- มีสวิตซเ์ลือกการรับสถานีแบบ AM หรือ FM ได้
- ใช้ตัวตานทานแบบปรับคาใด ในการปรับเลือกสถานี
- มีตัวตานทานแบบปรับค่าได้ในการปรับลดเร่งเสียง
- ใช[้]ไอซีเครื่องรับวิทยแบบ DSP ซึ่งมีภาครับและตัวควบคมการทำงานภายในตัว
- มีภาคขยายเสียง ขนาด 0.6 วัตต ์ที่ 6 โวลท์
- ขนาดแผนวงจรพิมพ์ : 3.28 x 2.27 นิ้ว

การทำงานของวงจร

การทำงานของวงจรนี้ จะแบ่งออกเป็น 2 ส่วนใหญ่ๆ ควยกัน ได้แก่ ภาครับ สัญญาณวิทยุและภาคขยายเสียง

ส่วนที่หนึ่ง ภาครับสัญญาณวิทยุ หัวใจของวงจรนี้จะอยู่ที่ IC1 ซึ่งเป็นใอซี ควบคุมแบบ DSP โดยมีขาหลักๆ ดังนี้

- ขา 1 และขา 2 จะถูกต่อกับสวิตซ์ SW1 ทำหน้าที่เป็นตัวเลือกรับสถานีวิทยุ แบบ AM หรือ FM
- ขา 4 จะถูกต[่]อกับ VR1 ทำหน้าที่เป็นขาควบคุมการปรับหาสถานีวิทยุ
- ขา 16 เป็นขาส่งสัญญาณเสียงออก
- ขา 12 และขา 13 จะถูกต่อกับแร่คริสตอล 32.768KHz เพื่อผลิตความถี่ให้กับตัว
- ขา 8 เป็นขา RF อินพทของภาครับวิทยแบบ AM
- ขา 6 เป็นขา RF อินพุทของภาครับวิทยุแบบ FM โดยมีตัวทรานซิสเตอร์ TR1 เป็นตัวขยายสัญญาณก่อนจะเข้าขานี้

ส่วนที่สอง ภาคขยายเสียง จะใช้ตัว IC2 เป็นตัวขยายเสียง โคยการทำงานจะเริ่ม จาก เมื่อสัญญาณเสียงจากขา 16 ของ IC1 มาเข้าที่ขา 7 ของ IC2 โคยผ่านวอลลุ่ม VR2 ซึ่งทำหน้าที่เป็นตัวเร่งหรือลคสัญญาณเสียงคังกล่าว สัญญาณนี้จะถูกขยายให้แรงขึ้น แล้วส่งออกที่ขา 1 และขา 3 เพื่อสงออกลำโพงต่อไป

การประกอบวงจร

รูปการลงอุปกรณ์และการต่ออุปกรณ์ภายนอกแสดงไว้ในรูปที่ 2 ในการประกอบ วงจร ควรจะเริ่มจากอุปกรณ์ที่มีความสูงที่น้อยที่สุดก่อน เพื่อความสวยงามและการ ประกอบที่ง่าย โดยให้เริ่มจากไดโอดตามด้วยตัวต้านทานและไล่ความสูงไปเรื่อยๆ สำหรับอุปกรณ์ที่มีขั้วต่างๆ ควรใช้ความระมัดระวังในการประกอบวงจร ก่อนการใส่ อุปกรณ์หล้อนั้จะต้องให้ขั้วที่แผ่นวงจรพิมพ์กับตัวอุปกรณ์ให้ตรงกัน เพราะอาหากใส่ กลับขั้วแล้ว อาจจะทำให้อุปกรณ์หรือวงจรเสียหายได วิธีการดูขั้วและการใส่อุปกรณ์ นั้นได้แสดงไว้ในรูปที่ 3 แล้ว ในการบัดกรีให้ใช้หัวแร้งขนาดไม่เกิน 40 วัตต์ และ ใช้ตะกั่วบัดกรีที่มีอัตราส่วนของดีบุกและตะกั่วอยู่ระหว่าง 60/40 รวมทั้งจะต้องมีน้ำยา ประสานอยู่ภายในตะกั่วด้วย หลังจากที่ได้ใส่อุปกรณ์และบัดกรีเรียบร้อยแล้ว ให้ทำ การตรวจสอบความถูกต้องอีกครั้งหนึ่ง เพื่อใหเกิดความมั่นใจแก่ตัวเราเอง แต่อาเกิด ใส่อุปกรณ์ผิดตำแหน่ง ควรใช้ที่ดูดตะกั่วหรือลวดซับตะกั่ว เพื่อป้องกันความเสียหายที่ อาจจะเกิดกับลายวงจรพิมพ์ได้

การทดสอบ

ปรับ VOLUME ไปทางซ้ายมือสุด จ่ายไฟเข้าวงจร LED POWER จะติด แล้ว ก่อยๆ หมุน VRI ไปทางขวามือ จะได้ยินเสียงออกทางลำโพง ทดลองปรับ TUNER จะได้ยินเสียงคลื่นวิทยหลายๆ สถานี

สำหรับสวิตซ์ SW1 เป็นตัวเลือกยานความถี่ที่ต้องการรับ นั่นคือ AM และ FM จุดจั๊ม JSW เป็นจุดตัดต่อไฟเข้าวงจร สามารถใช้ตัวจั๊มเปอร์หรือต่อผ่านสวิตซ์ ON/OFF ได้

วงจรเครื่องรับวิทยุ AM/FM แบบ DSP DSP AM/FM RADIO RECEIVER KIT CODE 716

This circuit is a DSP (Digital Signal Processing) radio circuit that uses selective adjustment. Stations by changing the pressure Which is different from choosing a conventional station that uses adjustable capacitors Is a station selector Which will be a problem when used for a while, this circuit uses only one controller IC, can operate as AM and FM radio, so the circuit can be easily built and assembled for newbies as well.

Technical data

- Power supply: 4.5-6VDC
- Electric current consumption : 200mA. (max.)
- There is a switch to choose to AM or FM stations
- Use adjustable resistors To adjust the station selection.
- Use adjustable resistor In reducing the sound acceleration.
- Use the DSP radio receiver IC with internal receiver and controller
- Has a power amplifier within 0.6 watts at 6 volts.
- PCB dimension: 2.85 in x 2.21 in

How does it work

The operation of this circuit Will be divided into 2 major parts, including radio receiver and audio amplifier

Part One: Radio reception The heart of this circuit is located in IC1 which is a DSP controlled IC with main pins as follows

- Pin 1 and Pin 2 are connected to the SW1 switch, operate as an option to receive AM or FM radio stations.
- Pin 4 will be connected to VR1, operate as a pin for controlling radio
- Pin 16 is the signal output pin
- Pin 12 and pin 13 are connected to the crystal 32.768KHz to generate the frequency for IC1.
 - Pin 8 is the pin input of the AM radio receiver.
- Pin 6 is an RF input pin of the FM radio receiver, with TR1 transistor to amplify the signal before entering this pin.

The second part, the amplifier will use IC2 as the amplifier. The operation starts when the audio signal from pin 16 of IC1 arrives at pin 7 of IC2 through the VR2 volume, which acts as a catalyst or reduce the said signal This signal will be strengthened. Then output to pin 1 and pin 3 for the next speaker output.

Circuit Assembly

The assembly of components is shown in Fig. 2. For good looking and easy assembly, the shorter components should be first installed - starting with low resistant components and then the higher. An important thing is that diodes, electrolyte capacitors, and transistors shall be carefully assembled before mounting them onto their right anode/cathode of the IC board otherwise it might cause damage to the components or the circuit. Configuration of the anode and the cathode is shown in Fig 3. Use the soldering iron/gun not exceeding 40 watts and the solder of tin-lead 60:40 with flux within. Recheck the correctness of installation after soldering. In case of wrong position, just use lead absorber or lead extractor wire to avoid probable damage to the PCB.

Testin

Adjust the VOLUME to Max. counterclockwise. Supply power to the circuit, LED POWER will be lighted on. Slowly turns the VR1 to clockwise. The sound can be heard through the speaker. Adjust the TUNER, you are hearing the sound of many radio stations.

For the switch SW1 is the frequency band you want to receive, that is AM and FM.

The jump point JSW is the point to turn on and off the power to enter the circuit. It can be used with a jumper or connected via an ON/OFF switch.





