
# DIGITAL LOCK | WS 300



#### **Outer Dimension**



#### Color





**SILVER** 

**BLACK** 

# WS300



Password



Card

## **Feature**

#### Tamper alarm function

Tamper-proof Mode starts when improper operation is repeated 6 times When Start Button is pressed at Tamper-proof mode, tamper alarm is triggered and no operation is allowed.

## Auticrime function

Set as s factory default for higher security.

Inputting random numbers can prevent your password form being stolen by fingerprints

#### Emergency power supply function:

When the battery runs out and can't unlock, you can input power by USB-TypeC (Mobile Battery)

#### Anti-theft thumbturn function


You can't lock or unlock the door if you don't press the thumb turn button. This function prevents unauthorized unlocking by turning the thumb turn.

# Timer lock function

Timer locking can be set to prevent forgetting to lock the door.

The door will automatically lock 5 minutes after unlocked by password, user card, or manually.

# **Card Specification**



User Card (Sell Separately)



Registration card (2 pcs included)

### List of Item No.

door thickness	Color	Item No.
32-40	SILVER	9QK18-00100
	BLACK	9QK18-10100

#### **Basic Specification**

Variable : D/T 32-40mm Color : Silver / Black

password : Type Touch Sensor

Digits 4 to 12 ID 2 ID

Battery : Power AA alkaline 4 pcs

Life Prox. 2years (5cycles per day)
Size : Outside 59mm(W) x 201mm(H) x 39mm(D)
Inside 70mm(W) x 125mm(H) x 66mm(D)

Temperature: Unit -30~80°C (Outside)

0~50°C (Inside)

Card -25~50°C Tag -10~60°C

Battery 5~45°C \*The case of Panasonic battery