

วงจรเต๋าอิเล็กทรอนิคส์เป็นวงจรเครื่องเล่นอิเล็กทรอนิคส์ชนิด หนึ่ง ซึ่งใช้การทดแทนการโยนลูกเต๋า เมื่อเรากดสวิตซ์ LED ทั้ง 7 ดวง จะกระพริบพร้อมกันทั้งหมดด้วยความเร็วสูง ครั้นพอปล่อย สวิตซ์ LED จะหยุดกระพริบแล้วติดที่ตำแหน่งใดตำแหน่งหนึ่ง จึง คล้ายการโยนลูกเต๋ามาก

ขอมูลทางดานเทคนิค

- ใช้แหล่งจ่ายไฟขนาด 9 โวลท์ดีซี
- กินกระแสสูงสุดประมาณ 18-30 มิลลิแอมป์
- ขนาดแผนวงจรพิมพ์ : 3.59 x 1.59 นิ้ว

การทำงานของวงจร

ในส่วนแรกของวงจรจะทำหน้าที่เป็นวงจรออสซิสเลท เพื่อสร้าง กวามถี่กลื่นสี่เหลี่ยมขึ้นมา ถ้าเรากดสวิตซ์คลื่นสี่เหลี่ยมนี้ ก็จะผ่าน สวิตซ์และเข้าไปยังวงจรนับ โดยไอซีที่ทำหน้าที่นับ คือ IC1 ซึ่งเป็น วงจรนับสิบ แต่ในที่นี้เราจะต่อขา 5 และขา 15 ของ ไอซีรวมกัน การ นับจึงได้เอาท์พุทออกมาเพียง 6 ตำแหน่ง แล้วนำเอาท์พุทเหล่านี้ไป เข้าวงจรไดโอด เพื่อขับ LED ให้สวาง ตามตำแหน่งของการใช้งาน ต่อไป สำหรับลายปริ้นท์ต้องจัดวางตำแหน่ง LED ให้ได้ ลักษณะ กล้ายกับลูกเต่าจริงตามรูปที่ 2

การประกอบวงจร

รูปการลงอุปกรณ์และการต่ออุปกรณ์ภายนอกแสดงไว้ในรูปที่ 2 ในการประกอบวงจรควรจะเริ่มจากอุปกรณ์ที่มีความสูงที่น้อยที่สุด กอน เพื่อความสวยงามและการประกอบที่งาย โดยให้เริ่มจากไดโอด ตามด้วยตัวต้านทานและไลความสูงไปเรื่อยๆ สำหรับอุปกรณ์ที่มีขั้ว ตางๆ เช่น ไดโอด, คาปาซิสเตอร์แบบอิเล็กทรอไลต์และทรานซิสเตอร์ เป็นตน ควรใช้ความระมัดระวังในการประกอบวงจร ก่อนการ ใสอุปกรณ์เหลานี้จะต้องให้ขั้วที่แผนวงจรพิมพ์กับตัวอุปกรณ์ให้ตรง กัน เพราะถ้าหากใสกลับขั้วแล้ว อาจจะทำให้อุปกรณ์หรือวงจรเสียหายได้ วิธีการดูขั้วและการใส่อุปกรณ์นั้นได้แสดงไว้ในรูปที่ 3 แล้ว ในการบัดกรีให้ใช้หัวแรงขนาดไมเกิน 40 วัตต์ และใช้ตะกั่วบัดกรีที่มีอัตราสวนของดีบุกและตะกั่วอยู่ระหวาง 60/40 รวมทั้งจะต้องมีน้ำยาประสานอยู่ภายในตะกั่วด้วย หลังจากที่ได้ใส่อุปกรณ์และบัดกรีเรียบรอยแล้ว ให้ทำการตรวจสอบความถูกต้องอีกครั้งหนึ่ง เพื่อให้เกิดความมั่นใจแก่ตัวเราเอง แต่ถ้าเกิดใส่อุปกรณ์ผิดตำแหน่ง ควรใช้ที่ดูดตะกั่วหรือลวดซับตะกั่ว เพื่อป้องกันความเสียหายที่อาจจะเกิดกับลายวงจรพิมพ์ได้

การทดสอบ

จ่ายไฟเข้าวงจร LED อาจจะติด 1-6 ดวง ไม่แน่นอน กดสวิตซ์ ตอนนี้ LED จะกระพริบ เมื่อปล่อยสวิตซ์ LED อาจจะติด 1-6 ดวง ไม่แน่นอน ให้ทำการทดลองกดสวิตซ์หลายๆ ครั้งแล้วปล่อย สังเกต LED ที่ติด อาจจะติด 1, 2, 3, 4, 5, 6 ดวง ไม่แน่นอนเหมือน กับการโยนลูกเต๋า

วงจรเต๋าอิเล็กทรอนิคส์ ELECTRONIC DICE GAMES CODE 129



Instead of tossing a dice to device who goes next or how far to advance along a board game, press the FK129's switch and its 7 red LEDs will cycle through rapidly. Release the switch and the LED action will stop at a random selection of LEDs between 1 and 6 in the traditional dice pattern. Use two FK129 for craps or similar games or for classroom demonstration of random numbers.

Technical data

- Power supply: 9VDC.
- Electic current consumption: 18-30mA (max.)
- IC board dimension: 3.59 in x 1.59 in.

How does it work


The circuit functions as oscillator to create frequency of quadrature waves. Once the switch is pressed the quadrature waves will enter the counting IC1 which is a decade counter circuit. However, as L5 and L15 of the circuit are connected to each other the counting thus can do only six outputs and consequently take them to the diode circuit to turn on the LED at point of use. The design of the printed circuit board (PCB) shall be arranged in the manner that the LEDs look like a real dice (see Fig. 2).


Circuit Assembly


The assembly of components is shown in Fig. 2. For good looking and easy assembly, the shorter components should be first installed - starting with low resistant components and then the higher. An important thing is that diodes, electrolyte capacitors, and transistors shall be carefully assembled before mounting them onto their right anode/cathode of the IC board otherwise it might cause damage to the components or the circuit. Configuration of the anode and the cathode is shown in Fig 3. Use the soldering iron/gun not exceeding 40 watts and the solder of tin-lead 60:40 with flux within. Recheck the correctness of installation after soldering. In case of wrong position, just use lead absorber or lead extractor wire to avoid probable damage to the IC.

Testing

Energize the circuit the LED1-6 might turn on. Press the switch, they might blink. Release the switch, some of them might turn on. Test by doing this again and again and observe whether the LEDs lit. Some of them might turn on like the tossing of a dice.







NOTE:

FUTURE BOX FB04 is suitable for this kit.