

Sole-Mate™ II

Static Dissipative Footwear Test Station

The **Sole-Mate™ II** is a user friendly device that is designed to test the condition of static dissipative footwear prior to entering safety critical hazardous areas exposed to potentially ignitable atmospheres.

Enquiry > Click here to submit a product related query or a request for quotation.

International Standards (detailed on the next page) recommend regular testing of static dissipative footwear. The **Sole-Mate II** provides a time efficient and cost effective method of ensuring personnel operating in hazardous areas are wearing static dissipative shoes that are capable of preventing electrostatic charge accumulation on their bodies.

The **Sole-Mate II** tests the condition of the shoes by measuring the resistance of the electrical loop through the operator and their footwear. If the resistance of the shoes is too high, the **Sole-Mate II** will indicate that the shoes have failed the test via a red lamp and buzzer alarm. If the shoes pass the test a green lamp will indicate to the operator that the shoes are fit for purpose.

Additionally, users can interlock the tester with audible alarms or entry doors into hazardous areas so that personnel not wearing suitable footwear cannot enter the hazardous area.

All **Sole-Mate II** units are supplied with 3 m cable to wire into a mains supply. The U.S. unit is supplied with 6 ft. cord and U.S. 3 prong plug.

- > Upper level resistance options available
- > Sole-Mate II resistance level tester
- > IP65 industrial standard enclosure



Sole-Mate II
Static Dissipative Footwear Test Station



Sole-Mate™ II Static Dissipative Footwear Test Station

Relevant International Standards

Based on user preference, the Sole-Mate II can be ordered to measure upper level resistance as defined by the following standards:

- > EN ISO 20345 — 1×10^9 ohm
- > IEC 60079-32 — 1×10^8 ohm
- > ASTM F2413 — 1×10^8 ohm
- > CAN/CSA Z195-14 — 1×10^8 ohm

PLEASE NOTE: Equipment specifiers must ensure that the Sole-Mate Tester resistance level selected is compatible with the static dissipative shoes in use within the hazardous area. E.g.: a 1×10^8 resistance level should not be selected for EN ISO 20345 compatible shoes.

Sole-Mate Resistance Tester

The resistance test unit can be used at regular intervals (every 6 or 12 months) to ensure the upper resistance threshold of the footwear tester is operating at the correct level.

Contact Us > Your enquiry will be processed rapidly via our webform enquiry service. If you would prefer to call us, or e-mail us, please use the contact details provided below.

The Sole-Mate™ II forms part of the Static Grounding and Bonding Equipment available from Newson Gale.

United Kingdom
Newson Gale Ltd
Omega House
Private Road 8
Colwick, Nottingham
NG4 2JX, UK
+44 (0)115 940 7500
groundit@newson-gale.co.uk

Deutschland
IEP Technologies GmbH
Kaiserswerther Str. 85C
40878 Ratingen
Germany
+49 (0)2102 5889 0
erdung@newson-gale.de

United States
IEP Technologies LLC
417-1 South Street
Marlborough, MA 01752
USA
+1 732 961 7610
groundit@newson-gale.com

South East Asia
ngsea@newson-gale.com