

PATRA

FINE BONE CHINA



208, 7th Floor, 208 Building, Wireless Road,
Lumpini, Pathumwan, Bangkok 10330, Thailand
Tel : +662 651 5625 Fax : +662 651 5653
info@patraporcelain.com www.patraporcelain.com

Hotel & Restaurant

Measurement

D = Outside Diameter mm
 d = Inside Diameter mm
 L = Major axis mm
 S = Minor axis mm

H = Height mm
 cc = centiliter cc



Type of Strainer	Section & Elevation of Pot	Reference mark
Strainer Type		
No Strainer		

CONTENT

Fine Bone China by PATRA

PATRA Bone China	02
Coupe Plate & Rim Plate	03
Plate & Deep Plate	04
Oval Plate	05
Bowl	07
Holloware	09
Coupe Plate & Bowl	10
Casserole & Accessory	11
Measurement Guide	12

PATRA

FINE BONE CHINA
THAILAND

PATRA Bone China is a customizable line enabling highly differentiated western and oriental offerings.

Ethereal lines and fluid curves naturally define unique tableware offerings while also complementing existing tableware settings.

Western and Oriental shapes centered on delivering functional elegance with diverse aesthetic appeal.

All PATRA products are characterized by quality and durability.

With Bone China, PATRA has strived to deliver the highest standard product properties in terms of material strength, body color, and translucence.

PATRA Bone China delivers cultured refinement centered on established comfort zones and user familiarity.

Casserole



Casserole 1,000 cc w/Lid (S)

5017002 Ø 20 cm. Set

5017000 Body
D204, H72, 1,000 CC

5017001 Lid
D175.5, H28



Casserole 1,500 cc w/Lid (M)

5017012 Ø 23 cm. Set

5017010 Body
D238, H76, 1,500 CC

5017011 Lid
D207, H39



Casserole 2,000 cc w/Lid (L)

5017015 Ø 25 cm. Set

5017013 Body
D257, H85, 2,000 CC

5017014 Lid
D231, H40



Casserole 2,500 cc w/Lid (LL)

5017018 Ø 27 cm. Set

5017016 Body
D275, H89, 2,500 CC

5017017 Lid
D244, H42

Accessory



Soy Sauce Pot w/ Lid

5017118 80 cc. Set

5017117 Body
L92.5, S63, H63.3, 80 CC

5017111 Lid
D25, H27



Round Divided Dish

5014905 Ø 9.5 cm.

D97, H19, 30 CC



Square Divided Dish

5014904 9 cm.

88 X 88, H20.5, 35 CC



Dish

5011110 Ø 10 cm.

D104.5, H17, 55 CC



Egg Cup

5046506 Ø 5 cm.

D50, H60



Spoon

5016428 13.5 cm.

L138, S49.5, H45



Sauce Spoon

5016421 8 cm.

L87.5, S22, H34



Butter w/ Lid

5043157 Ø 7 cm. Set

5043107 Body
D71, H30, 80 CC

5043156 Lid
D72, H23



Spoon & Chopstick Rest

5016569

L112.5, S65, H10.5



Chopstick Rest

5016583

L62.5, S21, H11.5



Spoon Rest

5046592

L92, S57, H36



Salt

5036501

D40, H60



Pepper

5036502

D40, H60

Coupe plate/bowl



Coupe plate
5056307 7 cm.
L70, S62, H15



Coupe bowl
5056357 7 cm.
L70, S62, H20, 30 CC



Coupe plate
5056310 10 cm.
L100, S90, H16



Coupe bowl
5056360 10 cm.
L100, S90, H25, 80 CC



Coupe plate
5056312 12 cm.
L120, S108, H19



Coupe bowl
5056362 12 cm.
L120, S108, H30, 140 CC



Coupe plate
556314 14 cm.
L140, S126, H22



Coupe bowl
5056364 14 cm.
L140, S126, H45, 320 CC



Coupe plate
5056316 16 cm.
L160, S145, H25



Coupe bowl
5056366 16 cm.
L160, S145, H55, 540 CC



Coupe Plate



Coupe Plate

- 5011192 Ø 42 cm.
D426, H36
- 5011188 Ø 38 cm.
D389.5, H38.5
- 5011186 Ø 36 cm.
D364, H36
- 5011183 Ø 33 cm.
D335, H35
- 5011131 Ø 31 cm.
D319, H36



- 5011127 Ø 27 cm.
D274, H28.5
- 5011124 Ø 24 cm.
D243, H24
- 5011121 Ø 21 cm.
D209, H20.5
- 5011118 Ø 18 cm.
D180.5, H23
- 5011116 Ø 16.5 cm.
D167.5, H23.5

Rim Plate



Rim Plate

- 5031030 Ø 30 cm.
D301, H23.8
- 5031027 Ø 27.5 cm.
D276, H21.8
- 5031025 Ø 25.5 cm.
D255, H20.5
- 5031023 Ø 23 cm.
D290, H20
- 5031021 Ø 21 cm.
D210, H18.6



Rim Plate

- 5031019 Ø 19 cm.
D190, H18.7
- 5031017 Ø 17 cm.
D173, H17.5
- 5031015 Ø 15 cm.
D153, H15.6
- 5011016 Ø 16.5 cm.
D168, H18



Plate



Hot Plate

5041024 Ø 24.3 cm.
D243, H21.5

5041025 Ø 25.3 cm.
D253, H20



Side Plate

5041017 Ø 17.5 cm.
D178.5, H16.5

Deep Plate



Deep Plate/Dish

5011336 Ø 36 cm.
D369.5, H67

5011331 Ø 31 cm.
D317, H59

5011327 Ø 27 cm.
D273.5, H55

5011323 Ø 23 cm.
D235, H43.5

5011310 Ø 10 cm.
D102, H26

5011308 Ø 8 cm.
D82.5, H21.5

5011307 Ø 7 cm.
D73, H18



Round Dish

5011414 Ø 14 cm.
D143.5, H27

5011412 Ø 12 cm.
D122, H22



Chinese Tea Cup

5013008 150 cc.
D80.5, H58, 150 CC



Chappai Cup w/ Lid

5012988 190 cc. Set

5012985 Chappai Cup
D98, H57, 190 CC

5012987 Lid
D83, H28.5

5012989 Dish Rimmed
D102.5, H23



Tea Coffee Cup w/Saucer

5032147 290 cc. Set

5032145 Coffee Cup
L116, S89, H62.3, 290 CC

5032144 Saucer 16 cm.
D160, H19



Espresso Cup w/Saucer

5042102 100 cc. Set

5042100 Espresso Cup
L85, S66, H49, 100 CC

5042101 Saucer 12.5 cm.
D125, H19



Tea Cup w/ Saucer

5012027 150 cc. Set

5012025 Tea Cup
L97.5, S77, H54, 150 CC

5012026 Saucer 12.5 cm.
D125, H19



Coffee Cup w/Saucer

5042002 210 cc. Set

5042000 Coffee Cup
L105, S80, H65, 210 CC

5042001 Saucer 15 cm.
D150, H22



Mug

5042401 350 cc.
L168, S34, H18, 350 CC



Cappuccino Cup w/Saucer

5042092 320 cc. Set

5042090 Coffee Cup
L129, S101, H66.5, 320 CC

5042091 Saucer 17 cm.
D171.4, H23.5



Stacking Mug

5032487 340 cc. Set

5032483 Stack Mug
L117, S90, H70, 340 CC

5032144 Saucer 16 cm.
D160, H19



Mug

5032414 380 cc.
L115, S84, H102, 380 CC



Mug

5032430 300 cc.
L106, S76, H91, 300 CC

Holloware



Tea Pot w/ Lid

5016057 950 cc. Set

5016055 Body
L234.5, S91.5, H94, 950 CC

5016056 Lid
D79, H78



Coffee & Tea Pot w/ Lid

5046012 500 cc. Set

5046010 Body
L156, S104, H96, 500 CC

5046011 Lid
D77, H36



Tea Pot w/ Lid

5036017 700 cc. Set

5036015 Body
L203, S115, H93, 700 CC

5036016 Lid
D85, H33



Tea Pot w/ Lid

5036042 400 cc. Set

5036040 Body
L171.2, S98, H18, 400 CC

5036001 Lid
D75, H32



Coffee Pot w/ Lid

5036002 350 cc. Set

5036000 Body
L156, S83.4, H95, 350 CC

5036001 Lid
D75.5, H32



Creamer

5046191 70 cc.
L85, S70, H57, 70 CC



Creamer

5036190 230 cc.
L118, S70, H78, 230 CC



Sugar Pack

5043096 Ø 8 cm.
L80, H70, 260 CC



Sugar Bowl w/ Lid

5036172 220 cc. Set
5036170 Body
D70, H78, 220 CC
5036171 Lid
D72, H24.2

Deep Plate



Serving Bowl

5031227 Ø 27.3 cm.
D273, H52



Pasta Soup

5030223 Ø 23 cm.
D230, H52



Soup Pasta

5031223 Ø 23 cm.
D230, H32.7



Soup Pasta

5031223 Ø 23 cm.
D230, H32.7

5037157 Cover 17 cm.
D173, H77

Oval



Oval Platter

5014046 46 cm.
L463, S336, H46

5014041 41 cm.
L410, S291, H39

5014036 36.5 cm.
L366.5, S263, H31.5

5014026 26 cm.
L262, S194, H27.5

5014021 21 cm.
L213.5, S157, H20



Oval Coupe Platter

5014131 31 cm.
L319.5, S234, H27

5014126 26 cm.
L267.5, S190, H25

5014123 23 cm.
L237.5, S160, H24.5



Oval Serving Platter

5034830 30.5 cm.
L305, S230, H26



Soup Bowl
5013010 Ø 10.5 CM.
D107, H51, 230 CC



Rice Bowl
5013011 Ø 11.5 cm.
D117.5, H56.5, 300 CC



Noodle Bowl
5013012 Ø 12.5 cm.
D129, H62, 410 CC



Bowl
5033114 Ø 14 cm.
D140, H67, 690 CC



Cereal Bowl
5033115 Ø 15 cm.
D152, H70, 800 CC



Shark Fin Soup Bowl
5013809 Ø 9 cm.
D97, H47, 150 CC



Bowl
5013811 Ø 11 cm.
D11.2, H52.5, 240 CC
5013810 Ø 10 cm.
D107, H51, 200 CC



Noodle Bowl
5013514 Ø 14 cm.
D149, H62.5, 560 CC



Noodle Soup Bowl
5013519 Ø 19 cm.
D192, H72, 1,120 CC



Bowl
5033118 Ø 18 CM.
D180, H50, 730 CC



Bowl
5030326 Ø 26 cm.
D266, H69, 800 CC



Medium Bowl
5043516 Ø 16.5 cm.
D168, H68, 770 CC



Large Bowl
5043020 Ø 20 cm.
D206.5, H72.5, 1,200 CC



Condiment Bowl w/ Lid
5043112 Ø 9 cm. Set
5043109 Body
D90, H43.5, 180 CC
5043111 Lid
D91, H29



Small Bowl w/ Lid
5043572 Ø 13.5 cm. Set
5043513 Body
D137, H67, 550 CC
5043571 Lid
D139, H45



Soup Cup with 2 handles
5012242 340 cc. Set
5012240 Body
D123.5, H54, 340 CC
5012241 Lid
D126, H43
5012011 Saucer 15 cm.
D150.5, H24.5