



# FUTURE KIT

HIGH QUALITY ELECTRONIC KITS

วงจรคอมพิวเตอร์ดิจิตอลนี้ เป็นวงจรที่ใช้ในการวัดพลังเสียงเบื้องต้น ซึ่งไม่ต้องการความละเอียดมากนัก โดยวงจรนี้จะหมายความว่าที่จะใช้เป็นกุญแจที่ดูดเสียงจากภายนอกหรือใช้ในงานวัดระดับเสียงที่ไม่ต้องการความละเอียดมากนัก

#### ข้อมูลทางด้านเทคนิค

- ใช้แหล่งจ่ายไฟขนาด 9 โวลต์ดีซี
- กินกระแสสูงประมาณ 20 มิลลิแอมป์ (standenby), 50 มิลลิแอมป์ (ขณะทำงาน)

- สามารถปรับความไวในการตรวจจับเสียงได้
- ขนาดแพนแองเพิร์ฟ : 2.29 x 1.11 นิ้ว

#### การทำงานของวงจร

วงจรจะแสดงในรูปที่ 1 การทำงานจะเริ่มจาก เมื่อไมโครโฟนได้รับเสียงเข้ามา สัญญาณเสียงดังกล่าวจะถูกเปลี่ยนเป็นพลังงานไฟฟ้า จากนั้นจะไปเข้าที่ IC3/4 เพื่อทำการขยายสัญญาณให้แรงขึ้น โดยนี่ VR1 เป็นคัวบันสายอัตรากาหนดของอัตราขยายของสัญญาณ สัญญาณที่ออกมาจาก IC3/4 จะส่งออกไปในอั้สีหับ TR1 ทำงาน เมื่อ TR1 ทำงาน แรงดันจากขา C จะไปออกที่ขา E และไปเข้าบานกลางของ IC1/2 จนถึง IC3/3 เพื่อทำการเปรียบเทียบแรงดันกัน นำบานกลางไอซีเด็ดตัวซึ่งได้รับแรงดันมาจาก IC1/1 ซึ่งต่อวงจรในลักษณะของวงจรบัฟเฟอร์ ถ้าแรงดันที่บานกลางกว่าหลับ LED ที่ต่ออยู่กับไอซีเดดตัวนั้นจะติด ในการถัดไปแรงดันที่บานกลางอย่างกว่าหลับ LED ที่ต่ออยู่กับไอซีเดดตัวนั้นจะดับ C5 และ R7 จะทำหน้าที่หน่วงเวลาในการดับของ LED สวิตช์ SW RESET จะทำหน้าที่รีเซ็ตให้ LED ทุกดวงดับ

สำหรับ VR2 จะทำหน้าที่เป็นคัวปรับแรงดันเปรียบเทียบที่ป้อนเข้าสู่ขาบาน IC1/2 จนถึง IC3/3 ในการปรับอัตราของความต้องการของเรามากขึ้น

#### การประกอบวงจร

รูปการลงอุปกรณ์และการต่ออุปกรณ์ภายนอกแสดงไว้ในรูปที่ 2 ในการประกอบวงจร ควรจะเริ่มจากอุปกรณ์ที่มีความสูงที่น้อยที่สุดก่อน เพื่อความสวยงามและการประกอบที่ง่าย โดยให้เริ่มจากไฟโดยตรงด้วยตัวคนงานและไฟความสูงไปริ่มๆ สำหรับอุปกรณ์ที่มีหัวต่างๆ เช่น ไดโอด, ตัวเก็บประจุนิดอิเล็กทรอนิกส์และทรานซิสเตอร์ เป็นต้น ควรใช้ความระมัดระวังในการประกอบวงจรก่อนการใส่สูปอร์ฟลูแล้วให้ชี้ตัวให้เข้าที่เพื่อตรวจสอบอุปกรณ์ให้ตรงกัน เพราะหากนำไปติดกันแล้ว อาจทำให้อุปกรณ์เสียหายได้ วิธีการรู้ขั้วและการใส่สูปอร์ฟลูนั้นได้แสดงไว้ในรูปที่ 3 และในการบัดกรีให้หัวแรงขนาดไม่เกิน 40 วัตต์ และใช้ตะเกียบบัดกรีที่มีอัตราส่วนของดีบุกและตะเกียบอยู่ระหว่าง 60/40 รวมทั้งจะต้องมีหัวประสาทอยู่ภายในตัวด้วย หลังจากที่ได้ใส่สูปอร์ฟลูแล้ว ให้ทำการตรวจสอบความถูกต้องอีกครั้งหนึ่ง เพื่อให้เกิดความมั่นใจแก่ตัวเราเอง แต่ถ้าเกิดใส่อุปกรณ์ผิดตำแหน่ง ควรไข่หุคดีกับหัวรีดเวลาดับตัว หรือเปลี่ยนอุปกรณ์ที่ติดต่อ

#### การทดสอบ

ทำการจ่ายไฟตรงขนาด 9 โวลต์ ต่อเข้าบานของ VR1 และ VR2 ไปทางขวามือสุด ทดลองมองว่าเมื่อบริเวณไมโครโฟน LED จะขึ้นหมดทุกดับ จากนั้นถ้าไม่มีเสียงดังใดๆ เข้ามา LED จะดับอย่างต่อเนื่องไปเรื่อยๆ ดังนั้น ควรหันหัวไปทางทุกด้านหรือต่อหัวไว้ให้ดับและในทันที ถ้าสามารถกดสวิตช์ RESET ได้ ถ้าเป็นตามที่ทดลองมา จะแสดงว่างานพร้อมสำหรับใช้งานได้แล้ว

สำหรับ VR1 จะเป็นคัวปรับความไวในการรับสัญญาณเสียงของไมโครโฟนและ VR2 จะใช้สำหรับปรับระดับแรงดันเปรียบเทียบที่เพื่อให้ LED ติดได้อย่างเหมาะสมกับสภาพแวดล้อม

## เกมส์ทดสอบพลังเสียง 10 LED

### SOUND TESTER GAME 10 LED

CODE 181

LEVEL 2

Similar to a VU meter, the FK181 can be used to detect and visually display the general level of sound in various parts of a room or auditorium. The unit may be used on its own or augmented by power drivers for large displays in discos and public places. The FK181 can also be used as a wearable sound-sensitive display in "Ghost Buster" or "Star Wars" costumes.

#### Technical data

- Power supply : 9VDC.
- Electric current consumption : 20mA. (stand by), 50mA. (working)
- Adj. sensitivity : trimmer potentiometer.
- IC board dimension : 2.29 in x 1.11 in.

#### How does it work

The circuit working as shown in Figure 1, will start when it receives incoming sound signal. The signal will be changed to electric power and fed to IC3/4 for signal amplification. VR1 will act as a signal amplifying controller. The output signal from pin 7 of IC3/4 will be fed to the base of TR1 for bias and TR1 starts working. When TR1 works, voltage from the collector will move out from the emitter to positive pins of IC1/2 to IC3/3 for comparing with negative pins of each IC that receives voltage from IC1/1 (buffer circuit). In case of the positive pin voltage is bigger than the negative pin voltage, the attached LED of that IC will be lit up. And LED will be off when the positive pin voltage is less than the negative pin voltage. C5 and R7 will delay the switching off time of each LED while switch SW RESET will turn all LEDs off.

VR2 will adjust the comparing voltage amount that being fed to the negative pin of IC1/2 to IC3/3 as required.

#### Circuit Assembly

The assembly of components is shown in Fig. 2. For good looking and easy assembly, the shorter components should be first installed - starting with low resistant components and then the higher. An important thing is that diodes, electrolyte capacitors, and transistors shall be carefully assembled before mounting them onto their right anode/cathode of the IC board otherwise it might cause damage to the components or the circuit. Configuration of the anode and the cathode is shown in Fig 3. Use the soldering iron/gun not exceeding 40 watts and the solder of tin-lead 60:40 with flux within. Recheck the correctness of installation after soldering. In case of wrong position, just use lead absorber or lead extractor wire to avoid probable damage to the IC.

#### Testing

Supply 9VDC to the circuit that having connected positive pole to position +9V and negative one to position G. Then adjust VR1 and VR2 to the most right hand side. Try to clap closely at the microphone, all LEDs will be lit up. LEDs will be off one by one if there is no incoming sound. Turn on switch RESET if require an instant switching off. Those results show that the circuit is workable.

VR1 will act as a signal receiving sensitivity adjuster of the microphone while VR2 will control the comparing voltage level for lighting up LED to suit the surrounded environment.




Figure 1.  
Sound Tester Game  
10 LED circuit

**NOTE:**  
FUTURE BOX FB03  
is suitable for this kit.





Figure 2.  
Circuit  
Assembling



NO.1