

# LabJack

Published on *LabJack* (<https://labjack.com>)

[Home](#) > [Support](#) > [Datasheets](#) > [T-Series Datasheet](#) > [3.0 Communication](#) > 3.2 Stream Mode

---

## 3.2 Stream Mode [T-Series Datasheet]

[Log in](#) or [register](#) to post comments

### Stream Mode Overview

Streaming is a fast data input mode. It is more complicated than command-response mode, so it requires more configuration. Using stream is simplified by the [LJM stream functions](#); to stream without them, see [3.2.2 Low-Level Streaming](#).

For a given stream session, a list of channels/addresses are sampled as input to the device. This list of channels (known as a scan list) is input, as quickly as possible, immediately after a clock pulse. Stream clock pulses are hardware-timed at a constant scan rate. By default, a stream session begins scanning immediately after being started and continuously scans until stopped.

Stream can also output data.

Stream sessions can be configured to collect a limited number of scans. (See [Burst Stream](#))

T7 only:

The T7 supports some advanced stream features:

- Stream sessions can be configured to delay scanning until after the T7 detects a trigger pulse.
- Stream clock pulses can also be read externally at either a constant or a variable rate.

### On This Page

- [Maximum Stream Speed](#)
- [Stream-In and/or Stream-out](#)
- [Streamable Registers](#)
- [16-bit or 32-bit Data](#)
- [Configuring AIN for Stream](#)
- [Stream Timing](#)

- [Channel-to-Channel Timing](#)
- [Burst Stream](#)
- [Externally-Clocked Stream - T7 Only](#)
- [Triggered Stream - T7 Only](#)

## Maximum Stream Speed \_\_

### T4 Max Sample Rate: 40 ksamples/second

The T4 max sample rate is 40 ksamples/second. This is achievable for any single-address stream, but for a multi-address stream this is only true when resolution index = 0 or 1.

### T7 Max Sample Rate: 100 ksamples/second

The T7 max sample rate is 100 ksamples/second. This is achievable for any single-address stream, but for a multi-address stream this is only true when resolution index = 0 or 1 and when range = +/-10V for all analog inputs.

The **max scan rate** depends on how many addresses you are sampling per scan:

- Address => The Modbus address of one channel. (See [Streamable Registers](#), below.)
- Sample => A reading from one address.
- Scan => One reading from all addresses in the scan list.
- $\text{SampleRate} = \text{NumAddresses} * \text{ScanRate}$

Examples:

- For a T4 streaming 4 channels at resolution index=0, the max scan rate is 10 kscans/second (calculated from 40 ksamples/second divided by 4).
- For a T7 streaming 5 channels at resolution index=0 and all at range=+/-10V, the max scan rate is 20 kscans/second (calculated from 100 ksamples/second divided by 5).

**Ethernet provides the best throughput:** Ethernet is capable of the fastest stream rates. USB is typically a little slower than Ethernet, and WiFi is much slower. For more information on speeds, see the [Data Rates Appendix](#).

## Stream-In and/or Stream-Out \_\_

There are three input/output combinations of stream mode:

**Stream-in:** The device collects data and streams it to the host.

**Stream-out:** The device does not collect data but streams it out. (See [3.2.1 Stream-Out](#))

**Stream-in-out:** The device collects data and streams it to the host. It also streams data out.

The stream channels determine which of these modes are used. Streamable channels may be either stream-in or stream-out.

## Streamable Registers \_

The [Modbus map](#) shows which registers can be streamed (by expanding the "details" area). Input registers that can be streamed include:

---

	For more information
AIN#	See <a href="#">14.0 Analog Inputs</a> .
FIO_STATE	See <a href="#">13.0 Digital I/O</a> .
EIO_STATE	See <a href="#">13.0 Digital I/O</a> .
CIO_STATE	See <a href="#">13.0 Digital I/O</a> .
MIO_STATE	See <a href="#">13.0 Digital I/O</a> .
FIO_EIO_STATE	See <a href="#">13.0 Digital I/O</a> .
EIO_CIO_STATE	See <a href="#">13.0 Digital I/O</a> .
DIO#(0:22)_EF_READ_A	See <a href="#">13.2 DIO Extended Features</a> .
DIO#(0:22)_EF_READ_A_AND_RESET	See <a href="#">13.2 DIO Extended Features</a> .
DIO#(0:22)_EF_READ_B	See <a href="#">13.2 DIO Extended Features</a> .
CORE_TIMER	See <a href="#">4.0 Hardware Overview</a> .
SYSTEM_TIMER_20HZ	See <a href="#">4.0 Hardware Overview</a> .
STREAM_DATA_CAPTURE_16	See <a href="#">below</a> .

For stream-out registers, see [3.2.1 Stream-Out](#).

## 16-bit or 32-bit Data \_

Stream data is transferred as 16-bit values, but 32-bit data can be captured by using `STREAM_DATA_CAPTURE_16`.

**16-bit:** In the normal case of an analog input such as `AIN0`, the 16-bit binary value is actually is what is transferred and LJM converts it to a float on the host using the calibration constants that LJM reads before starting the stream.

**32-bit:** Some streamable registers (e.g. `DIO4_EF_READ_A`) have 32-bit data. When streaming a register that produces 32-bit data, the lower 16 bits (LSW) will be returned and the upper 16 bits (MSW) will be saved in `STREAM_DATA_CAPTURE_16`. To get the full 32-bit value, add `STREAM_DATA_CAPTURE_16` to the stream scan list after any applicable 32-bit register, then combine the two values in software ( $LSW + 65536 * MSW$ ). Note that `STREAM_DATA_CAPTURE_16` may be placed in multiple locations in the scan list.

## Configuring AIN for Stream

`STREAM_SETTLING_US` and `STREAM_RESOLUTION_INDEX` override the normal [AIN configuration settling](#) and resolution registers.

Name	Start Address	Type	Access
 <code>STREAM_SETTLING_US</code> Time in microseconds to allow signals to settle after switching the mux. Does not apply to the 1st channel in the scan list, as that settling is controlled by scan rate (the time from the last channel until the start of the next scan). Default=0. When set to less than 1, automatic settling will be used. The automatic settling behavior varies by device.	4008	FLOAT32	R/W
 <code>STREAM_RESOLUTION_INDEX</code> The resolution index for stream readings. A larger resolution index generally results in lower noise and longer sample times.	4010	UINT32	R/W

&print=true

The normal AIN configuration registers for range and negative channel still apply to stream.

T7 only: Stream mode is not supported on the hi-res converter. (Resolution indices 9-12 are not supported in stream.)

## Stream Timing

When using LJM, there are three ways that stream can be too slow:

1. Sample rate is too high

2. Device buffer overflow
3. LJM buffer overflow

**Sample rate is too high: When the sample rate is too high, it causes a `STREAM_SCAN_OVERLAP` error and stream is terminated.**

Scans are triggered by hardware interrupts. If a scan begins and the previous scan has not finished, the device stops streaming and returns a `STREAM_SCAN_OVERLAP` error (errorcode 2942), which LJM returns immediately upon the next call to `LJM_eStreamRead`.

**Device buffer overflow: When the device buffer overflows, LJM inserts a dummy sample (with the value -9999.0) in place of each skipped sample, or it causes a `STREAM_AUTO_RECOVER_END_OVERFLOW` error and stream is terminated.**

As samples are collected, they are placed in a FIFO buffer on the device until retrieved by the host. The size of the buffer is variable and can be set to a maximum of 32768 bytes. Write to `STREAM_BUFFER_SIZE_BYTES` to set the buffer size.

Name	Start Address	Type	Access
 <code>STREAM_BUFFER_SIZE_BYTES</code> Size of the stream data buffer in bytes. A value of 0 equates to the default value. Must be a power of 2. Size in samples is <code>STREAM_BUFFER_SIZE_BYTES/2</code> . Size in scans is <code>(STREAM_BUFFER_SIZE_BYTES/2)/STREAM_NUM_ADDRE..</code> Changes while stream is running do not affect the currently running stream.	4012	UINT32	R/W

&print=true

If the device buffer overflows, the device will continue streaming but will discard data until the buffer is emptied, after which data will be stored in the buffer again. The device keeps track of how many scans are discarded and reports that value. Based on the number of scans discarded, the LJM library adds the proper number of dummy samples (with the value -9999.0) such that the correct timing is maintained. This will only work if the first channel in the scan is an analog channel.

If the device buffer overflows for too much time, a `STREAM_AUTO_RECOVER_END_OVERFLOW` error occurs and stream is terminated.

If the device buffer is overflowing, see the [LJM stream help](#) page for some mitigation strategies.

**LJM buffer overflow: When the LJM buffer overflows, it causes a `LJME_LJM_BUFFER_FULL` error and stream is terminated.**

LJM reads samples from the device buffer and buffers them internally. LJM reads these samples

in an internal thread, regardless of what your code does. LJM's buffer can run out of space if it is not read often enough using [LJM\\_eStreamRead](#), so make sure the LJMScanBacklog parameter does not continually increase.

LJM\_eStreamRead blocks until enough data is read from the device, so your code does not need to perform waits.

If the LJM buffer is overflowing, see the [LJM stream help](#) page for some mitigation strategies.

## Channel-to-Channel Timing \_\_

Channels in a scan list are input or output as quickly as possible after the start of a scan, in the order of the scan list.

Timing pulses are generated on [SPC](#) so that the channel-to-channel timing can be measured. Pulses on SPC are as follows:

- Falling edge at the start of a scan.
- Rising edge at the start of a sample.
- Falling edge at the end of a sample.
- Rising edge at the end of a scan.

## Burst Stream \_\_

Burst stream is when stream collects a pre-determined number of scans, then stops. To set the stream burst size, write to STREAM\_NUM\_SCANS:

Name	Start Address	Type	Access
 STREAM_NUM_SCANS      The number of scans to run before automatically stopping (stream-burst). 0 = run continuously. Limit for STREAM_NUM_SCANS is 2^32-1, but if the host is not reading data as fast as it is acquired you also need to consider STREAM_BUFFER_SIZE_BYTES.	4020	UINT32	R/W

&print=true

The LJM library collects burst stream data with the [StreamBurst\(\)](#) function.

It may be beneficial to set STREAM\_BUFFER\_SIZE\_BYTES to a large value for fast burst stream. See above for details about STREAM\_BUFFER\_SIZE\_BYTES.

T7-Pro only: Burst stream is well-suited for WiFi connections, because WiFi has a lower throughput than other connection types.

## Externally Clocked Stream - T7 Only \_

Externally-clocked stream allows T-series devices to stream from external pulses. It also allows for variable stream scan rates.

**Clock Source:** The scan rate is generated from the internal crystal oscillator. Alternatively, the scan rate can be a division of an external clock provided on CIO3.

Name	Start Address	Type	Access
 <b>STREAM_CLOCK_SOURCE</b> Controls which clock source will be used to run the main stream clock. 0 = Internal crystal, 2 = External clock source on CIO3. Rising edges will increment a counter and trigger a stream scan after the number of edges specified in <b>STREAM_EXTERNAL_CLOCK_DIVISOR</b> . T7 will expect external stream clock on CIO3. All other values reserved.	4014	UINT32	R/W

&print=true

To subdivide the external clock pulses for a slower scan rate, use **STREAM\_EXTERNAL\_CLOCK\_DIVISOR**.

Name	Start Address	Type	Access
 <b>STREAM_EXTERNAL_CLOCK_DIVISOR</b> The number of pulses per stream scan when using an external clock.	4022	UINT32	R/W

&print=true

To use externally clocked stream with LJM, see the [externally clocked stream](#) section of the LJM User's Guide.

## Triggered Stream - T7 Only \_

T7 minimum firmware 1.0186

Stream can be configured to start scanning when a trigger is detected. Trigger sources

are DIO\_EF modes:

- [Frequency In](#)
- [Pulse Width In](#)
- [Conditional Reset](#)

Frequency In and Conditional Reset allow you to select rising or falling edges and Pulse Width In will trigger from either edge.

See [Appendix A](#) for hysteresis voltage information.

Configuring stream to use a trigger requires setting up a DIO\_EF and adding the STREAM\_TRIGGER\_INDEX register to normal stream configuration.

Name	Start Address	Type	Access
 STREAM_TRIGGER_INDEX Controls when stream scanning will start. 0 = Start when stream is enabled, 2000 = Start when DIO_EF0 detects an edge, 2001 = Start when DIO_EF1 detects an edge. See the stream documentation for all supported values.	4024	UINT32	R/W

&print=true

STREAM\_TRIGGER\_INDEX (address 4024):

- 0 = No trigger. Stream will start when Enabled.
- 2000 = DIO\_EF0 will start stream.
- 2001 = DIO\_EF1 will start stream.
- 2002 = DIO\_EF2 will start stream.
- 2003 = DIO\_EF3 will start stream.
- 2006 = DIO\_EF6 will start stream.
- 2007 = DIO\_EF7 will start stream.

To use triggered stream with LJM, see the [triggered stream](#) section of the LJM User's Guide.

A more complicated stream trigger can be implemented with a [Lua script](#). For example, a Lua script could check for an arbitrary stream trigger condition in conjunction with triggered stream being started as normal. Once the Lua script detects that the stream condition is fulfilled, it writes a pulse to a digital out (such as DIO3) which is then detected by the normal trigger (as specified by STREAM\_TRIGGER\_INDEX).

## 3.2.1 Stream-Out (Advanced) [T-Series

# Datasheet]

[Log in](#) or [register](#) to post comments

## Stream-Out (Advanced) Overview

Stream-out is a set of streamable registers that move data from a buffer to an output. The output can be digital I/O (DIO) or a DAC. The buffer can be read linearly to generate an irregular waveform or be read in a looping mode to generate a periodic waveform.

A T-series device can output up to 4 waveforms using stream-out.

In terms of timing and data rates, stream-out channels count the same as input channels so see the normal documentation of [Streaming Data Rates](#).

Alternate waveform generation techniques are described in the [Waveform Generation](#) App Note.

## Performing Stream-Out

For each waveform being streamed out:

1. Choose which target channel will output the waveform
2. Configure stream-out
  1. STREAM\_OUT#\_TARGET
  2. STREAM\_OUT#(0:3)\_BUFFER\_ALLOCATE\_NUM\_BYTES
  3. STREAM\_OUT#(0:3)\_ENABLE
3. Update the stream-out buffer
  1. STREAM\_OUT#(0:3)\_LOOP\_NUM\_VALUES
  2. STREAM\_OUT#(0:3)\_BUFFER\_F32 or STREAM\_OUT#(0:3)\_BUFFER\_U16
  3. STREAM\_OUT#(0:3)\_SET\_LOOP
4. Start stream with STREAM\_OUT#(0:3) in the scan list
5. Stream loop: read and update buffer as needed
6. Stop stream

Executing stream-out for multiple output waveforms is a matter of performing the above steps in the order above and using corresponding STREAM\_OUT#(0:3) addresses in the scan list.

### 1. Target Selection

The following target list represents the I/O on the device that can be configured to output a waveform using stream out. The list includes the analog and digital output lines.

- DAC0
- DAC1
- FIO\_STATE

- FIO\_DIRECTION
- EIO\_STATE
- EIO\_DIRECTION
- CIO\_STATE
- CIO\_DIRECTION
- MIO\_STATE
- MIO\_DIRECTION

## 2. Configure Stream-Out

Configuration will set the buffer size and target. The target specifies which physical I/O to use. Data in the buffer will be output onto the target I/O as a generated waveform.

Stream-Out Configuration			
Name	Start Address	Type	Access
 STREAM_OUT#(0:3)_TARGET Channel that data will be written to. Before writing data to _BUFFER_###, you must write to _TARGET so the device knows how to interpret and store values.	4040	UINT32	R/W
 STREAM_OUT#(0:3)_BUFFER_ALLOCATE_NUM_BYTES Size of the buffer in bytes as a power of 2. Should be at least twice the size of updates that will be written and no less than 32. Before writing data to _BUFFER_###, you must write to _BUFFER_ALLOCATE_NUM_BYTES to allocate RAM for the data. Max is 16384.	4050	UINT32	R/W
 STREAM_OUT#(0:3)_ENABLE Write 1 to enable, 0 to disable. When enabled, you get 1 update per target per stream scan, so a stream must be active for updates to happen.	4090	UINT32	R/W

&print=true

Configuration can be done before or after stream has started.

## 3. Update Buffer

Each stream-out has its own buffer. Data is loaded into the buffer by writing to the appropriate buffer register. Output waveform data points are stored in the buffer as 16-bit values, so values greater than 16-bits will be converted automatically before being stored in the buffer. Use only one buffer per STREAM\_OUT channel.

For outputting an analog waveform (DAC output), write an array of floating-point numbers to the STREAM\_OUT#(0:3)\_BUFFER\_F32 register.

For outputting a digital waveform, pass an array of integer 0 or 1 values to the STREAM\_OUT#(0:3)\_BUFFER\_U16 register.

Stream-Out Buffers			
Name		Start Address	Type Access
 STREAM_OUT#(0:3)_BUFFER_U16	Data destination when sending 16-bit integer data. Each value uses 2 bytes of the stream-out buffer. This register is a buffer.	4420	UINT16 W
 STREAM_OUT#(0:3)_BUFFER_F32	Data destination when sending floating point data. Appropriate cal constants are used to convert F32 values to 16-bit binary data, and thus each of these values uses 2 bytes of the stream-out buffer. This register is a buffer.	4400	FLOAT32 W

&print=true

Once the waveform data points are stored, configure STREAM\_OUT#(0:3)\_LOOP\_SIZE and STREAM\_OUT#(0:3)\_SET\_LOOP.

Stream-Out Waveform Periodicity			
Name		Start Address	Type Access
 STREAM_OUT#(0:3)_LOOP_SIZE	The number of values, from the end of the array, that will be repeated after reaching the end of supplied data array.	4060	UINT32 R/W
 STREAM_OUT#(0:3)_SET_LOOP	Controls when new data and loop size are used. 1=Use new data immediately. 2=Wait for synch. New data will not be used until a different stream-out channel is set to Synch. 3=Synch. This stream-out# as well as any stream-outs set to synch will start using new data immediately.	4070	UINT32 W

&print=true

## 4. Start stream

Next, start stream with STREAM\_OUT#(0:3) in the scan list.

Name		Start Address	Type Access
------	--	---------------	-------------

Name		Start Address	Type	Access
 STREAM_OUT#(0:3)	Include one or more of these registers in STREAM_SCANLIST_ADDRESS#(0:127) to trigger stream-out updates. When added to the scan list these do count against the max scan rate just like normal input addresses, but they do not return any data in the stream read.	4800	UINT16	R

```
&print=true
```

The order of STREAM\_OUT#(0:3) in the scan list determines when the target updated. For example, if STREAM\_OUT3 is before STREAM\_OUT0 in the scan list, STREAM\_OUT3\_TARGET will be updated before STREAM\_OUT0\_TARGET.

## 5. Stream Loop

Read from stream, if there are stream-in channels.

Also, if the output waveform needs to be updated, read STREAM\_OUT#(0:3)\_BUFFER\_STATUS to determine when to write new values to the buffer. When to write values depends on how large the buffer is and how many values need to be written.

Name		Start Address	Type	Access
 STREAM_OUT#(0:3)_BUFFER_STATUS	The number of values in the buffer that are not currently being used.	4080	UINT32	R

```
&print=true
```

For a more thorough description of how a Stream-Out buffer works, see [3.2.1.1 Stream-Out Description](#).

## 6. Stop stream

Stopping a stream that streams out is no different from stopping stream-in.

## Example

This example demonstrates how to configure DAC0 to output an analog waveform that resembles a triangle wave, and also quickly measure two analog inputs AIN0 and AIN2 in streaming context.

### Configuration steps specific to stream-out

```
STREAM_OUT0_ENABLE = 0    -> Turn off just in case it was already on.
STREAM_OUT0_TARGET = 1000 -> Set the target to DAC0.
STREAM_OUT0_BUFFER_SIZE = 512 -> A buffer to hold up to 256 values.
STREAM_OUT0_ENABLE = 1    -> Turn on Stream-Out0.
```

With the LJM library, write these registers with a call to `eWriteNames` or multiple calls to `eWriteName`.

## General stream configuration

```

STREAM_SCANLIST_ADDRESS0= AIN0    -> Add AIN0 to the list of things to stream in.
STREAM_SCANLIST_ADDRESS1= STREAM_OUT0 -> Add STREAM_OUT0 (DAC0 is target) to the list of things to
stream out.
STREAM_SCANLIST_ADDRESS2= AIN2    -> Add AIN2 to the list of things to stream in.
STREAM_ENABLE = 1                 -> Start streaming. LJM_eStreamStart does this.

```

With the LJM library, this is all done with the call to `eStreamStart`.

Other settings related to streaming analog inputs have been omitted here but are covered under the section for [stream mode](#).

## Load the waveform data points

The following data points have been chosen to produce the triangle waveform: 0.5V, 1V, 1.5V, 1V, so the next step is to write these datum to the appropriate buffer. Because it is a DAC output (floating point number), use the `STREAM_OUT0_BUFFER_F32` register.

```

STREAM_OUT0_BUFFER_F32 = [0.5, 1, 1.5, 1] -> Write the four values one at a time or as an array.
STREAM_OUT0_LOOP_SIZE = 4                 -> Loop four values.
STREAM_OUT0_SET_LOOP = 1                  -> Begin using new data set immediately.

```

With the LJM library, write the array using `eWriteNameArray`, and write the other 2 values with a call to `eWriteNames` or multiple calls to `eWriteName`.

## Observe result with stream mode

Every time the stream is run, AIN0 is read, then DAC0 is updated with a data point from Stream-Out0's buffer, then AIN2 is read. Thus, the streaming speed dictates the frequency of the output waveform.

## Sequential Data

Once a sequence of values has been set via the `STREAM_OUT#_SET_LOOP` register, that sequence of values will loop and only be interrupted at the end of the sequence. Therefore, to have stream-out continuously output a sequence of values that is larger than the size of one stream out buffer, probably the easiest way to do so is to:

1. Start by dividing the stream out buffer into 2 halves,
2. Write one half of the buffer with your sequential data,
3. In a loop, every time the `STREAM_OUT#_BUFFER_STATUS` reads as being half full/empty, write another half buffer-worth of values.

Note that the buffer is a circular array, so you could end up overwriting values if you're not careful.

Here's an example:

Stream-out buffer is 512 bytes, divide that by 2 to get the number of samples the buffer can hold => 256 samples

256 samples divided by 2 to get the "loop" size, AKA the set-of-data-to-be-written-at-a-time size => 128 samples

Write 128 samples:

Write 128 to STREAM\_OUT0\_LOOP\_SIZE

Write 128 samples to STREAM\_OUT0\_BUFFER\_F32 (This should probably be done by array write, which is much faster than writing values individually.)

Write 1 to STREAM\_OUT0\_SET\_LOOP

Loop while you have more sequential data to write:

Read STREAM\_OUT0\_BUFFER\_STATUS

If STREAM\_OUT0\_BUFFER\_STATUS is 128 or greater, write the next 128 samples, along with STREAM\_OUT0\_LOOP\_SIZE = 128 and STREAM\_OUT0\_SET\_LOOP = 1

Sleep for something like  $1 / \text{scanRate}$  seconds to prevent unnecessary work for the hardware

## 3.2.1.1 Stream-Out Description [T-Series Datasheet]

[Log in](#) or [register](#) to post comments

### T-Series Stream-Out Animation/Presentation

The T-Series Stream-Out presentation is only viewable online. Please go to our website <https://labjack.com/support/datasheets/t-series/communication/stream-mode/stream-out/stream-out-description>.

## 3.2.2 Low-Level Streaming [T-Series

# Datasheet]

[Log in](#) or [register](#) to post comments

## Overview

Stream mode is complicated but can easily be executed using the [high-level LJM stream functions](#). LJM is recommend for all users, except users that need to integrate a T-series device into a system that cannot use LJM. The rest of this section is about manually executing stream protocol without LJM. For an introduction to stream and for additional configurations, see [3.2 Stream Mode](#).

Executing stream mode involves the following:

- Stream setup
- Stream start
- Stream-in data collection, if any stream includes stream-in channels
- Stream-out buffer updates, if stream includes stream-out channels (See [3.2.1 Stream-Out](#))
- Stream stop

### Spontaneous Stream vs. Command-Response Stream:

Data can be sent to the host in one of two data collection modes:

- Spontaneous: In spontaneous mode, packets are automatically sent to the host as soon as there is enough data to fill a packet. The packet size is adjustable. See the register definitions below.
- Command-Response (CR): In CR mode, the stream data is stored in the device's buffer and must be read out using a command. CR mode is useful for when the connection is unreliable.

T-series devices connected via either USB and Ethernet are capable of both spontaneous stream and command-response stream.

T7-Pro only: T7-Pro devices connected via WiFi are capable of only command-response stream.

## Setup

Manual stream setup requires configuration of the registers that [LJM\\_eStreamStart](#) automatically configures:

Manual Stream Setup			
Name	Start Address	Type	Access

Name		Start Address	Type	Access
 STREAM_SCANRATE_HZ	Write a value to specify the number of times per second that all channels in the stream scanlist will be read. Max stream speeds are based on Sample Rate which is NumChannels*ScanRate. Has no effect when using and external clock. A read of this register returns the actual scan rate, which can be slightly different due to rounding. For scan rates >152.588, the actual scan interval is multiples of 100 ns. Assuming a core clock of 80 MHz the internal roll value is $(80M/(8*DesiredScanRate))-1$ and the actual scan rate is then $80M/(8*(RollValue+1))$ . For slower scan rates the scan interval resolution is changed to 1 us, 10 us, 100 us, or 1 ms as needed to achieve the longer intervals.	4002	FLOAT32	R/W
 STREAM_NUM_ADDRESSES	The number of entries in the scanlist	4004	UINT32	R/W
 STREAM_SAMPLES_PER_PACKET	Specifies the number of data points to be sent in the data packet. Only applies to spontaneous mode.	4006	UINT32	R/W
 STREAM_AUTO_TARGET	Controls where data will be sent. Value is a bitmask. bit 0: 1 = Send to Ethernet 702 sockets, bit 1: 1 = Send to USB, bit 4: 1 = Command-Response mode. All other bits are reserved.	4016	UINT32	R/W
 STREAM_SCANLIST_ADDRESS#(0:127)	A list of addresses to read each scan. In the case of Stream-Out enabled, the list may also include something to write each scan.	4100	UINT32	R/W
 STREAM_ENABLE	Write 1 to start stream. Write 0 to stop stream. Reading this register returns 1 when stream is enabled. When using a triggered stream the stream is considered enabled while waiting for the trigger.	4990	UINT32	R/W

&print=true

### Additional Configuration Notes

Additionally, address 4018 (STREAM\_DATATYPE) must be written with the value 0. Note that address 4018 (STREAM\_DATATYPE) is not in [ljm\\_constants.json](#) and is not compatible with [LJM\\_NameToAddress](#).

STREAM\_ENABLE must be written last.

For other stream configuration registers, which are not required for all streams, see [3.2 Stream Mode](#).

# Data Collection

**Spontaneous Stream:** Once stream has been initiated with `STREAM_ENABLE`, the device sends data to the target indicated by `STREAM_AUTO_TARGET` until `STREAM_ENABLE` is written with the value 0. Stream-out streams that do not contain stream-in channels (see above) do not send data.

## **Modbus Feedback Spontaneous Packet Protocol:**

Bytes 0-1: Transaction ID

Bytes 2-3: Protocol ID

Bytes 4-5: Length, MSB-LSB

Bytes 6: 1 (Unit ID)

Byte 7: 76 (Function #)

Byte 8: 16

Byte 9: Reserved

Bytes 10-11: Backlog Bytes

Bytes 12-13: Status Code

Byte 14-15: Additional status information

Byte 16+: Stream Data (raw sample = 2 bytes MSB-LSB)

**Command-Response Stream:** When collecting data using command-response stream mode, data must be read from `STREAM_DATA_CR` (address 4500). Data is automatically discarded as it is read.

## **Modbus Feedback Command-Response Packet Protocol:**

Bytes 0-1: Transaction ID

Bytes 2-3: Protocol ID

Bytes 4-5: Length, MSB-LSB

Bytes 6: 1 (Unit ID)

Byte 7: 76 (Function #)

Bytes 8-9: Number of samples in this read

Bytes 10-11: Backlog Bytes

Bytes 12-13: Status Code

Byte 14-15: Additional status information

Byte 16+: Stream Data (raw sample = 2 bytes MSB-LSB)

### Backlog Bytes:

Backlog Bytes is the number bytes contained in the device stream buffer after reading. To convert BacklogBytes to the number of scans still on the device:

$$\text{BacklogScans} = \text{BacklogBytes} / (\text{bytesPerSample} * \text{samplesPerScan})$$

Where bytesPerSample is 2 and samplesPerScan is the number of channels.

### Status Codes:

- 2940: Auto-recovery Active.
- 2941: Auto-recovery End. Additional Status Information is the number of scans skipped. A scan consisting of all 0xFFFF values indicates the separation between old data and new data.
- 2942: Scan Overlap
- 2943: Auto-recovery End Overflow
- 2944: Stream Burst Complete

## Stop

To stop stream, write 0 to STREAM\_ENABLE. All stream modes expect to be stopped, except for burst stream (see STREAM\_NUM\_SCANS for more information on burst stream).

## Code Example

A general low-level stream example written in C/C++ can be found [here](#).

---