

<u>Home</u> > <u>Support</u> > <u>Datasheets</u> > <u>Accessories</u> > LJTick-CurrentShunt

LJTick-CurrentShunt Datasheet

Log in or register to post comments LJTick-CurrentShunt Stock: Low Stock Price: \$45.00



Click here to order!

The LJTick-CurrentShunt (LJTCS) is a signal-conditioning module designed to convert 2x 4-20 mA current loop signals into voltage signals that vary from 0.472-2.360 volts. The 4-pin design plugs into the standard AnalogInput/AnalogInput/GND/VS screw terminal block found on newer LabJacks such as the U3, U6, UE9, T4, and T7. The major advantages of the LJTCS, compared to using a simple load resistor, are ease of use, high common-mode range, and lower voltage drop on the 4-20 mA signal.



Figure 1: LJTick-CurrentShunt

Figure 2: LJTick-CurrentShunt With U3

The pins shown on the right side of the LJTCS (Figure 1) connect to the LabJack. The VS/GND pins power the LJTCS, while the OUTA/OUTB pins send the output voltage signal to analog inputs on the LabJack.

Note that 4-20 mA corresponds to 0.472 to 2.36 volts, and thus on the U3-HV and T4 the low-voltage analog inputs (FIO/EIO) will provide the better results than the high-voltage analog inputs (AIN0-AIN3).

Following are descriptions of the LJTCS screw-terminal connections:

SGND: This terminal connects to LabJack ground (GND), with a 750 mA self-resetting thermal fuse in series. Often, the 4-20 mA sensor has its own power supply, and that supply ground needs to be connected to LabJack ground to provide a common reference. SGND allows that to be done, but protects from the risk of the external power supply dumping excess ground current through the LabJack.

VS: This is the same 5 volt output as the VS terminals on the LabJack itself. This is an output terminal, not an input. It can be used to provide 5 volt (nominal) power as needed.

INA+/INA- (or INB+/INB-): The 4-20 mA current loop should be connected to INA+ and INAsuch that the current flows into INA+ and out of INA-. Each channel has a 5.9 Ω measurement resistor (0805, 0.10%, 50ppm), and the voltage across that resistor is amplified by x20. So 4 mA gives about 0.472 volts and 20 mA gives about 2.36 volts.

Relationship between output voltage and input current:

I = V / (20 * 5.9) = V / 118

mA = 8.475 * *volts*

In addition to the 5.9 Ω shunt resistor, there is a self-resetting thermal fuse in series. This has a typical resistance of 18 Ω (min=3.6 and max=50). This does not affect the measurement, but does affect how much voltage is dropped as the 4-20 mA signal passes through the LJTCS.

The common-mode input range of the LJTCS is -8 to +28 volts. That means that the voltage of each of the inputs must be within that range compared to LJTCS ground.

If the 4-20 mA signal does not have a common reference at all with the LJTCS, one needs to be made. One common way of doing this is by connecting ground from the sensor to SGND on the LJTCS. SGND has a fuse in series and then connects to normal GND. The fuse is a 750 mA self-resetting thermal fuse, and prevents other systems from using the LJTCS ground as their power ground.

The following figures show typical connections. Figures 3 & 4 show typical connections with a 3wire sourcing type sensor. This type of sensor sources the 4-20 mA signal, which is then returned to sensor ground. The common-mode voltage of INA- is 0, while the common-mode voltage of INA+ is equal to the signal loading of the LJTCS (typically 0.48 volts @ 20 mA).




Figure 3: 3-Wire Sourcing Sensor Figure 4: 3-Wire Sourcing Sensor w/ Ext. Supply

Figures 5 & 6 show typical connections with a 2-wire (loop-powered) sourcing type sensor. This type of sensor sources the 4-20 mA signal, which is then returned to sensor ground. The common-mode voltage of INA- is 0, while the common-mode voltage of INA+ is equal to the signal loading of the LJTCS.




Figure 5: 2-Wire Sourcing Sensor



Figures 7 & 8 show typical connections with sinking type sensors. This type of sensor sinks the 4-20 mA signal, and thus the common-mode voltage of INA+ is equal to the full supply voltage and the common-mode voltage of INA- is equal to the supply voltage minus the signal loading of the LJTCS.




Figure 7: 3-Wire Sinking Sensor

Figure 8: 2-Wire Sinking Sensor

Troubleshooting:

- Note the discussion above about having a common reference. When you are using external supplies (Figures 4, 6, 7 and 8), those supplies must be referred to LabJack GND. If the supplies are not already referred (the DC output of an AC-DC supply is usually floating), make one connection from the common/negative of each power supply to SGND or GND on the LJTCS or LabJack.
- Use a DMM to measure the voltage of IN+ and IN- versus GND. Both must be in the range of -8 to +28 volts versus GND.
- Use a DMM to measure the voltage difference of IN+ versus IN-. The total input impedance of the LJTCS varies from 9 to 56 ohms, but the typical value is 24 ohms, and if you are putting 10 mA (for example) through 24 ohms you should measure a voltage difference of about 0.24 volts.
- Use a DMM to measure the voltage of OUT/AIN versus GND. The output voltage should be 20*5.9*I, so if the current is 10 mA (for example) the output voltage should be about 1.18 volts.
- Put a DMM in series with the IN+ terminal to see what it reports for current.
- Remove the LJTCS from the LabJack and remove all I/O connections, then use a DMM to measure the resistance from IN+ to IN-. The total input impedance of the LJTCS varies from 9 to 56 ohms, but the typical value at room temperature is 24 ohms.
- Rather than connecting your signal, do a basic test with a 1k resistor connecting VS to IN+ and a jumper from IN- to GND. This should result in roughly 5 mA (VS/1000), and then you can do the above measurements with that known current.
- Too much noise? First step is to isolate the source of the noise to the LabJack, LJTick-CurrentShunt, or the signal itself. Do the above test with a resistor, but rather than VS (which might be noisy) use a battery (great) or DAC output (good to great depending on device) with an appropriate resistor to get a current around 5 mA.

Specifications:

Parameter	Conditions	Min	Typical	Max	Units
General					
Supply Voltage		3.6	5	12	Volts
Supply Current			0.5		mA
Operating temperature		-40		85	°C
Signal Specs					
Gain (1)			20		V/V
Sense Resistor			5.9		Ohm (Ω)

19	May	201	9
	inay	-01	~


GaiseAaeelaaky			<u>Ø</u> .5		ñ٩٧
Total Input Impedance (2)		9	24	56	Ohm (Ω)
Signal Loading (2)	@ 20 mA		0.48		Volts
Common-Mode Range (3)	VS = 5 V		-8 to +28		Volts
Typical Output For 4- 20mA		0.472		2.36	Volts
Typical Output Range		0.02		VS - 0.2	Volts
Typical Input Range	Vout = 0.02 - 4.8 V	0.17		40.7	mA
-3dB Bandwidth			1200		Hz

(1) The 4-20 mA signal passes through a sense resistor, and the voltage across that resistor is amplified to produce the output voltage signal. Thus the response of the LJTick-Current is 118 mV/mA.

(2) The total input impedance is the sum of the sense resistor and the thermal fuse resistance, and is typically 21-27 ohms at room temperature. The voltage dropped across this total impedance by the 4-20 mA signal is the loading.

(3) The voltage from IN+/IN- to GND must stay within the common-mode limits.

Dimensions:



Declaration of Conformity

Manufacturers Name: LabJack Corporation Manufacturers Address: 3232 S Vance St STE 200, Lakewood, CO 80227 USA Declares that the product Product Name: LabJack Tick Current Shunt Model Number: LJTCS conforms to the following Product Specifications: EMC Directive: 89/336/EEC